



SERVICE MANUAL



CFORCE 520S/L

CF500AU-7A
CF500AU-7C

CFMOTO

Edition No. :20170208

Edition Item: CF500AU-7A/CF500AU-7C v1. pdf

www.cfmoto.com

All right reserved
ZHEJIANG CFMOTO POWER CO.,LTD.
February 2017

FOREWORD

This manual introduces CF500AU-7A/CF500AU-7C maintenance information, removal & installation procedure, checking & adjustment methods, troubleshooting and technical specifications in detail. There are illustrations to guide your operations.

Chapter 1 mainly introduces general operation information, service tools, vehicle structure and basic specifications.

Chapter 2 mainly introduces assemble and disassemble vehicle body covering parts methods.

Chapter 3 mainly introduces checking & adjustment methods and how to do vehicle maintenance.

Chapter 4 mainly introduces how to remove the parts at side the engine

Chapter 5 mainly introduces how to remove, check and maintain the engine parts, and some matters need to pay attention.

Chapter 6 mainly introduces the infomations of the vehicle chassis

Chapter 7 mainly introduces how to check and maintain lighting system and signal system

Chapter 8 mainly indroduces electrical parts and EFI system

Chapter 9 introduces the trouble shooting

Appendix: electrical schematic diagram

CFMOTO reserves right to make improvements and modifications to the products without priornotice. Overhaul and maintenance should be done according to actual condition of vehicle.

All rights reserved
Zhejiang CFMOTO Power Co., LTD.

February/2017

INDEX

M a i n t e n a n c e	1
B o d y c o v e r i n g p a r t s	2
P e r i o d i c i n s p e c t i o n a n d a d j u s t m e n t	3
E n g i n e s u r r o u n d i n g s	4
E n g i n e	5
V e h i c l e c h a s s i s	6
L i g h t i n g s y s t e m a n d s i g n a l s y s t e m	7
E l e c t r i c a l p a r t s a n d E F I s y s t e m	8
T r o u b l e s h o o t i n g	9
E l e c t r i c a l s c h e m a t i c d i a g r a m	Appendix

Unit changing calculation

Item	Conversion
Pressure	$1\text{kgf}/\text{cm}^2=98.0665\text{ kPa}; 1\text{kPa}=1000\text{Pa}$
	$1\text{mmHg}=133.322\text{ Pa}=0.133322\text{kPa}$
Torque	$1\text{kgf} \cdot \text{m}=9.80665\text{N} \cdot \text{m}$
Volume	$1\text{mL}=1\text{cm}^3=1\text{cc}$
Force	$1\text{L}=1000\text{cm}^3$
	$1\text{kgf}=9.80665\text{ N}$
Length	$1\text{in}=25.4\text{mm}$

Danger/Warning/Note

Please read the note below carefully. It shows “Danger”, “Warning” and “Note” professional meaning. Please pay attention to the special meaning when repairing the vehicle.

Danger: This problem may cause a person death or seriously injure.

Warning: This can cause a person injure. Pay attention

Note: This can cause a person get hurt or machanical damage.

But pay attention: All the notice in this manual including “Danger”, “Warning” cannot include all the potential dangerous in using and repairing work. For this reason, technicians must have basic knowledge of the machenic except “Danger” and “Warning” rules. If you have no confidence to finish the work. Please ask experienced technicians.

1 Maintenance Information

- | | |
|---|--|
| 1.1 Operationcautions information···1-1 | 1.5Tightening torque table ······1-8 |
| 1.2 Maintenance Information ······1-3 | 1.6Lubricants and seal products·····1-10 |
| 1.3 General specifications ·······1-4 | 1.7Wiring,pipes&cables ·······1-11 |
| 1.4 Maintenance specifications ·····1-6 | |

1.1 Operation cautions

Safety cautions

1. Wear proper work clothes(e.g.:boiler suits), cap and boots. If necessary, wear dustglass, gloves and mask.
2. Engine exhaust fumes are poisonous and can result in loss of consciousness or death. Do not run the engine in an enclosed or poorly ventilated area.
3. Do not touch the engine or muffler with bare hands after the engine has been just stopped to avoid burns.
4. Battery electrolyte (dilute sulfuric acid) is highly caustic and can result in burns from contact with skin and eyes. If you spill electrolyte on skin,flush with water and seek for medical attention immediately. If you spill electrolyte on clothes,flush with water in order to avoid burns.Keeping battery and electrolyte out of reach of children.When the battery is being charged, it produces explosion gases which may cause explosive. Charge the battery in a well-ventilated area.
5. Coolant is poisonous. Do not drink or spill it on skin, eyes or clothes. If you spill coolant on skin,pls wash with soap and water immediately. If you spill coolant on eyes, flush with water and seek prompt medical attention.If you swallow coolant, induce vomit and see the doctor. Keep coolant out of reach of children.
6. Gasoline is highly flammable. Don't smoke or fire. Also keep gasoline away from sparks.. Vaporized gasoline is also explosive. operate it in a well-ventilated area.
7. Be careful not to get pinched by the turning parts like wheels and clutch.
8. When more than two people are operating, keep reminding each other for safety purpose.

Cautions for removal and installation

1. Use genuine CFMOTO parts, lubricants and service products.
2. Store the removed components separately in order for correct installation.
3. Clean mud, dust before servicing.
4. Replace the removed washers, o-rings, piston pin retainers, cotter pins with new ones.
5. Elastic retainers might get distorted after disassembled. Do not use the loosened retainers.
6. Clean and blow off the detergent after removal. Apply lubricants on the surface of moving parts.
7. Measure the data during removal for correct installation.
8. Pre-tighten the bolts, nuts and screws, then torque to specification.The basic sequence is from big to small, from inner side to outer side and criss-cross.

9. Checking the removed rubber parts are aged and replace if necessary. Keeping the rubber parts away from grease.
10. Apply or inject recommended lubricant to the specified lubrication points.
11. Use special tools when necessary.
12. Finger turn the inner and outer rings of ball bearing to make sure the bearing will turn smoothly. When ball bearing is removed by pressing steel balls, it can not be reused:
Replace if the axial or radial play is too big.
If the bearing surface is uneven, clean with oil and replace if the cleaning does not work.
When pressing the bearing into the machine or onto the shaft, if the bearing can not be securely seated, replace it.
13. Install the one-side dust-proof bearing in the right direction. When assembling the open type or double-side dust-proof bearing, install with manufacturer mark outward.
14. Install the elastic circlip properly. Turn the circlip after assembling to make sure it has been installed into the slot.
15. After assembling, check whether all the tightened parts are properly tightened and can move smoothly.
16. Brake fluid and coolant may damage painting, plastic and rubber parts. Flushing with water if you splashed on these parts.
17. Install oil seal with the side of manufacturer's mark outward. Do not fold or scratch the oil seal lip. Apply grease to the oil seal lip before assembling.
18. When installing pipes, insert the pipe till the end of joint. Fit the pipe clip, if any, into the groove. Replace the pipes or hoses that cannot be tightened.
19. Do not mix mud or dust into engine and/or the hydraulic brake system.
20. Clean the gaskets and washers of the engine casing before assembling. Remove the scratches on the joint faces by polishing evenly with an oilstone.
21. Do not twist or bend the cables too much. Distorted or damaged cables may cause poor performance.
22. When assembling the parts of protection caps, insert the caps to the grooves, if any.

I ENGINE BREAK-IN

There are many movable components inside the engine, such as piston, piston ring, cylinder, crankshaft, gears and so on. During initial use period, proper run-in for every critical component is necessary. Break-in can help engine components match each other better and adjust working condition. Careful treatment of a new engine will result in more efficient performance and a longer service life.

Recommended break-in period: First 20 hours:

0~10 Hours: Do not operate continuously at more than 50% throttle position. Cool down the engine for every 5~10 minutes after every 1 hour operation. Avoid sudden acceleration. Vary the throttle position slowly and smoothly. Do not vary the throttle position rapidly

10~20Hours Avoid long-time run at more than 75% throttle position. Do not open throttle completely during the period.

ATTENTION:

- Maintain and repair as regular procedures during break-in period
- After break-in, do not forget to check and maintain the engine before normal using.


1.2 LOCATION OF VIN/EIN

Model Number: CF500AU-7A /CF500AU-7C




① VIN: LCELDTZE~/LCELDTZF~

② Name plate:

③ EIN: 191R~



CF500AU-7A



CF500AU-7C

CFMOTO

1.3 GENERAL INFORMATION

Item		Specifications	
Vehicle model		CF500AU-7A	CF500AU-7C
Overall length×width×height (mm)		2105 mm×1100 mm×1150 mm	2305 mm×1100 mm×1350 mm
Wheelbase		1260 mm	1460 mm
Engine type		191R	
Displacement		495mL	
Fuel type and Octane No.		RQ-92 or higher unleaded gasoline	
Dry weight		343 kg	358 kg
Passengers		2 persons (including driver)	
Total vehicle load allowed		2persons+60 kg =210 kg	
Tire	Front	24×8-12 45J AT25×8-12 40L	AT25×8-12 40J
	Rear	24×10-12 52J AT25×10-12 50L	AT25×10-12 47J
Min. ground clearance		250mm	
Min. turning radius		CF500AU-7A :7.5m ; CF500AU-7C:8.5m	
Engine	Starting	Electric	
	Type	Single cylinder,4-stroke,liquid-cooled,4 valves,SOHC	
	Valves	SOHC	
	Bore×Stroke	91mm×76.2mm	
	Compression ratio	10.3:1	
	Lubrication	Pressure + splash lubrication	
	Oil pump	Rotor type	
	lubricating oil filter	Full flow rotary filter, paper type	
	Engine oil type	SAE15W-40/SG level or higher	
	Cooling way	Liquid-cooled/close-loop cooling	
Coolant	-30℃anti-corrosion and anti-freezing cooling liquid		

1 Maintenance

1

Item		Specifications			
Air filter type		Paper filter element			
Throttle	Model	0GQ0-173000-20000			
	Diameter of throttle body	40mm			
Fuel tank capacity		15L±1L			
Transmission	Clutch		Dry auto centrifugal		
	Transmission		CVT + Gearshift		
	Gearshift		Two drive gears, one reverse gear, one parking gear		
	Gearshift methods/orders		Manual operation/L-H-N-R-P		
	CVT ratio range		0.675~3.021		
	Gear shift ratio		H	L	R
		Final	1.333		
		Secondary	1.952		
		Single gear	1.350	2.533	2.071
		Total ratio	3.514	6.595	5.392
	Ratio of the axel	Front	33 / 9 = 3.667		
Rear		33 / 9 = 3.667			
Output type		Front/Rear shaft drive			
Rotation of engine output		When forward, clockwise (rear view)			
Steering	Turn angle	Inner	21°		
		outer	28°		
Brakes	Front	Hydraulic disc			
	Rear	Hydraulic disc			
Absorber	Suspension	Double A-arm and independent			
Frame type		Steel tube and plate			

CFMOTO

1.4 MAINTENANCE SPECIFICATIONS

I Lubrication System

Item		Standard	Service limit
Engine oil capacity	Only oil replaced	2800mL	—
	Oil with filter replaced	2900mL	
	Totally dry	3000mL	—
<p>Engine oil recommend</p>		<ul style="list-style-type: none"> Specially for 4 stroke motor: SAE-15W-40. If it's not available, select alternative according to the following specifications API classifications: SG or higher SAE rating: choose from the left chart according to 	
Oil Pump Rotor	Clearance Between Inner and Outer Rotor	0.07 mm ~ 0.15mm	0.2mm
	Clearance Between Outer Rotor and Bore	0.03 mm ~ 0.10mm	0.12mm
	Rotor End Clearance	0.023 mm ~ 0.055 mm	0.12 mm
	Oil Pressure	1500r/min , 90 °C 200kPa ~400kPa, Normally 240 kPa 6000r/min , 90 °C 600kPa ~700kPa, Normally 600 kPa	

I Air Intake System(See 0 5- Engine)

I Cooling System

Item		Standard		Remark
Coolant capacity	Full capacity	About 2500mL		
	Reservoir capacity	350mL		
	Density	50%		
Opening pressure		110 kPa±15kPa(1.1kgf/cm ²)		
Thermostat	Opening temp.	65°C±2°C		
	Full open temp.	85°C		
	Full open travel	85°C, >5mm		
Relations between water temp.and resistant of water temp. sensor	Coolant temp (°C)	Resistant of B terminal (Ω)	Resistant of A,C terminal (kΩ)	
	-20	---	13.71~16.94	
	25	---	1.825~2.155	
	50	176~280	----	
	80	63.4~81.4	0.303~0.326	
	110	24.6~30.6	0.138~0.145	
Coolant type	-30°C anti-freezing, anti-corrosive and high boiling point			

I Wheel (same for front & rear)

Item		Standard	Service limit
Rim jump	Longitude	1.0mm	2.0mm
	Transverse	1.0mm	2.0mm
Tire	Remaining groove	—	3.0mm
	Front tire Pressure	24 inch: 56kPa (0.57kgf / cm ²)	—
		25 inch: 45 kPa (0.46kgf / cm ²)	—
	Rear tire Pressure	24 inch: 42kPa (0.43kgf / cm ²)	—
25 inch: 45 kPa (0.46kgf / cm ²)		—	

I Braking System

Item		Standard	Service limit
Front break	Break disc thickness	3.5mm	2.5mm
Rear break	Handle bar travel	10 mm ~20 mm	—
	Break disc thickness	3.5mm	2.5mm

I Battery / Charging Device

Item		Standard	
AC magneto	Type	Magneto 3-phase A C flywheel Generator	
	Output	3-phase AC output	
	Resistance of coil (20°C)	0.5Ω~1.5Ω	
	Resistance of pick- up coil	900Ω~1000Ω	
	Voltage without load(cold engine)	>50V (AC), 5000r/min	
	Max. output power	320W, 5000r/min	
	S table voltage	13.5V~15.0V, 5000r/min	
	Peak voltage of pick-u p	≥ 3V, 200 r/min	
Regulator type		3 -phase supply power o f thyris tor trigger circuit	
Battery	Capacity	12V 30Ah	
	Voltage between terminals	Fully charged	14.4V
		Battery low	Lower 11.8V
	Recharging current/time	Normal	2.7A / 5h~10h
Fast charge		12A / 1h	

I Ignition System

Item		Standard
Ignition type		ECU
Spark plug	Type	Resistant-type
	Standard	DCPR8E (NGK)
	Gap of spark plug	0.8mm~0.9mm
	Characteristic	>8mm, 100kpa
Ignition time	BTDC10° 1500r/min	
Resistance of ignition coil	Primary	0.74Ω~0.78Ω
	Secondly	10.1kΩ~11.1kΩ
Peak voltage	Primary	>25V

	Pulse voltage	2V
	Resistance of starter relay coil	3Ω ~5Ω
	Resistance of auxiliary relay	90Ω ~100Ω

I Light / Dashboard / Switch

Item		Standards
Fuse	Main	30A
	Auxiliary	10A×1 15A×5
Light & Bulb	Headlight (Hi / Lo)	12V HS1 35/35W×2
	Front turn light	12V W16W 16W×2
	Front position light	12V 3LED/1.5W×2
	Daytime running light	12V 35W×2
	Brake light/Tail light	12V 21/5W×1
	Rear turn light	12V R10W 10W×2
	License plate lamp	12V 5W W5W
	Dashboard indicator light	LCD

I Valves & Cylinder Head (See 05-Engine)

I Cylinder, Piston, Piston Ring & Crankshaft (See 0 5- Engine)

I Clutch + CVT + Gearbox (See 0 5- Engine)

1. 5 Tightening Torque for fastener

Attention:

Threads and contact area should be applied by anti-corrosive grease before assembling.

I Tightening Torque for pointed part- body of vehicle

1 Maintenance

1

No.	Item	Specification or P/N	Qty	Torque (N·m)
1	Engine front and rear	GB5789 M12×1.25×180	2	60~70
2	Engine front bracket	GB5789 M12×1.25×170	1	60~70
3	Engine front bracket	GB5789 M10×20	4	40~50
4	Front and rear rocker	GB5789 M10×1.25×70	16	40~50
5	Shock absorber	GB5789 M10×1.25×50	8	40~50
6	Rear wheel bracket	GB5789 M10×1.25×100	4	40~50
7	Wheel nut	901A-07.00.02	16	70~80
8	Wheel shaft nut	5HY0-110001 M20×1.5	4	220~250
9	Front and rear axel	GB5789 M10×1.25×110	4	40~50
10	Steering rod ball pin nut	9010-100002	4	40~50
11	Handle bar cover bolt	GB5789 M8×55	4	30~40
12	Front brake caliper bolt	GB5789 M8×25	4	20~30
13	Front brake disc bolt	9010-080003	8	30~35
14	Rear brake caliper bolt	GB57891 M10×1.25×55	2	40~50
15	Rear brake disc bolt	7020-100001	2	30~35
16	Muffler mounting bolt	GB5789 M10×1.25×70	1	40~50
17	Muffler mounting bolt	GB5789 M8×65	1	30~40
18	Exhaust pipe	8010-020001	2	25~35
19	Steering knuckle bolt	GB5789 M10×1.25×35	2	40~50
20	Towing bracket	GB5789 M10×1.25×70	2	40~50
21	Winch motor mounting	GB5789 M8×20	4	35~45
22	Cable wheel mounting	GB5789 M10×1.25×20	2	40~50
23	Fuel pump mounting	GB/T5789 M5×14	6	5~8
24	Oxygen sensor	018B-176000	1	40~60
25	Wheel nut	9010-070002-A000	16	70~80
26	EPS steering joint	9CR6-102003	2	35~45

CFMOTO

I Tightening Torque of Specified parts-Engine(See 05-Engine)

I Tightening Torque of Not specified Part

Item	Torque N • m	Item	Torque N • m
5mm bolt、nut	5	5mm screw	4
6mm bolt、nut	10	6mm screw	9
8mm bolt、nut	20~30	6mm SH flange bolt	10
10mm bolt、nut	30~40	6mm flange bolt、nut	12
12mm bolt、nut	40~50	8mm flange bolt、nut	20~30
		10mm flange bolt、nut	30~40

Engine Service Tools(See 0 5- Engine)

Engine Special Service Tools(See 0 5- Engine)

1. 6 Lubricants ,Sealants

Covering parts	Cautions	Oil or grease
Steering bearing Throttle cable connector Throttle moving parts Breaking pedal moving parts Rocker arm moving parts Steering shaft inner surface Seat pad moving parts Shifting moving parts		Grease


Control cable, Bearing, Other movement parts lubricants

Parts	Detail	Material
Steering shaft ball sleeve	Lubrication	Automotive general lithium based grease GB/T5671
rear axle shaft bracket		
knuckle bearing, front & rear absorber		
Throttle control handle shaft & cable joint		
brake lever spindle		
Joint of packing cable		
rotation part of rear brake pedal		
Front, rear drive shaft spline joints	Grease 15g~18g	The Great Wall G-2 universal grease T1

Engine running material & install accessories(See 0 5- Engine)

Engine running material including lubricating oil(engine oil),greese(butter)and cooling liquid;install accessory including sealant,thread lock glue etc .

1.7 Wiring, pipes & cables




1

1. Cap, Reservoir Tank 2. Auxiliary Relay 3. Fuel Pump Relay 4. Brake Relay 5. 4x4 drive relay 6. 2x4 drive relay 7. Fan Relay 8. Low Beam Light Relay 9. High Beam Light Relay 10. Day Running Light Relay 11. EPS connector 12. Fan connector 13. Radiator Cap 14. Reservoir Tank. NOTE: Before check or repair above items, rack cover should be removed, see details in Chapter 2 -Body covering parts.




1. Fan Connector 2. EPS diagnostic 3. Dashboard Connector 4. EPS Connector 5. Connector, Right Handlebar Switch 6. Connector, Ignition Switch 7. Flasher 8. Connector, Right Front Headlight 9. Connector, Left Front Headlight Note: Before checking above items, Front rack, front rack, front fender, left and right side panel, dashboard cover, etc. should be removed. See details in Chapter 2- Body covering parts.


CFMOTO




1 .Cable,Horn 2.Connector,Horn 3.Horn 4 .Radiator 5.Connector, Left Front Headlight.




1. Oil Level Sensor 2. Fuel Pump 3. Cable, Fuel Pump 4. High Tension Pipe 5. Connector, Oil Level Sensor 6. Check Valve 7. Oil Pan 8. Cap, Fuel Tank 9. Oil Filter
 Note: Before checking above items, seat, front rack, left and right side panel, dashboard cover and front fender, etc should be removed. See details in Chapter 2 -Body covering parts .



1.Negative Cable,Starter Motor 2.Sensor, Ignition Singal 3.Magnetor Charging Cable 4.Positive Cable, Starter Motor 5.Gearshift 6.Water Inlet Pipe, Radiator 7.Water Outlet Pipe, Radiator




1 2




3 4 5 6 7 8




1. Tail Light 2. Connector,Right Turn Light (Symmetrical to Connector, Left Tail Light) 3. Connector, Left Turn Light 4. Connector, Tail Light 5 . Connector,Trailer Power Socket (NOTE:Voltage of trailer power socket (DC12V) Max.current is less than 10A. The power output only supplies rear turn light of trailer, tail light and rear licence light.) 6. Air Pipe, Rear Axle 7. Licence Light 8. Connector, Right Tail Light




1 . Throttle body 2.Air intake temp. sensor 3.Fuel injector cap 4 .Connector,fuel injector
5.Throttle cable 6.Sensor. Water temp. 7.Oil pressure sensor 8.Exhaust gas pipe, crankcase




1 . Positive Cable, Starter Motor 2 . High Tension Cable 3 .Idle speed stepper motor
4 . Magneto Valve, Idle



1. Cable, Brake Switch 2. Cable, Winch Motor 3. Water Outlet Pipe 4. Winch Motor 5. Speed Sensor 6. Oxygen Sensor 7. Connector, Oxygen Sensor 8. Cable, Regulator 9. Connector, Regulator 10. Regulator 11. Power Socket, Trailer 12. Connector, Rear Turning Light (LH) 13. Connector, Licence Light



1.Oil pipe 1 2.Oil pipe 2



1.ECU 2.Differential relay.

2 Body covering parts

2.1 Maintenance Information	2-2	2.7.1 LH/RH Rear Turn Light Guard.....	2-12
2.2 Installation torque.....	2-2	2.7.2 LH/RH Rear Decoration Panel.....	2-13
2.3 Disassemble & installation of Driver Seat, Front & Rear Rack, Backrest, Handgrip		2.7.3 Tail Light Panel.....	2-13
2.3.1 Driver Seat.....	2-3	2.7.4 Rear Fender.....	2-14
2.3.2 Handlebar cover	2-3	2.7.5 Rear Box.....	2-15
2.3.3 Front Rack	2-3	2.7.6 Turning light cover.....	2-15
2.3.4 Backrest	2-4	2.8 LH/RH foot step, LH/RH footrest board, Tool case, Oil filter cap, Engine side cover, Deco cover recoil starter	
2.3.5 Left/Right Handgrip.....	2-4	2.8.1 LH/RH Foot Step.....	2-16
2.3.6 Rear rack.....	2-4	2.8.2 LH/RH Footrest Board.....	2-16
2.4 Front Decoration Panel, Dashboard Cover, Fuel Tank Top Cover, Left/Right Side Cover, Gearshift decoration Cover, Fuel Tank Lower Cover		2.8.3 Tool Case.....	2-16
2.4.1 Front Decoration Panel	2-5	2.8.4 Cap, Oil Filter	2-17
2.4.2 Dashboard Cover	2-5	2.8.5 Engine Side Panel.....	2-17
2.4.3 Fuel Tank Top Cover	2-6	2.8.6 Deco cover, recoil starter.....	2-17
2.4.4 LH/RH Side Cover	2-6	2.9 Engine Panel, LH/RH Front Protector, LH/RH Rear Protector, Extended Skid Plate	
2.4.5 Gearshift Decoration Cover	2-7	2.9.1 Front Panel, Engine.....	2-18
2.4.6 Fuel Tank Lower Cover.....	2-7	2.9.2 Middle Panel, Engine.....	2-18
2.5 Left/Right headlight guard, LH/RH front lower inner fender, LH/RH front upper inner fender, LH/RH handguard, front fender		2.9.3 Rear Panel, Engine	2-18
2.5.1 LH/RH headlight guard.....	2-8	2.9.4 LH/RH Front Protector.....	2-19
2.5.2 LH/RH front lower inner fender...	2-8	2.9.5 LH/RH Rear Protector.....	2-19
2.5.3 LH/RH front upper inner fender...	2-8	2.9.6 Extended Skid Plate.....	2-19
2.5.4 LH/RH handguard.....	2-9	2.10 (Single Seat) LH/RH side panel, LH/RH footrest board	
2.5.5 Front Fender.....	2-10	2.10.1 LH/RH side panel.....	2-20
2.6 LH/RH Damper, Front Lower Fender, Bumper, Front Face, Fuel Tank Front Cover		2.10.2 LH/RH footrest board.....	2-20
2.6.1 LH/RH Damper	2-11	2.11 Rack Cover, Rack, Handgrip	
2.6.2 Front Lower Fender.....	2-11	2.11.1 Front Rack Cover	2-21
2.6.3 Bumper	2-11	2.11.2 Front Rack	2-21
2.6.4 Front Face.....	2-12	2.11.3 Deco Cover, Backrest.....	2-21
2.7 LH/RH rear turn light guard, LH/RH rear decoration panel, tail light panel, rear fender, Rear case, LH/RH turn light decoration cover		2.11.4 Rear Handgrip	2-22
		2.11.5 Rear Rack Cover.....	2-22
		2.11.6 Rear Rack.....	2-22
		2.12 Description of Outer Parts.....	2-23

2.1 Maintenance information

Maintenance notice

When replacing the warning stickers on vehicle body. Follow the original to paste all the stickers on vehicle body.

This chapter shows the order of install and remove order of the body parts. You can follow all the maintenance step in this chapter.

And also the cargo frame, seat pad, back rest, here has all the maintenance work for these.

For pipes and cables. Please follow cables, pipes, cables line to go though in The right position.

2.2 Assembly torque:

M8 bolt 20 (2.0) Torque N • m (kgf • m)

M6 bolt 10 (1.0) Torque N • m (kgf • m)

M5 bolt 5 (0.5) Torque N • m (kgf • m)

Screw 4 (0.4) Torque N • m (kgf • m)

2 Body covering parts

2.3 Seat assy, Handle bar cover, Cargo frame, back rest, rear handle.

2.3.1 Seat assy

Remove

Twist the seat hook 1


Lift up the seat and pull out the seat assy 2

Install

Reverse the removal procedures for installation.

Inspect the seat after installed.

To make sure it is stable.



2.3.2 Handlebar cover.


Remove

Pull up hard to open 2 locker 1

Take off the handle bar cover 2

Install

Reverse the removal procedures for installation.



2.3.3 Front cargo frame


Remove

Disassemble 4 M8 bolt 1

Remove the front cargo 2

Install

Reverse the removal procedures for installation.



2.3.4 Back rest

Remove

Remove 2 M6 bolt 1

Pull out the back rest 3 from 2

Loeking sleeves 2.


Install

Reverse the removal procedures for installation.

Be careful with the direction of the back rest

Inspect the back rest after installation to

check if it is loosen or not.



2.3.5 Rear right handle bar

Remove

Remove 3 M8 bolt 1

Remove the handle bar 2


Install

Reverse the removal procedures for installation.

Left handle bar

Removal and installation

Same as the right side.



2.3.6 Rear cargo frame

Remove

Remove the backrest.(2.3.4)

Remove the left and right handle bar(2.3.5)


Remove 2 M6 bolt 1

Remove 4 M8 bolt 2

Remove the rear cargo frame 3

Install

Reverse the removal procedures for installation



2 Body covering parts

2.4 Front panel, dashboard cover, tank cover, left/right side cover, Shift deco cover, fuel tank lower cover

2.4.1 Front Panel

Remove

Loosen clamp through collar NO.1

Raise the rear of the front panel




NO.2

Slide front panel NO.4 rearward out from

6 clips No.3

Install

Reverse the removal procedures for installation.



2.4.2 DASHBOARD COVER

Remove

Remove front panel(2. 4 .1)

Pull clamps out from 4 collars NO.1 upward with 45 degree backwards


Disconnect dashboard connector No.2

Loosen two M6 bolts No.3

Remove dashboard No. 4

Installation

Reverse the removal procedures for installation.



CFMOTO



2.4.3 TOP COVER, FUEL TANK

Remove

- Remove seat(2 . 3 .1)
- Remove dashboard(2 . 4 .2)
- Loosen four M6 bolts No.1
- Rotate off fuel tank cap No. 2
- Loosen two plastic clip No. 3
- Loosen three rubber collar No. 4
- Remove top cover No.5

Install

Reverse the removal procedures for installation.



2.4.4 Left and right side cover

Left side cover

Remove

- Remove top cover, fuel tank (2.4.3)
- Loosen M6 bolt No.1
- Loosen two tapping screw NO.2 Remove left side cover No.4 from Rubber collar No.3



Install

Reverse the removal procedures for installation.

Right side cover

Remove and install

Same way as left side cover.



2 Body covering parts


2.4.5 Gear shift cover

Removal


- Remove the left side cover (2.3.1)
- Remove three units trapping screw 1
- Pull out the lock cover 2
- Remove the gear shift cover 3

Install

Reverse the removal procedures for installation.



2




2.4.6 Fuel Tank lower panel

Removal

- Remove the Fuel Tank Protector Panel (upper) (2.3.1)
- Remove Fuel tank(4.1)
- Remove two units rubber gasket1
- Remove the g Fuel Tank Protector Panel (lower) 2

Instal

Reverse the removal procedures for installation.



CFMOTO

2. 5 Left and right headlight cover, left & right front inner fender (lower), left & right front inner fender (upper), left & right hand protector, front fender.

2. 5. 1 Left and front headlight cover Removal

Remove 1 units tapping screw 1

Remove 8 units plastic block 2


Remove the left and front headlight cover 3

Install

Install is inverse process to removing

Right and front headlight cover Removal

It is same removal process as right and front headlight cover.



2. 5. 2 Left and front inner fender (lower)

Removal

Remove 2 units plastic block 1

Remove 2 units snap joint 2

Remove the left and front inner fender (lower) 3



Install

Reverse the removal procedures for installation.

Right and front inner fender (lower)

Removal/ Installation

It is same removal process as left and front inner fender (lower)



2 Body covering parts

2. 5. 3 Left and front inner fender (Upper)


Removal

Remove left and front headlight cover (2.5.1)

Remove left and front inner fender(lower) (2.5.2)

Remove 1 unit plastic block 1

Loosen snap joint 2 Pull out snap joint from rubber sleeve 3 Remove left and front inner fender (upper)



2


Install

Reverse the removal procedures for installation.

Right and front inner fender (upper)

Removal

It is same removal process as left and front inner fender (upper)



2. 5. 4 Left hand protector

Removal

Remove 2 units M5 bolts 1

Remove 1 unit M8 bolts 2

Remove the left hand protector cover


Install

Reverse the removal procedures for installation.

Right hand protector

Removal

It is same removal process as left hand protector







2. 5. 5 Front Fender

Removal

- Remove front cargo frame (→ 2. 3. 3)
- Remove gear shift cover (→ 2. 4. 5)
- Remove the left and right headlight cover (→ 2. 5. 1)
- Remove the left & right and front inner fender (→ 2. 5. 3)
- Remove 6 units left and right plastic block1
- Remove 7 units M6 bolt 2
- Remove fuse 3
- Remove flasher 4
- Remove relay 5
- Remove 2 units tapping screw 6
- Remove oil cup 7
- Pull out 2 units snap joint from rubber sleeve 8
- Pull out front fender from 2 sockets 9
- Remove electric door lock 10
- Remove USB 11
- Remove external electric supply socket 12
- Remove front fender 13

Install

Reverse the removal procedures for installation.



2 Body covering parts

2.6 Left &right bumper block, Front fender(lower),bumper, Headlight panel

2.6.1 Left bumper block

Removal

Remove 1 units bolt 1

Remove left bumper block 2


Install

Reverse the removal procedures for installation.

Right bumper block

Removal

Same as the left side.



2

2.6.2 Front fender (lower)


Removal

Remove 4 units bolt 1

Remove front fender (lower) 2

Install

Reverse the removal procedures for installation.



2.6.3 Bumper

Removal

Remove left and right bumper block (2.6.1)


Remove left and right 2 units M8 bolt 1

Remove front 2 units M8 bolt 2

Remove bumper 3

Install

Reverse the removal procedures for installation.



2.6.4 Headlight panel

Removal

Remove left and right headlight cover (2.5.1)

Remove front fender (2.5.5)

Remove bumper(2.6.3)


Remove 4 units M6 bolt 1

Remove 8 units tapping screw 2

Remove front fender 3

Install

Reverse the removal procedure for installation



2.7 Left& right turning light cover, left& right rear panel, Rear light panel, rear fender, rear box, left& right turning light trim cover

2.7.1 Left turning light cover

Removal

Remove 5 units tapping screw 1

Remove left & rear turning light cover 2



Install

Reverse the removal procedure for installation

Right turning light cover

Removal/ Install

It is same removal process as left turning light cover



2 Body covering parts

2. 7. 2 Left Rear Panel

Removal

Pull open drawstring 1 and open rear light panel
Remove tapping screw 2

Push out left & rear panel from snap joint 3



Install

Reverse the removal procedure for installation.

Right rear panel

Removal/ Install

It is same removal process as left & rear panel



2. 7. 3 Rear light panel

Removal

Open rear storage box

Remove rear light connector 1

Remove M6 bolt 2

Come away spindle 3

Remove rear light panel 4

Install

Reverse the removal procedure for installation.




2.7.4 Rear fender

Removal

- Remove rear rack(2.3.6)
- Remove left& right side cover (2.4.4)
- Remove left& right rear turning light cover (2.7.1)
- Remove left & right rear panel(2.7.2)
- Remove rear light panel(2.7.3)
- Remove 8 units M6 bolt 1
- Remove battery 2 Remove 2 units plastic snap joint 3
- Remove 2 units M6 bolts 4
- Remove 4 units tapping screw 5
- Remove rear fender 6

Install

Reverse the removal procedure for installation.



2 Body covering parts

2.7.5 Rear Box

Removal


Remove rear fender (2.7.4)

Remove 4 units tapping screw 1


Remove rear box 2

Install

Reverse the removal procedure for installation.



2



2.7.6 Left turning light trim cover

Removal

Remove 2 units tapping screw 1

Remove left turning light trim cover 2


Install

Reverse the removal procedure for installation.

Right turning light trim cover

Removal/ Install

It is same removal process as left turning light trim cover



CFMOTO

2. 8 Left& right pedal, left&right foot rest, tool box Engine oil covering cap, left engine cover, recoil start

2. 8. 1 Left pedal

Removal

Remove 3 units M6 blot 1


Remove left pedal

Install

Reverse the removal procedure for installation.

Right pedal

It is same removal process as left pedal



2. 8. 2 Left foot rest

Removal

Remove front fender (2.5.5)

Remove rear fender(2.7.4)

Remove left pedal(2.8.1)

Remove 3 units M8 bolts 1

Remove 4 units M6 bolts 2


Remove left pedal 3

Install

Reverse the removal procedure for installation.

Right foot rest

It is same removal process as left foot rest



2. 8. 3 Tool box

Removal


Remove rear fender(2.7.4)

Remove 3 units M6 bolts 1

Remove tool box 2

Install

Reverse the removal procedure for installation.



2 Body covering parts

2.8.4 Engine oil covering cap

Removal


Remove rubber sleeve 1

Remove rubber sleeve 2

Remove engine oil covering cap 3

Install

Reverse the removal procedure for installation.



2

2.8.5 Engine left side cover

Removal

Remove engine oil covering cap


(→ 2.8.4)

Remove 3 units M6 bolts 1

Remove left engine cover 2

Instal

Reverse the removal procedure for installation.



2.8.6 Recoil start cover

Removal

Remove engine oil covering cap

(→ 2.8.4)


Remove left engine cover (→ 2.8.5)

Remove 4 units M6 bolts 1

Remove recoil start cover 2

Install

Reverse the removal procedure for installation



2.9 Engine front/middle/rear protection plate, left/right front suspension fender, left/right rear suspension fender, base board

2.9.1 Engine front protection plate


Removal

Remove 4 units M6 bolts 1

Remove engine front protection plate 2

Install

Reverse the removal procedure for installation.



2.9.2 Engine middle protection plate


Removal

Remove 4 units bolts 1

Remove engine middle protection plate 2

Install

Reverse the removal procedure for installation.



2.9.3 Engine rear protection plate


Removal

Remove 4 units bolts 1

Remove engine rear protection plate 2

Install

Reverse the removal procedure for installation.



2 Body covering parts

2.9.4 RH PROTECTOR, FRONT SUSPENSION


Removal

Remove M6 bolts 1

Remove LH protector, front suspension 2

Install

Reverse the removal procedure for installation.



2

LH PROTECTOR, FRONT SUSPENSION

The way of removal and installation is the same as RH protector, front suspension.

2.9.5 LH PROTECTOR, REAR SUSPENSION


Removal

Remove bolts M6 1

Remove LH protector, rear suspension 2

Install

Reverse the removal procedure for installation



RH PROTECTOR, REAR SUSPENSION

The way of removal and installation is the same as LH protector, rear 2 suspension.

2.9.2 BASE PLATE EXTENSION


Removal

Remove bolts 1

Remove base plate extension 2

Install

Reverse the removal procedure for installation.



2. 10 LH & RH SIDE PANEL, LH & RH FOOTREST, SHORT VERSION

2. 10. 1 LH SIDE PANEL

Removal

Remove top cover, fuel tank (2. 4. 3)

Remove bolts M6 No. 1 3

Remove tapping screws No. 2

Remove LH side panel No. 4



Install

Reverse the removal procedure for installation.

RH SIDE PANEL

Removal & Installation

Refer to LH side panel, Process it symmetrically



2. 10. 2 LH FOOTREST

Removal

Remove rear fender (→ 2. 5. 5)

Remove rear fender (→ 2. 7. 4)

Remove bolt M6 No. 1

Remove LH footrest No. 2


Install

Reverse the removal procedure for installation

RH FOOTREST

Removal / Installation

Refer to LH side panel, Process it symmetrically



2 Body covering parts

2.11 OPTIONAL RACK COVER, RACK, HANDRAIL

2.11.1 FRONT RACK COVER

Removal

Remove bolts M6 No.1

Remove front rack cover No.2

Install

Reverse the removal procedure for installation



2

2.11.2 FRONT RACK

Removal

Remove front rack cover(2.11.1)

Remove bolts M8 No.1

Remove front rack No.2

Install

Reverse the removal procedure for installation

2.11.3 DECO COVER, BACKREST

Removal

Remove bolts M6 No.1

Remove deco cover, backrest No.2

Install

Reverse the removal procedure for installation

CFMOTO

2. 11. 4 REAR HANDLE

Removal


Remove deco cover, backrest(2.11.3)

Remove bolts M8 No.1

Remove rear handrail No.2

Install

Reverse the removal procedure for installation



2. 11. 5 REAR RACK COVER


Removal

Remove bolts M6 No.1

Remove rear rack cover No.2

Install

Reverse the removal procedure for installation



2. 11. 6 REAR RACK

Removal

Remove deco cover, backrest (2.11.3)

Remove rear handrail (2.11.4)

Remove rear rack cover(2.11.5)


Remove bolts M8 No.1

Remove bolts M6 No.2

Remove rear rack No.3

Install

Reverse the removal procedure for installation



2 Body covering parts


2.12 外观件名称

REF NO.	PART NO.	NAME	PIC.
1	9GQ0-041011	Front face	
2	9GQ0-041023	Front top cover	
3	9GQ0-041021	Front fender	
4	9GQ0-041013	Headlight guard, LH	
5	9GQ0-041014	Headlight guard, RH	
6	9GQ0-041022	Dashboard cover	
7	9GQ0-041041	Front lower fender	
8	9GQ0-042011	Top cover, fuel tank	
9	9GQ0-042021	side panel, LH	
10	9GQ0-042022	side panel, RH	



2

CFMOTO

CFMOTO

REF NO.	PART NO.	NAME	PIC.
11	9GQ0-042023	Deco cover, gearshift	
12	9GQ0-042031	Footrest board, LH	
13	9GQ0-042032	Footrest board,RH	
14	9GQ0-043021	Rear fender	
15	9GQ0-043022	Rear box	
16	9GQ0-043023	Guard,LH tail light	
17	9GQ0-043024	Guard,RH Tail light	
18	9GQ0-043011	Panel,tail light	
19	9GQ0-044011	Lower panel, Fuel tank	

2 Body covering parts

REF NO.	PART NO.	NAME	PIC.
20	9GQ0-043025	Rear deco Panel,LH	
21	9GQ0-043026	Rear deco panel, RH	
22	9GQ0-044021	Engine skid plate,FR	
23	9GQ0-044022	Middle skid plate	
24	9GQ0-044023	Rear skid plate	
25	9GQ0-044031	Front upper inner Fender,LH	
26	9GQ0-044032	Front upper inner fender,RH	
27	9GQ0-044033	Front lower inner fender,LH	
28	9GQ0-044034	Front lower Inner fender, RH	

2

CFMOTO

CFMOTO

REF NO.	PART NO.	NAME	PIC.
29	9GQ0-044041	Front LH suspension protector	
30	9GQ0-044042	Front RH Suspension protector	
31	9GQ0-044044	Rear RH suspension protector	
32	9GQ0-044043	Rear LH suspension protector	
33	9GQL-042021	Left side panel	
34	9GQL-042022	Right side panel	
35	9GQL-042032	Footrest Board,RH	
36	9GQL-042031	Footrest board,LH	
37	9GQL-042033	Left foot pedal	

2 Body covering parts

REF NO.	PART NO.	NAME	PIC.
38	9GQL-042034	Right foot pedal	
39	9GQL-044024	Base plate extension	
40	9GQL-044025	Tool box	
41	9GQ0-041042	Damper block, LH	
42	9GQ0-041043	Damper block, RH	
43	9CR6-044061	Deco cover, backrest	
44	9CR6-101211	Hand guard, LH	
45	9CR6-101221	Hand guard, RH	
46	9CR6-044051	Left side cover, engine	

2

CFMOTO

REF NO.	PART NO.	NAME	PIC.
47	9CR6-044052	Cap,oil filter	
48	9CR6-044053	Deco cover, Recoil starter	
49	9CR6-140001	Cover,Rack	
50	9CR6-101001	Cover, dashboard	
51	9GQ1-043021	Bracket, left reflector	
52	9GQ1-0430212	Bracket, right reflector	

3 Periodic inspection and adjustment

3 Maintenance and adjustment

Maintenance information	3-1	3.7 Throttle.....	3-13
3.1 Maintenance interval.....	3-2	3.8 Cooling system	3-14
3.2 Maintenance procedures.....	3-3	3.9 Lights	3-16
3.3 Steering & Brake system.....	3-6	3.10 Shock absorber	3-17
3.4 Wheels	3-9		
3.5 Suspension system	3-11		
3.6 Gearshift, fuel system.....	3-12		

3

MAINTENANCE INFORMATION

Operation Cautions

WARNING

1. Engine exhaust contains poisonous carbon monoxide and can cause loss of consciousness resulting in severe injury or death. Never run an engine in an enclosed area
2. Don't perform the maintenance immediately after the engine stops, as the exhaust system and engine become very hot. Serious burns could result from the contact with the exhaust system or engine. Wear long-sleeved uniform and gloves to operate when necessary.
3. Gasoline is highly flammable, therefore smoke and fire are strictly forbidden in the work place. Special attention should also be paid to sparks. Gasoline may also be explosive when it is vaporized, so operation should be done in a well-ventilated place.
4. Don't get pinched by the drive system and other rotational parts.

ATTENTION

Always put the vehicle on level ground

CFMOTO

3.1 Maintenance Intervals

The maintenance of engine is a regular work. It is very important to have the periodic maintenance. Careful periodic maintenance will assure your vehicle having a good performance., reliability, economy and durability. Details of 191R engine are explained in periodic maintenance chart below.:

ATTENTION: Maintenance intervals in the following chart are based upon average riding conditions. Vehicles subjected to severe use must be inspected and serviced more frequently.

A: Adjust C: Clean I: Inspect L: Lubricate R: Repalce	10h or 300km				
	20h or 750km				
	Every 50h or 1500km				
	Every 100h or 3000km or 1 year				
	Every 200h or 6000km or 2 year				
Remark					
Engine					
Engine oil and filter		R		R	
Valve clearance adjustment		I, A		I, A	
Engine sealing	I			I	
Engine mounting	I			I	
Air filter		C	R		
Coolant		I	I		R
Radiator cap, cooling system pressure	I				I
Spark plug		I		I	R
Fuel system					
Throttle body	I			I, L	
CVT					
Belt			I	R	
Drive and driven pulley				I, C	
Clutch				I	

3 Periodic inspection and adjustment

3.2 MAINTENANCE PROCEDURE

○ : Maintenance interval

Task		Inspection item	Maintenance interval			Criteria
			Daily	Every 6 months	Yearly	
Steering system	Handle bar	Agility	○			
	Steering system	Damage	○			
		Installing condition	○			
		Free play of ball joint pin	○			
Brake system	Brake lever	Free play	○	○		
		Braking performance	○	○		
	Brake Lines & fittings	Looseness & damage	○		○	
	Brake Fluid & disc	FR&RR brake fluid level	○	○		Brake fluid should be between "Lower" and "Upper"
Brake disc & pads Wear & damage		○	○		If front brake disc thickness is less than 2.5mm or rear brake disc thickness is less than 4mm, replace the disc	
Running Device	Wheel	Tire pressure	○	○		Front : 56kPa (0.56kgf/cm ²) Rear : 42kPa (0.42kgf/cm ²)
		Crack & damage	○		○	
		Tread depth & abnormal wear	○		○	Tread depth should be more than 3.0mm.
		Looseness of wheel nuts & axle	○	○		
		FR wheel bearing free play	○		○	
		RR wheel bearing free play	○		○	
Suspension Device	A-arm	Free play & damage	○		○	
	Shock	Leaks & damage	○		○	
		Function			○	
Transmission Device	FR Diff	Drive & lubrication	○		○	
	RR Diff	Drive & lubrication	○		○	
	Gearcase/Diff	Leaks & oil level	○		○	Keep the oil level even with the bottom threads of fill plug hole.

3

CFMOTO

Check item		Check interval			Criteria	
Component	Item	Daily	Every 6 months	Annually		
Drive system	Drive axle	Connection looseness	○	○		
		Free play of splines			○	
Electricals	Ignition	Spark plug conditions		○	Spark plug clearance: 0.8mm~0.9mm	
		Ignition timing		○		
	Wiring	Battery	Connections of terminals		○	
		Wiring	Connections and looseness		○	
Fuel system	Fuel leakage			○		
	Throttle conditions				○	Throttle grip free play: 3mm~5mm
Cooling system	Coolant level		○	○		
	Leakage				○	

3 Periodic inspection and adjustment

Check item		Check interval			Criteria
Component	Item	Daily	Every 6 months	Annually	
Lighting and indicators	Function	○	○		
Alarming and locking system	Function			○	
Dashboard	Function			○	
Exhaust and muffler	Looseness and damage			○	
	Function			○	
Frame	Looseness and damage			○	
Others	Lubrication conditions in other frame components			○	
Components with recognizable abnormal damage in operation	Check if the suspect components are normal	○			


3

3.3 Steering column, braking system

Place the vehicle on a level surface. Hold the handlebar as illustrated in the figure. Check for the free play.

If a free play is found, determine whether the free play is from handlebar or other components and do repairs when necessary.

If handlebar has free play, tighten the steering column locking nut or remove the steering column to do further inspection and repairs.




Place the vehicle on a level surface. Turn the handlebar slowly and check for smoothness. If any binding is checked at any point, check the handlebar interference with main harness and cables. If the handlebar doesn't interfere with harness and cables, check the ends of steering rod for interference with other parts and to see the steering bearing is damaged.

CAUTION: Always check the steering smoothness. The vehicle may be out of control and result in accident with faulty steering.

Front brake lever free play:

Operate front brake lever. Check for brake performance and free play.



3 Periodic inspection and adjustment

Front brake master cylinder

〈Fluid level〉

Check the brake fluid level.

Check the leakage of master cylinder, brake line and connections for leakage when brake fluid level is at LOWER mark.

Remove the 2 brake fluid reservoir screws

2. Remove brake fluid reservoir cover.

Add DOT 3 or DOT 4 brake fluid to UPPER mark.

- No dust or water entrance when adding brake fluid.
- To avoid chemical changes, always use specified brake fluid.
- Do not splash brake fluid on plastics and rubber as it will damage them.
- Move the handlebar to left or right to keep the master cylinder lever prior to the reservoir cap removal

Brake disc, brake pads

〈Brake pads wear〉

Check the brake pads wear from the marked place. If the wear reaches the service limit, replace the brake pads.

NOTE




Always replace brake pads in a set.

Brake disc inspection and replacement
Check the brake disc sliding surface for wear and tear. When front brake disc thickness = 4mm, replace the brake disc.
Front brake disc thickness service limit:
4mm

BRAKE FLUID

〈Brake fluid change〉

Change the brake fluid every year



CFMOTO


Rear brake master cylinder

〈Fluid level〉

Check the rear brake fluid level

Check rear master cylinder, brake line and connections for leakage when rear brake fluid level reaches LOWER mark. Remove the rear brake reservoir cover 1. Add DOT3 or DOT 4 brake fluid to UPPER mark.

- No dust or water entrance when adding brake fluid.
- To avoid chemical changes, always use specified brake fluid.
- Do not splash brake fluid on plastics and rubber as it will damage them.



Brake disc, Brake pads

〈Brake pads wear〉

Inspect the wearing from looking at mark.
If the wear reaches the service limit,
replace the brake pads

NOTE

Always replace brake pads in a set.


Brake disc inspection and replacement
Check brake disc 3 sliding surface for wear
and damage. When the rear brake disc
thickness < 4mm, replace the brake disc.

Rear brake disc thickness service limit
: 4mm

Brake fluid

〈Brake fluid replacement〉

Replace brake fluid every year.



Rear brake disc

3 Maintenance and adjustment

3.4 Wheels

Lift the front part of the vehicle.

Ensure there is no any force exerted on the wheels. Push and pull front wheels to check if they are mounted firmly and without any play.

Check and tighten the bolts and nuts of swing arms, axles and rims

If the play remains, inspect and replace the bearing, swing arm bushings and ball end pin

Front wheel toe-in

Place the vehicle on a level surface and measure the front wheel toe-in.

The distance between the leading edges of the front wheels: A

The distance between the trailing edges of the front wheels: B



Toe-in: $B - A = 4\text{mm} \sim 10\text{mm}$

If the toe-in is out of specification, adjust the locking nut 2 of the steering rod 1.

CAUTION: Drive the vehicle slowly after toe-in is adjusted and ensure that the being can control the vehicle properly.



3




CFMOTO

Tire pressure

Check the tire pressure using a tire pressure gauge.

CAUTION: Measure tire pressure when the tire is cold. Maintain proper tire pressure. Improper inflation may affect ATV maneuverability, comfort, or uneven wear to different tires.



Tire pressure gauge


Specified tire pressure/tire

	Front tire	Rear tire
Pressure	56kPa (0.56kgf/cm ²)	42kPa (0.42kgf/cm ²)
Tire size	See chapter 1	See chapter 1

Tire tread

Check the tire tread. Replace the tire when tread depth is less than 2 mm.

NOTE: When tire tread depth is less than 3 mm, replace the tire immediately.



3 Periodic inspection and adjustment

Wheel nuts and axles

Check front axle, rear axle nuts 1 and lock pin for looseness. Tighten the axle nuts to specified torque when loose.

Torque:

Front axle nut: $320\text{N}\cdot\text{m}\sim 350\text{N}\cdot\text{m}$
($32.65\text{kgf}\cdot\text{m}\sim 35.7\text{kgf}\cdot\text{m}$)

Rear axle nut: $320\text{N}\cdot\text{m}\sim 350\text{N}\cdot\text{m}$
($32.65\text{kgf}\cdot\text{m}\sim 35.7\text{kgf}\cdot\text{m}$)



3

Wheel bearing play


Lift the front part of the vehicle. Ensure that there is no any force exerted on the front wheels. Push and pull the wheel in axle direction.

If any play is detected, remove the front wheel to check the wheel bearing.



3.5 Suspension system

Place the vehicle on a level surface. Press the vehicle in the illustrated direction as showing in the right figure for a few times. If there is play or abnormal noise, check the shocks for damping oil leakage and the connection




CFMOTO

Suspension adjustment

Using a tool, adjust the spring cam 1 to adjust the shock preload.

Turn the cam clockwise to lower the cam and turn the cam counterclockwise to lift the cam. This vehicle has a few shocks for customers' option.

This shock is the regular configuration. Refer to 3.10 for other shocks' adjustment. (→ 3.10)




3.6 Shift mechanism, fuel system

Shift mechanism

Shift to check the shift linkage 2 for smoothness and gear engagement. If shifting is not smooth, adjust the length of shift rod.

Loose the locking nut 1 and adjust the length of shift rod.



Fuel system

Fuel system conditions

Remove the seat (→ 2-3)

Check the fuel line for aging, damage. If fuel line is aged and damaged, replace the fuel line with new one. Check fuel tank breather hose or EVAP hose for cracks, kinking. If they are damaged, replace with new ones.

3 Periodic inspection and adjustment

3.7 Throttle inspection



1

Check the throttle lever 1 for free play

Free play: 3mm~5mm

If the free play is out of specification, adjust the free play.

Slide out the sleeve 3. Loosen the throttle cable locking nut 2. Turn the adjuster to adjust the throttle lever free play. Lock the locking nut 2 after adjustment. Slide back the sleeve 3. If the free play is still not within the specification or throttle cable is binding at some point, replace with new throttle cable.

Speed limiter

Speed limiter is designated to limit the opening of throttle valve. Check the speed limiter maximal threads length.

Threads maximal length: $a=12\text{mm}$

Adjustment procedure: Loosen the locking nut. Using a cross screw driver, adjust the length of the speed limiter screw.

NOTE: Speed limiter screw should be turned in all the way for beginners.


Only adjust the speed limiter when driving skills reach a certain level.

In addition, 12 mm is the maximal length of the speed limiter. Basically the speed limiter screw length is adjusted to be 3mm~5mm.



3

Free play 3mm~5mm



$a=12\text{mm}$



CFMOTO

3.8 Cooling system

CAUTION

- Check the coolant level in reservoir tank. If the radiator cap is removed when engine is hot (above 100 °C), the pressure in cooling system would decrease sharply. Therefore radiator cap must be removed when coolant temperature is down.
- Coolant is toxic. Don't drink nor spill on skin, eyes, clothing.
 - *If you spill coolant on your skin or clothing immediately wash it off with soap.
 - *If you get coolant in your eyes, immediately wash it off before medical attention.
 - *If you swallow coolant, immediately spit it out and gargle before medical attention.
- Coolant must be kept away from children.

Coolant level

Coolant would decrease due to evaporation, etc. Inspect coolant level periodically.


NOTE

- **Coolant is anti-rust and anti-freezing. Using tap water will rust the engine, and may crack the engine when it's freezing. Thus, Always using specified coolant is better.**
- **Position the vehicle on a level ground before cooling system inspection**
- **Start the engine and warm it up before inspecting the cooling system**

Start the engine and warm it up.

Shut off the engine.

Check the coolant level in reservoir tank. Ensure that the level is between LOWER and UPPER line.



3 Periodic inspection and adjustment

When coolant level is lower than the “LOWER” line, remove the reservoir tank cap and add coolant to” UPPER” line. (Fill pure water or cooling liquid)

Recommended Coolant: CFMOTO premixed coolant.

Mixture Ratio: 50% (The freezing temperature varies according to the mixture ratio. Adjust the mixture ratio according to freeze protection required in your area.)

When coolant is reduced significantly, check the cooling system for leaks. If no coolant remains in the reservoir tank, there may be air in the cooling system. Purge the cooling system of air.

Coolant Leakage

Inspect radiator, water pump, coolant hoses and connections for leaks.


If any leaks are found, repair the cooling system (→ 4. 4)

Check radiator hoses for aging, damages and cracks.

Hoses ages over time due to special working conditions and may crack. Bend a hose to check for cracks. If any damages or cracks are found, replace it with a new hose.

Check coolant hose clamps and tighten the loose ones.


Reservoir cap



3

Check radiator fins for mud or damages. Correct the fin bending. Use tap water or compressed air to clean off the mud.

The radiator should be replaced when more than 20% fins are damaged



CFMOTO

Checking the coolant temperature gauge

Coolant gauge indicator should point to 0 position when engine is not started. Coolant temperature varies after the engine is started. If the coolant temperature doesn't vary, a further inspection should be taken in time.




①

3.9 Lighting system

Headlight aiming

Remove the headlight cover (→ 2.6.3)
(Use left headlight as example) Using a cross screwdriver or wrench, adjust the headlight aiming up and down or left and right.




②

③

3 Periodic inspection and adjustment

3.10 Optional front shock absorber

View of the optional front shock



Spring preload adjustment cam Turn clockwise to increase and turn counterclockwise to decrease spring preload.

3

CFMOTO

Adjustment of optional front shock

Spring preload adjustment: Remove the inner hex bolt, Loosen the locking nut 1, Turn to adjust shock spring preload to requirement. Tighten the locking nut 1.


NOTE: The left and right shock absorber should have the same setting.



①

3 Periodic inspection and adjustment

View of optional rear shock



Spring preload adjustment
cam Turn clockwise to
increase and turn coun-
terclockwise to decrease
the preload.

3

CFMOTO

Adjustment of optional rear shock 2

Spring preload adjustment: Remove the inner hex bolt, Loosen the locking nut 1, Turn to adjust shock spring preload to requirement. Tighten the locking nut 1.

NOTE: The left and right shock absorber should have the same setting.



①

4 Engine Surroundings

Service information	4-1	4.3 Exhaust system	4-3
4.1 Fuel system	4-2	4.4 Cooling system.....	4-5
4.2 Intake system.....	4-2	4.5 Engine removal and installation	4-12

Service information

4

Operation cautions

- Ensure that the repair is carried out at least 1 hour later after the engine is shut off. To avoid burns to mechanics. repair it after hot parts cooling down.
- Do not damage frame, engine, bolts and wiring.
- To protect frame, wrap the frame before engine removal and installation.
- To protect environment, using a container to collect coolant, engine oil, fuel after engine is removed. Add coolant, engine oil as per the requirements when installing the engine.
- The following operations can be completed without engine removal from chassis
 - Oil pump
 - Thermostat, air- filter
 - Cylinder valve cover, cylinder head, cylinder, camshaft
 - CVT case cover, CVT system
 - Left engine cover, AC magneto, water pump
 - Piston, piston rings, piston pin
- The following operation should be carried out with engine removed from chassis
 - Crankshaft.

Tightening torque

Rear engine mounting bolts	GB5789 M12 × 1.25 × 170	(60~70)N • m
Front engine mounting bolts	GB5789 M12 × 1.25 × 180	(60~70)N • m
Engine bracket mounting bolts	GB5789 M10 × 20	(40~50)N • m

CFMOTO

4.1 Fuel system

Removal

WARNING:

Gasoline is very flammable. Smoking and firing is forbidden in the operation area.

Pay attention to not only open fire but also spark.

Since gasoline vapor is explosive, always perform the service in a well-ventilated area.

Remove the seat, fuel tank cover, dashboard cover, left side panel, right side panel (→ Chapter 2 Body and Panels)

Remove the bolt 1

Disconnect the fuel level connector 2, Fuel pump connector 3.




Move the fuel tank 4 aside

Remove the fast snap-on connector 5.

Remove the fuel tank 4.

Install

Reverse the removal procedures for Installation. Ensure that each connector is fully engaged, Fast snap-on connector clicks when it's engaged properly. Check each hose for integrity during installation




4.2 Intake system

Removal

Remove the seat (Chapter 2 Body and Panels)

Remove the 3 bolts 1.

Remove the air filter housing 2 (Air filter can be cleaned or replaced, refer to → 3.1 Maintenance Interval Determination for the frequency)



4 Engine surroundings

Remove the fuel tank (→ 4. 1fuel tank removal and installation)

Remove the clamp 3.


Remove the breather hose 4.

Loose the clamp 5.

Remove the air filter box.

Install

Reverse the removal procedures for installation.



Air filter housing

3

4


5

4

4. 3 Exhaust system

Removal


Remove the seat, fuel tank cover, dashboard cover, right side panel(Chapter 2 Body and Panels) Remove the 3 bolts 1. Remove the exhaust Pipe heat shield.




1

CFMOTO


Remove the 4 bolts 4.
Remove the exhaust head pipe bracket
Remove the exhaust pipe springs 5.



Remove the bolt 6.
Remove the silencer 7.




Disconnect the oxygen sensor connector 8.




Remove the head pipe nuts 9.
Remove the head pipe 10.

Install

Reverse the removal procedures for installation. Check the exhaust gasket for sealing function during installation process. Move the vehicle to a well ventilated area to run the engine for at least 0.5 hour to allow the anti-rust oil to evaporate completely.




4.4 Cooling system




Removal


Remove the seat, fuel tank cover, dashboard cover, left side panel, left headlight cover (→ Chapter 2 Body and Panels)
Disconnect the fan motor connector 1.



Remove the 2 bolts 2.
Loosen the clamp 3.
Remove the reservoir tank hose 4 from the radiator cap.
Loosen the clamp 5,
Remove the radiator inlet hose 6 from the radiator.




Remove the bolt 8.
Remove the reservoir tank 9
Loosen the clamp 10
Remove the radiator outlet hose 11 from the radiator.
Remove the radiator lower rubber grommets 7.
Remove the radiator 12 upwards



Install

Reverse the removal procedure for installation. Add coolant after installation if necessary.



4 Engine surroundings

Overview

WARNING

Do not start the engine without coolant. Otherwise the cooling system parts may be damaged.

Use the torque and service materials as per the exploded view.

Inspection

Cooling system leak test

WARNING


To avoid potential burns, don't remove the Radiator cap or loosen the cooling drain plug if the engine is hot.



4

Remove the front rack, rack cover and radiator cap. Install the cooling system leak test cap (901-18.01.00-922-001). Use a pressure/vacuum pump to pressurize system to 103kPa (15 PSI).

Note: Inspection and replacement of cooling parts in the engine can be referred to the chapter in engine cooling system (→ 5.2.9 cooling system inspection).



View

1、Cooling system leak test cap

CFMOTO

Inspection

Check general condition of hoses and clamps tightness

Check the leak indicator hole if there is oil or coolant.

NOTE:Leaking coolant indicates a defective rotary seal. Leaking oil indicates a defective inner oil seal. If either seal is leaking, both seals must be replaced at the same time. Refer to WATER PUMP SHAFT AND SEALS in this section.

Maintenance

Coolant replacement

WARNING

To avoid potential burns, don't remove the radiator cap or loosen the cooling drain plug if the engine is hot.

Use CFMOTO premixed coolant or a blend of 50% antifreeze with 50% water. To avoid antifreeze deterioration, always use the same brand. Never mix different brands unless cooling system is completely flushed and refilled.


CAUTION: To prevent rust formation or freezing condition, always fill the system with the CFMOTO premixed coolant or with 50% antifreeze and 50% water. Don't use tap water, straight antifreeze or straight water in the system. Tap water contains minerals and impurities which build up in the system. During cold weather, straight water causes the system to freeze while straight antifreeze thickens and does not have the same efficiency. Always use ethylene glycol antifreeze containing corrosion inhibitors specifically recommended for aluminum engines.

Draining the system


WARNING

Never drain or fill the cooling system when engine is hot.

Remove the radiator cap. Partially unscrew cooling drain plug located below water pump housing. When cooling system is drained completely, remove coolant drain plug and install a new washer. Screw in the coolant drain plug and torque it to 10 N·m (89 lbf • in)。



1. Leak indicator hole



Beside the LH foot rest

1. Coolant drain plug

4 Engine surroundings

Refilling the System

Remove related parts. Unscrew the bleeding screw on top of thermostat housing. With vehicle on a level surface, engine cold, refill radiator. When the coolant comes out by the thermostat housing hole, install the bleeding screw with its washer and torque to **5 N·m (44 lbf·in)**.

Fill up the radiator and install radiator cap. Fill the reservoir tank and keep the coolant level even at **LOWER** mark, then install reservoir tank cap. Run the engine until thermostat opens, then shut off the engine. Recheck the coolant level in reservoir tank after the engine is completely cooled down. Refill coolant if necessary. Maintain coolant level between "LOWER" and "UPPER".

NOTE: Each year or every 100 hours or when vehicle reaches 3000km(1865mi), check coolant concentration (freezing point) with proper tester.

Cooling system External parts

RADIATOR CAP


Using a pressure test cap to check the radiator cap working pressure. If the radiator cap working pressure is low, replace it with a new radiator cap with specified working pressure 110 kPa (16PSI) (Do not over pressure).

Radiator



Check the radiator fins for obstruction or damage.

- Using compressed air or low pressure water, clean up the insects, mud or other obstruction.

- Using a small screw driver, correct the radiator fins if bending.




1. Leaking screw
2. Seal gasket



CFMOTO

Fan motor inspection


Troubleshoot the fan failure as per the right figure.



Fan relay

Fan relay install

NOTE: Relay may be inverted by 180 at Installation and it will work correctly. Ensure to align tabs of relay with terminals of fuse holder at installation.




Fan relay

4 Engine surroundings

Relay operation test

The easiest way to check the relay is to remove it and bypass it with a jumper. If the radiator fan is activated, replace the relay. See illustration to find where to bypass the relay.



1: Bypass the Relay

4

Relay Continuity Test

Remove relay.

Use multimeter and select the position Ω .

Probe relay as follows

Terminals		Resistance
30	87	Open circuit (OL)



probe relay

4.5 Engine removal and installation

Remove the seat, fuel tank cover, dashboard cover, left side panel, right side panel, left foot rest, right foot rest (→ chapter 2, body panels)

Remove fuel tank (→ 4.1 fuel system removal and installation)

Remove air filter housing (→ 4.2 intake system removal and installation)

Remove muffler (→ 4.3 exhaust system removal and installation)

Disconnect the oil pressure sensor connector 1

Disconnect the coolant temperature sensor connector 2.


Remove the throttle cable 3.

Loose the clamp 4 and disconnect the coolant hose from the engine.


Loose injector connector 5

Disconnect the intake air temperature/pressure sensor connector 6.

Remove throttle body 7.




Remove engine oil filler panel 1.




Remove the bolts 2.

Remove the engine left panel 3.




Remove the bolt 4.

Disconnect the shift arm 5 from the engine.




4 Engine surroundings

Remove the starting motor cable 1.
 Remove the bond strap 2.
 Remove the TPS sensor connector 3.
 Remove the idle Ignition Coil valve connector 4.
 Remove the speed sensor connector/
 magneto connector/gear
 position sensor connector/ignition
 signal transducer 5.
 Remove the ignition coil cap 6.




4

Loose the clamp 1.
 Remove the intake duct from
 engine



Loose the clamp 3.
 Remove the outlet duct 4 from
 engine.




Loose the coolant hose clamp 5
 Remove coolant hose 6 from
 engine.

Remove inner hex screw 7.
 Remove the front drive shaft
 8 from engine.
 Remove rear drive shaft 9
 (→ 6.7 Drive shaft removal)
 Remove the engine mounting
 bolts 10.

Remove the engine.

Install

Reverse the removal procedures
 for Installation.



CFMOTO

Contents

5.1 Maintenance information.....	1-16
5.2 Inspect and adjustment.....	18-27
5.3 Engine remove, inspection and assemble.....	29-89
5.4 Cooling and lubrication system.....	90-103
5.5 Electrical parts.....	104-131
5.6 Trouble shooting.....	132-155

5.1 Maintenance information

General precautions.....	5-2
Fuel, engine oil and coolant introduction.....	5-3
Engine running-in.....	5-3
Engine shape & location of ein.....	5-4
Engine general information.....	5-5
Maintenance specifications.....	5-8
Tightening torque.....	5-12
Service tool.....	5-14
Engine operation materials and service products.....	5-19

General precautions

Warning : Proper service and repair procedures are important for the safety of the service mechanic and the safety and reliability of the

- When two or more persons working together, pay attention to the safety of each other.
- When it is necessary to run the engine indoors, make sure that exhaust gas is forced out doors.
- When working with toxic or flammable materials, make sure that the area you work in is well ventilated and that you follow all of the manufacturer's instruction.
- Never use gasoline as a cleaning solvent.
- To avoid getting burned, do not touch the engine, engine oil, radiator, and exhaust system until they have cooled.
- After servicing the fuel, oil, engine coolant, exhaust or brake system, check all of the lines, and fittings related to the system for leaks.
- In order to protect the environment, do not unlawfully dispose of motor oil, engine coolant or parts no longer used.

Warning:


- If parts replacement is necessary, replace the parts with CFMOTO genuine parts or their equivalent.
- When removing parts that are to be reused, keep them arranged in an orderly manner so that they may be reinstalled in the proper order.
- Be sure to use special tools when instructed.
- Make sure that all parts used in reassembly are clean. Lubricate them when specified.
- Use the specified lubricate, bonds, or sealants.
- When tightening bolts, screws and nuts, tighten the larger sizes first. Always tighten the nuts and bolts from the inside working out, diagonally and to the specified torque.
- Use a torque wrench to tighten fasteners to the specified torque. Wipe off grease and oil if a thread is smeared with them.
- After removing the parts, need to double check them, cleaning all the parts before measure.
- After reassembling, check parts for tightness and proper operation.
- Never reuse a oil seal, O-ring, gasket, self-locking nut, locking washer, cotter pin, snap ring, and other specified parts, be sure to remove them with new ones.

5.1 Maintenance information

FUEL, OIL AND ENGINE COOLANT RECOMMENDATION

FUEL: Use unleaded gasoline that is Graded 93 octane or higher.

ENGINE OIL: Use 4-stroke motor oil, The oil need to meet API service Classification SG. If engine oil with a SAE 15W-40 is not available, choose from the right chart according to the environmental temperature.



ENGINE COOLANT: Since antifreeze also has corrosion and rust-inhibiting properties, engine coolant contains antifreeze, and the freezing point should be below the atmospheric temperature like 5°C.

Recommended coolant type: -30°C anti-frozen, antiseptic, high-boil coolant.

Danger: Keep the engine coolant properly and do not drink it as it is poisonous

Warning: Do not mix other brand engine coolant together.

Engine running-in

As the engine has a lot of relative motion parts, such as pistons, piston rings, cylinder blocks and inter-meshing gears, thus, good operation at the beginning is necessary. It helps a good adaptation to each part, adjust working gap, and make a smooth friction surface to bear heavy load.

Recommended running-in time: 20 hours, see detailed specification below:

0~10 hours


Avoid continuous operation above half-throttle or vary the speed of the vehicle from time to time. Do not operate it at one set throttle position. Allow a cooling-off period of 5 to 10 minutes after every hour of operation. Avoid acceleration heavily. The accelerator should be changed smoothly, avoid changing heavily from small to bigger

(10~20) hours


Avoid prolonged operation above three-quarter throttle. Allow using freely but not full throttle.

CAUTION: Maintain and repair as regular procedures during break-in period; After break-in, do not forget to check and maintain the engine before normal use.

ENGINE SHAPE & LOCATION OF EIN



Engine left side



Engine Right side

5.1 Maintenance Information

ENGINE GENERAL INFORMATION

NO.	ITEM		TYPE/SPECIFICATION	
1	Type		Single-cylinder, liquid-cooled, 4-stroke, SOHC4	
2	Bore×Stroke		91mm×76.2mm	
3	Displacement		495mL	
4	Compression ratio		10.3:1	
5	Low idling speed(Idle)		1500r/min±150r/min	
6	Starting		Electric	
7	Electric system	ignition type/ ignition timing	ECU / BTDC10° 1500r/min	
		Spark plug/ Electrode gap	DCPR8E-NGK/0.8mm~0.9mm	
		Magneto type/ Power	3-phase AC generator, 320W/5000r/min, 460W/5000r/min	
8	Combustion system	Combustion chamber	Triangular combustion chamber	
		Throttle body type	0GQ0-173000-20000	
		Air filter type	Sponge, Paper filter	
		Gasoline	RQ-92	
9	Valves system	Valves type	SOHC/ Timing chain drive	
10	Lubrication System	Lubrication type	Pressure and splash	
		Oil pump type	Rotor drive	
		Oil filter type	Paper type, replaceable	
		Engine oil type	SAE15W-40/SG or higher	
11	Cooling system	Cooling type	Liquid-cooled/close-loop cooling	
		Coolant type	-30°C anti-corrosion and anti-freezing	
12	Drive train system	Transmission type	CVT+ Gearshift	
		Reducer gear	Two forward gear, one reverse gear, one park	
		Gearshift methods/orders	Manual operation/L-H-N-R-P	
		CVT ratio range	3.021~0.675	
		Gearshift ratio	Final ratio	1.333 (24/18)
			Secondary	1.952(41/21)
Variable gear	L:2.53(38/15); H: 1.35(27/20) ; R:2.071(29/14)			
Total ratio	L:6.595; H: 3.514 ; R:5.392			
13	Overall size		L(mm)×W(mm)×H(mm): 616×528×509	
14	Dry weight		60.5kg	
15	Output type		Front/Rear shaft drive	
16	Rotation of engine output		When forward, clockwise(rear view)	

Valves & Cylinder Head

(mm)

Item	Standard value		Service limit	Remarks
Dia. Of valve neck	Intake valve	φ 33	—	
	Exhaust valve	φ 29	—	
Thickness of valve neck	Intake/Exhaust	1	0.5	
Valve clearance(cold engine)	Intake	0.08~0.12	—	
	Exhaust	0.12~0.18	—	
Inner dia. Of valve guide	Intake/Exhaust	5.000~5.012	5.045	
Outer dia. of valve stem	Intake	4.965~4.980	4.93	
	Exhaust	4.955~4.970	4.93	
Gap between valve guide and stem	Intake	0.020~0.047		
	Exhaust	0.030~0.057		
Valve stem roundness (diameter difference)		0.005	0.06	
Valve end run-out	Intake/Exhaust	0.02	0.05	
Valve length	Intake	90.1		
	Exhaust	88.7		
valve plate cone run-out	Intake/Exhaust	0.03	0.05	
Width of valve seat seal	Intake	1.2±0.1	1.7	
	Exhaust	1.3±0.1	1.8	
Valve spring free length	Intake/Exhaust	40	38.2	
Elasticity of valve spring	Intake/Exhaust	33: 200N~235N 23: 530N~587N		
Cam length	Intake	32.971~33.011	32.871	
	Exhaust	32.985~33.025	32.865	
Camshaft shaft neck	φ 35	34.959~34.975	34.95	
	φ 22	21.959~21.980	21.95	
Gap between outer dia. of camshaft and holes	φ 35	35.007~35.025	35.04	
	φ 22	22.012~22.025	22.04	
Gap between outer dia. of camshaft and holes	φ 35	0.032~0.066	0.09	
	φ 22	0.032~0.066	0.09	
Axial clearance of	0.12~0.28			
Camshaft run-out			0.10	
Bore diameter of rocker	Intake/Exhau	12.000~12.018	12.03	
Dia. of rockshaft	Intake/Exhau	11.973~11.984	11.96	
Fit gap between	Intake/Exhau	0.016~0.045	0.07	
Axial gap between	Intake/Exhau	0.06~0.34		
Flatness of cylinder head bottom surface	0.03		0.05	
Flatness of cylinder head cover combination	0.08		0.10	

5. 1 Maintenance information


Cylinder, Piston, Piston Ring & Crankshaft			(mm)	
Item	Standards		Service limit	Remarks
Cylinder compression	1000kPa		—	
Piston/Cylinder clearance	0.030~0.050		0.10	
Dia. of Piston	90.95mm~90.979 mm down along to the piston		90.85	
Inner diameter of cylinder	90.99~91.01		—	
Flatness of cylinder top and bottom surface	0.03		0.05	
Free open of piston ring	1 st ring	R round 11.7	8.9	
	2 nd ring	R round 12	9.5	
Gap of piston ring	1 st ring	0.25~0.40	1.5	
	2 nd ring	0.35~0.45	1.5	
	Oil ring	0.2~0.7	1.5	
Height of piston ring	1 st ring	0.02~0.06	0.150	
	2 nd ring	0.02~0.06	0.150	
	Oil ring	0.03~0.15	0.250	
Height of piston ring	1 st ring	1.17~1.19	—	
	2 nd ring	1.47~1.49	—	
	Oil ring	2.37~2.47		
Width of piston ring	1 st ring	1.21~1.23	—	
	2 nd ring	1.51~1.53	—	
	Oil ring	2.50~2.52	—	
Inner diameter of piston pin hole	22.004~22.010			
Diameter of piston pin	21.995~22.000		21.980	
Inner diameter of small end of connecting rod	22.01~22.02		22.06	
Gap of piston/piston pin	0.004~0.015		0.08	
Small end hole of connecting rod / gap of piston pin	0.010~0.025		0.08	
Side gap of big end of connecting rod	0.1~0.45		0.7	
Thickness of big end of connecting rod	22.95~23.00			

To Be Continue (mm)

Item	Standards	Service limit	Remarks
Thickness of big end of connecting rod	22.95~23.00		
Crankshaft beat	0~025	0.055	
Connecting rod bearing journal	36.992~36.996	36.068	
Connecting rod bearing bore	37.006~37.028	37.06	
Gap of connecting rod bearing	0.01~0.032	0.065	
Main journal	41.955~41.970	41.935	
Case main bearing bore	41.980~42.000	42.10	
Gap of main bearing	0.045~0.01	0.08	
Gap of crankshaft axial direction	0.05~0.45	0.6	

MAINTENANCE SPECIFICATIONS

Lubrication System

Item		Standards	Service Limit
Engine Oil Capacity	Oil Change	2800mL (without oil filter replacement)	—
	Oil Change	2900mL(with oil filter replacement)	
	Oil Capacity	3000mL	—
Recommended engine oil (see original) Grade/ TEMP		<p>·Special for four stroke motorcycle SAE-15 W-40 If it's not available, select alternative according to the following specifications.</p> <p>·API classifications: SG or higher</p> <p>·SAE classifications: according to the left chart</p>	
			
Oil Pump Rotor	Clearance Between Inner and Outer Rotor	0.07mm ~ 0.15mm	0.2mm
	Clearance Between Outer Rotor and Case	0.03mm ~0.10mm	0.12mm
	Oil Pump Rotor End Clearance	0.023mm~ 0.055 mm	0.12 mm
	Engine oil pressure	1500r/min , 90°C , 200 kPa ~ 400kPa, general 240 kPa 6000r/min , 90°C , 600 kPa ~ 700kPa, general 600 kPa	

5. 1 Maintenance information

COOLING SYSTEM

Item		Standards		Service Limit
Thermostat	Opening temperature	65°C±2°C		
	Fully opening	85°C		
	Travel when fully opening	When 85°C, ≥5mm		
Radiator cap opening pressure		110 kPa±15kPa(1.1kgf/cm ²)		
Relations between water temp. and resistant of water temp. sensor	Water temperature (°C)	Resistant of B terminal(Ω)	Resistant of A,C Terminal(kΩ)	
	-20	—	13.71~16.94	
	25	—	1.825~2.155	
	50	176~280	—	
	80	63.4~81.4	0.303~0.326	
	110	24.6~30.6	0.138~0.145	
Working temp. of thermo switch	OFF-ON	Around 88°C		
	ON-OFF	Around 82°C		
Coolant type		-30°C anti-freezing, anti-corrosive and high boiling point		

5

CFMOTO

Clutch + Transmission mechanism

(mm)

Item	Standards	Service limit	Remarks
Belt width	35.2	33.5	
Free length of driven pulley spring	238.5	214	
Hole dia. of driven pulley collar	38.10~38.14	38.30	
Clearance between gearshift fork and engagement groove	0.10~0.35	0.45	
Thickness of gearshift fork	5.8~5.9	5.7	
Groove width of high/low sliding	6.05~6.15	6.25	
Output gear groove width of driven shaft	6.05~6.15	6.25	
Groove width of gearshift drum	8.05~8.10		
Dia. of gearshift pawl pin	7.90~7.95	7.83	
Hole dia. of gear box	25~25.021	25.025	
Hole dia. of Reverse gear transition	25~25.021	25.025	
Dia. of main shaft	φ 30	28.980~29.993	29.970
	φ 17	16.983~16.994	16.978
Dia. of secondary shaft	φ 15	14.983~14.994	14.978
	φ 17	16.983~16.994	16.978
	φ 20	19.980~19.993	19.974
Dia. of drive bevel gear shaft	φ 17	16.983~16.994	16.978
	φ 25	24.980~24.993	24.974
Dia. of reverse intermediate gear	φ 20	19.980~19.993	

Air Intake System

Item	Standards
Throttle Body Part NO.	0GQ0-173000-20000
T-MAP Sensor Part No.	0JY0-175000
Fuel Injector Part No.	0GR0-171000
Idle Speed	1500 r / min±150r / min

5.1 Maintenance information

Electric system

Item		Standards	Remarks
Spark plug	Type	DCPR8E(NGK)	
	Gap of spark plug	0.8 mm ~ 0.9mm	
Characteristic		> 8mm, under 0.1MPa	
Resistance of ignition coil	Primary	0.74Ω ~ 0.78Ω	
	Secondly	10.1k Ω ~ 11.1kΩ	
Resistance of magneto coil		0.5Ω ~ 1.5Ω	
Resistance of speed sensor (trigger)		900Ω ~ 1000Ω	
Voltage without load(cold engine)		> 50V(AC), 5000r/min	
Max. output power of magneto		320W, 5000r/min 460W/5000 r/min	
Stable voltage		13.5V ~ 15V	
Secondly voltage of ignition coil		≥ 25kV	
Peak voltage of Trigger coil		Peak voltage ≥ 3V, 200r/min	
Resistance of starter relay coil		3Ω ~ 5Ω	
Resistance of auxiliary relay coil		90Ω ~ 100Ω	

5

CFMOTO

Engine tightening Torque list

Item	Qty	Dia. Of thread(mm)	Torque (N·m)	Remarks
Oil drain bolt M12×1.5	1	M12×1.5	25	
Bolt M14×1.5×12(left case)	2	M14×1.5	28	
Link bolt M14×1.5(left case)	2	M14×1.5	28	External oil tube
Plug screw, oil passage pressing plate (left case)	4	M6×12	8	Thread locker glue
Primary screen cover bolt	3	M6×20	8	Thread locker glue
Oil pressure switch	1	M10×1	12	Thread locker glue
Screw R21/8(CVT oil passage)	1	R21/8	20	Apply seal gum
Bolt, CVT air intake plate	3	M6×12	8	Thread locker glue
CVT cover screw	8	M6	7	
Plug screw, relief valve(left crankcase cover)	1	M20×1.5	30	
Bolt of wiring damper (left crankcase cover)	1	M6×10	8	Thread locker glue
Screw of oil seal plate((left crankcase cover)	3	M6×8	8	
Adjust nut, valve clearance	8	M6	12	
Bolt, timing sprocket	2	M6×10	15	
Bolt, decompressor, starter	1	M8×32	30	
Bolt, cylinder	4	M10	20、60	
Bolt, cylinder installation	2	M6×132/120	10	
Plug, spark	1	M12×1.25	20	
Sensor, water TEMP.	1	M12×1.5	16	
Tud bolt M8×42 (exhaust port)	2	M8×42	25	Thread locker glue
Nut, thrust M8 (exhaust port)	2	M8	13	
Plug, Screw M12×1.5	1	M12×1.5	20	
Tapping screw ST4.8×13(thermostat cap)	1	ST5.5×13	5	
Bolt M6×45(thermostat cap)	2	M6×45	6	
Injector seat installation bolt	2	M8×25	20	

5. 1 Maintenance information

To be continued

Item	Qty	Dia. Of thread(mm)	Torque (N·m)	Remarks
Bolt COMP. Cylinder head cover	4	M6	7	
Thread tension plate pin	1	M8	20	Thread locker glue
Bolt, magneto stator	3	M6×30	10	Thread locker glue
Bolt, overriding clutch COMP	6	M8×20	26	Thread locker glue
Bolt M10×1.25×40(Magneto rotor)	1	M10×1.25	55	Thread locker glue
Bolt, drive pulley(CVT drive pulley)	1	M12×1.5-LH	40	
Screw, gear shifting shaft (CVT driven pulley)	1	M20×1.5	115	Thread locker glue
Lock nut, drive bevel gear	1	M22×1	145	
Bolt(bearing seat, drive bevel gear)	4	M8×28	32	
Screw (bearing holder, drive bevel gear)	4	M8×25	15	
Stopper nut (driven bevel gear)	1	M65×1.5	110	Thread locker glue
Bolt(bearing seat, driven bevel gear)	4	M8×28	25	
Retainer, bearing (left)	1	M55×1.5	80	Thread locker glue
Bolt front/rear output M10×1.25×20	2	M10×1.25	55	Thread locker glue
Set screw, shift drum T25	1	M5×8	6	
Bolt, gear orientation	1	M14×1.5	18	
Bolt, oil pump cover	3	M5×16	7	Thread locker glue
Bolt, oil guard	2	M6×12	8	Thread locker glue

5

CFMOTO

191Q Engine Service Tools

Measuring instruments				
Item	Tool name	Specifications	Purposes	Remarks
1	Vernier caliper	0~150mm	Measure length and thickness	
2	Micrometer	0~25mm	Measure outer diameter of rocker arm shaft, valve stem, camshaft	
3	Dial gauge	25mm~50mm	Measure Max. travel of camshaft	
4	Dial gauge	75mm~100mm	Measure size of piston skirt	
5	Inner dia. of cylinder meter		Measure dia. of cylinder	
6	Inside caliper micrometer	10mm~34mm	Measure inner diameter of rocker and piston pin hole, connecting rod hole	
7	Dial indicator	1/100	Measure jump	
8	Knife straight edge		Measure flatness	
9	Feeler gauge		Measure flatness and adjust valve clearance	
10	Plastigauge		Measure fit clearance	
11	Spring balance		Measure elasticity of spring	
12	RPM meter		Measure RPM	
13	Compression tester and adapter		Measure cylinder compression	
14	Oil pressure meter		Measure oil pressure	
15	Air pressure meter		Measure opening pressure of radiator cover	
16	Ohmmeter		Measure resistance and voltage	
17	Amperometer		Measure current of switch	
18	Thermometer		Measure coolant temp	
19	Timing light		Measure ignition timing	
20	Torque wrench	One set	Measure tightening torque	

5. 1 Maintenance information

Generally & Auxiliary tools				
Item	Tool name	Specifications	Purposes	Remarks
21	Alcohol light		Warm up or increase temp.	
22	Magnetic meter seat		Mounting dial indicator	
23	Plate		Auxiliary measurement	
24	V-shaped bluff		Auxiliary measurement for jump	
25	Nipper		Mounting valve lock-clip	
26	Circlip plier		Circlip removal and installation	
27	Nipper plier		Stop collar removal and installation	
28	Impact driver		Disassembly of crosshead bolt	
29	Screw driver			
30	Plus driver			

5

CFMOTO

Engine Special Tools

Tool name	Part number	Purposes
Joint, oil hose	0800-000000-871-001	Measure oil pressure
Press tool, bearing of left crankcase	OGR0-012101-921-001	Press bearing
Punch, reverse transition gear shaft	OGR0-011103-921-001	reverse transition gear shaft
Oil pump duplex gear shaft installation	OGR0-011102-921-002	Oil pump duplex gear shaft installation
Punch, Oil pump duplex gear shaft	OGR0-011102-921-001	
Remover, magneto rotor	0180-031000-922-001	Remove magneto rotor
Press tool, bearing of left crankcase	OGR0-011101-921-001	Press bearing
Press tool, cover of left crankcase	OGR0-014001-921-001	Press bearing, water seal
Gauge, circumferential position of crankshaft balance gear		Inspection circumferential position of crankshaft balance gear
Press tool, right crankcase bearing bush	0800-012101-921-002	Pressing bearing bush
Press tool, oil seal	0180-012004-921-001-1	Install oil seal
30×45×7 Installer, oil seal	CF188-012006-923-001	Install oil seal
Installer, Driven bevel gear, bearing seat	0800-062202-921-002	Pressing bearing
Press tool, Driven bevel gear, bearing seat	0800-062202-921-001	Pressing bearing
Installer, Driven bevel gear, bearing seat	0800-062202-922-001	Install/Remove the retainer of ring gear bearing
Bearing Retainer Remover	0800-062206-922-001	
Installer, driven bevel gear bearing (6207C3)	CF188-062201-921-003	Pressing rolling bearing 6207c3
Press tool, left crankcase bearing bush	0800-011101-921-002	Pressing bearing bush
Installer	CF188-062103-921-001	Pressing bearing 6305C3
Press tool, bearing	CF188-062103-921-002	Pressing bearing
Installer, bearing front output shaft 6205	CF188-062301-921-001	Pressing bearing 6205
Air leak tester, cylinder cover	0800-022101-922-001	

5.1 Maintenance information

Tool name	Part number	Purposes
Bearing RNA49/22 presser		Install bearing RNA49/22
Press tool, left crankcase cover, hole bearing	CF188-014001-921-001	Pressing bearing 60/28
Press tool, oil seal	CF188-014008-921-001	Pressing oil seal 28×52×7
Press tool, oil seal of water pump	172MM-080005-923-001	Pressing oil seal 10×20×5
Press tool, left crankcase cover, water seal	152MI-081004-921-001	Pressing water seal
Press tool, water pump bearing 6000	1P72MM-081001-923-001	Pressing bearing 6000/P6
Installer, pump shaft	CF188-081001-922-001	Install water pump shaft
Press tool		Install oil seal ring
Press tool, CVT case earing bush	0JY0-013101-921-001	Pressing bearing bush
Installer, washer, rubber		Install washer
Installer, nut	CF188-062000-922-001	Lock gear shaft nut
Installer, driven bevel gear	CF188-062200-922-001	Remove driven bevel gear
Wrench, front output shaft oil seal ring	CF188-060008-922-001	Remove/install front output shaft oil seal ring
Press tool, front output shaft oil seal	0800-060000-923-001	Install oil seal 35×61×9(14)
Press tool, driven bevel gear oil seal	0800-062204-923-001	Install oil seal 35×50×7
Wrench, shift gears	CF188-064005-922-001	Inspection shift gears
Press tool, oil seal 32×55×10	0JY0-013103-921-001	Install oil seal 32×55×10
Wrench, adjust nut, valve	1P39MB-022102-922-001	Adjust valve clearance
Spark plug spacer	0800-022800-922-001	Remove/assemble spark plug
Installer, drive pulley	0JY0-050000-922-001	Setting torsion of drive pulley nut
Driven Pulley Expander	0800-052000-922-003	Expand the driven pulley to ease belt installation
Radiator cover test cap	901-18.01.00-922-001	Measure cooling system
Puller, water seal	0800-014001-922-002	Remove water seal
Puller, bearing	0800-014001-922-001	Remove bearing
Piston ring compressor	0800-040003-922-001	compress ring when assemble piston
Installer, circlip, piston pin	0800-040005-922-001	Install piston pin
Drive pulley disassembling tool	0JY0-050000-922-002	Remove drive pulley

Tool name	Part number	Purposes
Press tool, front output shaft oil seal	0800-060000-923-001	Install oil seal 35×61×9(14)
Press tool, driven bevel gear oil seal	0800-062204-923-001	Install oil seal 35×50×7
Wrench, shift gears	CF188-064005-922-001	Inspection shift gears
Press toll, oil seal 32×55×10	0JY0-013103-921-001	Install oil seal 32×55×10
Wrench, adjust nut, valve	1P39MB-022102-922-001	Adjust valve clearance
Spark plug spacer	0800-022800-922-001	Remove/assemble spark plug
Installer, drive pulley	0JY0-050000-922-001	Setting torsion of drive pulley nu
Driven Pulley Expander	0800-052000-922-003	Expand the driven pulley to ease belt installation
Radiator cover test cap	901-18.01.00-922-001	Measure cooling system
Puller, water seal	0800-014001-922-002	Remove water seal
Puller, bearing	0800-014001-922-001	Remove bearing
Piston ring compressor	0800-040003-922-001	compress ring when assemble piston
Installer, circlip, piston pin	0800-040005-922-001	Install piston pin
Drive pulley disassembling tool	0JY0-050000-922-002	Remove drive pulley

5. 1 Maintenance information

Engine operation materials and service products

Engine operation materials including lubricant(engine oil), grease, and coolant. Service products contain silicone, sealant and silicone sealant.

Item	Type	Lubrication points	Remarks
Lubricants (engine oil)	4-stroke motor oil SAE15W-40 Or SAE10W-40 API : SF, SG or higher	Cylinder rotating parts, sliding parts Inner crankcase rotating parts,sliding parts Cylinder head rotating parts, sliding parts Details see lubricants sketch map (Details of choosing brand of viscosity see page 5.1.2)	Capacity 2800mL (replace engine oil) 2900 mL (replace filter) 3000 mL (engine overhaul)
Molybdenum Disulfide grease		Piston pin, valve stem, valve oil seal, camshaft	
Grease	No.3MoS2 grease	Oil seal, O-ring and other rubber seals. Sealed bearing,	
Coolant	-30°C Anti-freezing, anti- corrosive, high-boiling coolant	Engine cooling system, water seal installation	Coolant capacity depends on radiator pipes
Silicone sealant		Crankcase splitting surfaces, contact surface between crankcase and cylinder,	
Thread locker		Some threads	see 5-11,5-12

5.2 Inspection and adjustment

Maintanance period.....	5-21
Maintanance adjustment step.....	5-22
Valve clearance.....	5-22
Engine idle speed.....	5-23
Spark plug.....	5-23
Air filter.....	5-24
Drive belt.....	5-25
Lubrication system instpetion.....	5-27
Cooling system inspection.....	5-29
Cylinder pressure.....	5-30

Inspecting information

Pre-caution

- The exhausted gas some poison elements like CO. Do not running the engine in bad vantilation area for too long time.
- The engine is still high heat when it just stopped. It will cause burnt when skin touched. If needs repair the engine when just stopped. You must wear long sleeve clothes with gloves on.
- Fuel is highly flammable. So no smoking and fire in working place. Not only fire. But also the spark. Evaporated fuel can cause explosive. So please do the repairing work in well vantilated area.
- Do not let the moving parts pinch on clothes or hand.
- Set the removed engine on flat stable area.

5.2 Inspection and adjustment

Period maintenance table

Engine maintenance is a periodic job, careful periodic maintenance is very important, will assure your vehicle having a good performance, reliability, economy and durability. Details are explained in below 191R engine periodic maintenance chart.

ATTENTION: Maintenance intervals in the following chart are based upon average riding conditions. Vehicles subjected to severe use must be inspected and serviced more frequently

A: Adjust C: clean I: Inspect L: Lubricate R: Replace		10 hours or 300km					Remark	
		20 hours or 750km						
		Every 50 hours or 1500km						
		Every 100 hours or 3000km or 1 year						
		Every 200 hours or 6000km or 2years						
Engine	Facilitating Conditions&abnormal sound	I		I	I			
	Exhaust condition		I	I	I		No black smoke or blue smoke	
	Valve setting		I, A		I, A		In: 0.08mm~0.12mm Out: 0.12mm~0.18mm	
	Idle speed	I		I			1400 r/min±100r/min	
SparkPlug			I		I	R	No carbon deposition ,electrode gap: 0.8mm~0.9mm	
Air Filter			C	R				
CVT system	CVT Belt			I	R		Replace every 2000km	
	Primary Pulley, Driven pulley				I, C			
Engine oil, filter			R		R			
Throttle Body		I			I, L			
Cooling System	Water volume	I		I				
	Water pipe	I			I			
	Radiator valve opening pressure	I		I	I		0.75 kg/cm ² ~1.05kg/cm ²	
	Replace coolant	Replace every 2 years						

Maintenance & Adjustment

This section describes the maintenance procedures for each item mentioned in the periodic maintenance chart.

Valve clearance

Inspect initially at 20-hour break-in and every 40 hours or every 1000km thereafter. Inspect the clearance after removing cylinder head

Excessive valve clearance results in valve noise and insufficient valve clearance results in valve damage and reduced power.

Check the valve clearance at the period indicated above and adjust the valve clearance to specification, if necessary.





- Remove CVT case cover ①;
- Remove RPM sensor of left crankcase cover ②;
- Remove cylinder head cover ③;
- Turn the crankshaft until the line 5 of T.D.C. C. on rotor is aligned with mark 6 of inspection hole on left crankcase..
- Insert feeler gauge to check the clearance between the valve stem end and the adjust bolt on the rocker arm.

Valve clearance Intake valve
0.08mm~0.12mm
(When cold) Exhaust valve
0.12mm~0.18mm

Attention:

- The valve clearance must be adjusted when the engine is cold.
- Adjust the valve clearance when the piston is at the Top Dead Center (T.D.C.) on the compression stroke.

- If the clearance is incorrect, bring it into the specified range using the special tool.



5.2 Inspection and adjustment

Loosen valve adjust bolt and nut, insert a feeler gauge between the valve stem end and valve adjusting bolt (0.1mm thickness for intake valve, 0.15mm thickness for exhaust valve), tighten valve adjust bolt, make sure it slightly contacts the feeler gauge, tighten bolt and nut.

● Take out the feeler gauge, measure the clearance. If the clearance is incorrect, repeat the above steps until the proper clearance is obtained.

Locknut: 12N • m

Tools: Valve adjuster
(1P39MB-022102-922-001)

Feeler gauge

Material: Thread Locker

Caution:

Securely tighten the locknut after completing adjustment

ENGINE IDLE SPEED

Inspect initially at 20 hours run-in and every 50 hours or 1500km thereafter.

● Install cylinder head, speed sensor
Start the engine and warm it up for several minutes, measure engine speed with a tachometer.

Engine idle speed: 1500r/min \pm 150r/min

Tool: Tachometer


SPARK PLUG

Inspect initially at 20 hours run-in and every 100 hours or 3000km thereafter.

● Remove the spark plug ① with a special tool;



Specification: DCPR8E (NGK)

● Spark plug inspection: If the electrode is extremely worn or burnt, or spark plug has a broken insulator, damaged thread, etc, replace the spark plug with a new one



5

Ignition Coil



CFMOTO

In case of carbon deposit, clean with a proper tool.

SPARK PLUG GAP: Measure the spark plug gap with a feeler gauge.

Out of specification: Adjust

Spark plug gap: 0.8mm~0.9mm

Caution:

Check the thread size and reach when replacing the spark plug. If the reach is too short, carbon will be deposited on the screw portion of the spark plug hole and engine damage may result

● Spark plug installation

Caution:

To avoid damaging the cylinder head threads; first, tighten the spark plug with fingers, and then tighten it to the specified torque using the spark plug wrench.

Tightening Torque: 20N · m

Tool: Spark Plug Wrench
(0800-022800-922-001)

Feeler Gauge

AIR FILTER

Inspect every 20 hours or 750km, clean it if necessary. Change every 1500km.




If the air cleaner is clogged with dust, intake resistance will be increased, with a resultant decrease in power output and an increase in fuel consumption. Check and clean the air filter as following:

- Remove fixing clamp ①, and top cover ②

Note Be careful not to drop the o-ring into the air filter box that is attached to the air filter top cover.

- Loosen screw ③ remove filter element ④ separate support ⑤ filter paper ⑥ and sponge ⑦

NOTE: If vehicle is used in dusty area, inspect more frequently than specified in MAINTENANCE CHART.



5.2 Inspection and adjustment

If liquid/deposits are found, squeeze and dry the foam filter. Replace filter element if damaged.

CAUTION: Do not start engine if liquid or deposits are found. If there is oil in the air filter housing, check engine oil level. Oil level may be too high.

Pour air filter cleaning solution or an equivalent into a bucket. Put the foam filter in to soak. Do not wash filter element.

While foam filter soaks, clean inside of air filter housing.

Rinse foam filter with warm water and let it dry completely.

Blow low pressure compressed air on filter element to clean it.

Warning: Never use with gasoline or low flash point solvents to clean the filter element.

● Inspect the filter element for tears, torn element must be replaced.

Note: Make sure that the air filter element is in good condition at all times. The surest way to accelerate engine wear is to operate the engine without the element or with torn element. If driving under dusty conditions, clean the air filter element more frequently

● Remove the drain plug 8 of air box to drain out any water.

Drive belt, CVT

Removal

● Remove CVT cover
● Hold the primary sheave with special tool and loosen primary bolt 1, nut 2 and gasket, take drive disk.

Special Tool: CVT Rotor Holder
(OJY0-050000-922-001)


● Hold the secondary sheave with special tool and loosen secondary sheave nut 3.

Special Tool: CVT Rotor Holder
(OJY0-050000-922-001)




● Remove secondary sheave together 3 with drive belt.

Tool: Driven Pulley Expander
(0800-052000-922-003)

● Remove drive belt 4 from secondary sheave



5




CFMOTO

Inspection

- Inspect CVT friction disk for wear and damage. If any cracks or damages are found, replace CVT with a new one.
- Inspect drive belt for wear and damage. If any cracks or damages are found, replace drive belt with a new one.
- Inspect drive belt for width, if width is out of service limit, replace drive belt with a new one.

Service Limit: 33.5mm

Tool: Vernier Caliper



Installation

Reverse the removal procedure for installation. Pay attention to the following:

- Insert drive belt with a special tool, as low as possible, between secondary sliding sheave and primary fixed sheave:
- Hold secondary sheave with a special tool and tighten the nut to the specified torque.

Tool: Installer, drive pulley
(0JY0-050000-922-001)

Nut, Secondary Sheave: 115N • m

- Install primary sheave and nut. Hold the primary sheave with a special tool and tighten the nut to the specified torque.



Nut, Primary sheave: 40N • m

Caution: Fit the drive belt with the arrow on the drive belt points towards normal turning direction.


- Screw Off Driven Pulley Expander, turn primary sheave, until the drive belt is properly seated.

Warning:
The drive belt contact surface of the driven face should be thoroughly cleaned.

- Install CVT cover



sign



5.2 Inspection and adjustment

Inspection of Lubrication System

Replace engine oil and oil filter initially at 20 hours or 750km and every 100 hours or 3000km thereafter.

Check Engine Oil Level

- Keep the engine in a plan position
- Remove oil dip rod 1
- Clean oil dip rod, insert oil dip rod but do not tighten it
- Take out oil dip rod and check if oil is between upper and lower limit.
- If the engine oil is insufficient, fill more oil until the sufficient oil is obtained.


Engine oil: SAE15W/40 SG or higher

Note:



Keep the engine in a plan position Do not tighten oil dip rod when measuring oil level.

Replace Engine Oil

- Remove oil dip rod 1, drain bolt 2 and washer 3;
- Drain out the engine oil while the engine is still warm.
- Clean oil dip rod, drain bolt and washer with solvent.
- Install washer and drain bolt;
Drain Bolt: 25N · m
- Fill engine oil (about 2900mL)



5



CFMOTO

● Install oil dip rod, start the engine and allow it to run for several minutes at idling speed.

● Turn off the engine and wait for about 3 minutes, and then check the oil level on the dipstick.

Caution:



The engine oil should be changed when the engine is warm. If the oil filter should be replaced, replace engine oil at the same time.

Replacing Oil Filter

● Remove relative parts (see Replacing Engine Oil)


● Remove oil filter cover bolt 1 and filter cover 2

● Remove O ring 3 , then oil filter 4



Oil Filter Element Inspection


Check and clean the engine oil filter inlet 1 and outlet 2 area for dirt and other contaminations.



5.2 Inspection and adjustment

Oil Filter Element Installation

Install a **NEW** o-ring on oil filter cover,
Apply engine oil on o-ring and the end of
filter;
Install the element into oil filter bore;
Install the element into oil filter bore, bolt.
Torque screws to:8N • m



Inspection of Cooling System

Check initially at 50 hours or 1500km, re-
place coolant every 2 years

Check radiator, reservoir tank and water
hoses.




Leakage or Damage——Replace

Inspection of engine coolant

Check coolant level by observing the up-
per and the lower limit on the reservoir tank. If
the level is below lower limit, fill coolant until
the level reaches the the upper limit.

Replacing Coolant

- Remove radiator cap ① and reservoir tank cap ②
- Place a pan below water pump, and drain cool-
ant by removing drain plug ③ and water hose ④
- Drain coolant from reservoir tank.



Warning:

Do not open radiator cap when engine is hot, you may be injured by escaping hot liquid or vapor.

Engine coolant is harmful. If coolant splashes in your eyes or clothes, thoroughly wash it away with water and consult a doctor. If coolant is swallowed, induce vomiting and get immediate medical attention.

Keep coolant away from reach of children.

- Clean radiator with fresh water, if necessary

5

CFMOTO

- Connect water hose ④, and tighten clamp ③ securely
- Fill the fresh specified coolant into the radiator
- Loosen bleed bolt ⑤, on water pump, when coolant flow from bleed bolt, tighten the bolt. Install radiator cap ① securely after filling coolant.
- Start the engine and keep it running for several minutes. After warm up and cooling down the engine, open radiator cap and check coolant. Fill the specified coolant until the level is between the upper and lower lines on the reservoir tank.

Caution:

Repeat the above procedures several times and make sure the radiator is filled with coolant and air is discharged.

- Fill coolant into the reservoir tank till between upper and lower limit. Install reservoir tank cap.

Warning: Never mix with other brand

Inspection of Radiator Hose

Perform inspection every 40 hours or 3000km

Check radiator hose and clamp, leakage or damage— Replace.

Inspection of cylinder pressure

Cylinder pressure can reflect the inner cylinder working status. Check cylinder pressure is necessary.

Cylinder pressure: 1000kPa

A lower cylinder pressure may be caused by:

- Excessive wear of cylinder
- Wear of piston or piston ring

5.2 Inspection and adjustment

- Piston ring jam in groove
- Poor closure of valve seat
- Damaged cylinder gasket or other defects

Note:

When cylinder pressure is too low, check the above items.



Testing Cylinder Pressure

Note:

Before testing of cylinder pressure, make sure that cylinder head bolts are tightened to the specified torque and valve clearance has been properly adjusted.

- Warm up the engine before testing
- Make sure battery is fully charged
- Remove spark plug 1
- Install cylinder pressure gauge 2 in spark plug hole and tighten nut
- Keep throttle full open
- Press start button crank the engine a few seconds. Record the maximum reading of cylinder pressure.

Tools: Cylinder Pressure Gauge
Adaptor



5

CFMOTO

5.3 Engine Removal, Inspection & Installation

△Engine Removal/Installation Orders and the Relative Page Numbers

Item	Description	Disassembly	Inspection/Maintenance	Assembly	Remarks
Engine Front Side ↓	Spark Plug	5-37	5-26	5-96	
	Cylinder Head Cover	5-37	5-47	5-96	
	Timing Chain Tensioner	5-37	5-47	5-95	
	Start decompression COMP	5-37	5-47	5-95	
	Timing driven sprocket	5-38	5-47	5-95	
	Camshaft, rocker arm	5-38	5-48	5-94	
	Cylinder Head	5-38	5-48	5-94	
	Guide chain plate	5-38	5-58	5-93	
	Cylinder	5-38	5-58	5-93	
	Piston	5-39	5-59	5-92	
Engine Right Side ↓	CVT Cover	5-39	5-61	5-96	
	Primary Sheave/Secondary Sheave/Drive Belt	5-39	5-62	5-91	
	CVT case	5-40	5-68	5-91	
	Chain holder, Tension plate	5-40	5-68	5-91	
	Timing Chain	5-40	5-68	5-91	
	Starting Motor	5-40	5-113	5-91	
Engine Left Side ↓	Sector Gear	5-41	5-68	5-88	
	Water Pump cover	5-41	5-69	5-90	
	Cap	5-41	/	5-90	
	Axle sleeve	5-42	/	5-90	
	Oil filter	5-42	5-69	5-90	
	Left Crankcase Cover/Magneto Stator	5-42	5-69	5-89	
	Magneto Rotor	5-42	5-69	5-89	
	Starting Driven Gear	5-43	5-70	5-89	
	Starting Dual Gear	5-43	5-71	5-89	
	Oil pump drive gear/Oil pump dual gear	5-43	5-71	5-89	

5.3 Engine Removal, Inspection & Installation

To be continue

Item	Description	Disasse mbly	Inspection/ Maintena	Asse mby	Rema rks
Engine Center	Gear Position Bolt	5-43	/	5-88	
	Right Crankcase/Crankc ase inspection	5-44	5-72	5-87	
	Front Output Shaft Components/ Driven Bevel Gear Components	5-44	5-76	5-86	
	Bevel Gear Components	5-45	5-75	5-87	
	Transmission Main Shaft	5-45	5-79	5-86	
	Shift Drum/ Shift Fork COMP	5-45	5-79	5-86	
	Drive countershaft	5-45	5-79	5-87	
	crankshaft & connecting	5-46	5-82	5-87	
	Balance Shaft	5-46	5-85	5-87	
	Oil Pump	5-46	5-85	5-88	
	Filter Net	5-46	/	5-88	
	Left Crankcase	/	5-72	/	

5

Notes: Arrowhead direction is for engine removal orders. Reverse the direction for assembly and installation

CFMOTO

I Engine Removal

Preparation before engine removal

- Prepare a proper tray used for load of components
- Prepare necessary removal and assembly tools
- Drain up engine oil (see 5.2.8)
- Drain up coolant (see 5.2.9)

Engine Front Side

Spark Plug

- Remove spark plug with special wrench (see 5.2.5)

Cylinder Head Cover





- Remove 4 bolts of cylinder head cover. Remove cylinder head cover 1

Timing Chain Tensioner

- Remove screw plug ①, insert a flat screwdriver into slot of timing chain tensioner adjuster, turn it clockwise to lock tensioner spring;
- Remove tensioner fix bolt
- Remove tensioner and gasket

Start decompression COMP


- Remove bolt 1, Remove Start decompression COMP 2



5.3 Engine Removal, Inspection & Installation

Timing driven sprocket


- Loosen 2 bolts 1 of timing driven sprocket
- Remove timing driven sprocket



Camshaft, rocker arm

- Loosen bolt 1
- Remove camshaft holder
- Remove rocker arm shaft, Remove rocker arm
- Remove camshaft


Note: Turn camshaft to free state.



Cylinder Head, Guide Chain Plate


- Remove 2 bolts 1 of cylinder head
- Remove 4 cylinder head bolts 2 diagonally
- Remove cylinder head 3
- Remove guide chain plate
- Remove dowel pin and cylinder head gasket

Note: Take care not to drop dowel pin into crankcase



Cylinder

- Remove cylinder



CFMOTO

Piston

Put a clean rag under piston so as not to drop piston pin circlip into crankcase.



Warning: Piston pin circlip is spring-loading

● Remove piston pin circlip 1 and discard it.

Note: No need to remove two piston pin circlip

Remove piston pin circlip 3 from piston pin hole (connecting rod hole)

Remove piston 2 from connecting rod




Engine Right Side

CVT Cover

● Remove CVT cover (see 5.2.7)

Primary Sheave/Secondary Sheave/Drive Belt

● Remove drive bolt 1 and driven screw 2




● Remove secondary sheave with special tools

● Remove primary sheave/secondary sheave/drive belt

Tool: Sheave Holder 3


(0JY0-050000-922-002)




5.3 Engine Removal, Inspection & Installation

CVT Case

- Remove bolt of air intake plate
Remove air intake plate




- Remove bolt of CVT case
- Remove CVT case
- Remove dowel pin
Remove paper gasket and discard it.



5


Chain holder, Tension plate

- Remove bolt 1 of tension plate
Remove tension plate 2
- Remove chain holder 3




Timing Chain

- Remove timing chain from crankshaft sprocket



Starting Motor


- Remove 2 bolts of starting motor
- Remove starting motor




CFMOTO

Sector Gear

- Remove 4 bolts of sector gear housing cover
- Remove sector gear housing cover 1




- Remove dowel pin and gasket
- Remove drive sector gear
- Loosen bolt 3, remove driven sector gear




Water Pump

- Screw out bolt of water pump
- Remove water pump, O ring



Cap


- Remove 3 bolts, remove cap



5.3 Engine Removal, Inspection & Installation


Axle sleeve

- Screw out bolt 1, remove Axle sleeve




Oil Filter

- Screw out 3 bolts of filter cover
- Remove filter cover, O ring
- Remove oil filter



Left Crankcase Cover/Magneto Stator


- Remove bolts of left
- Remove left crankcase cover
- Remove dowel pin and gasket



Magneto Rotor

- Install special tool to rotor thread
Remove rotor and woodruff key


Tool: Rotor Remover
(0180-031000-922-001)



CFMOTO


Starting Driven Gear/Starting Dual Gear

- Remove starting driven gear 1 and needle bearing
- Remove starting dual gear 2 and shaft




Oil pump drive gear/Oil pump dual gear


- Remove oil guide bolt
- Remove oil guide 1



- Remove 2 Circlip 2 by circlip plier
- Remove oil pump drive gear 3, oil pump dual gear 4 and gasket




- Remove needle bearing 5
- Remove pin shaft 6, gasket



Engine Center

Gear position bolt


- Remove gear position bolt 1
- Remove spring and steel ball




5.3 Engine Removal, Inspection & Installation

Right Crankcase

- Remove left crankcase bolts



- Remove right crankcase bolts




5

- Separate crankcase carefully with rubber hammer knocking the case


Caution:

Do not damage the seal surface of right/left crankcase when separating
Crankshaft should remain in the left crankcase half.




Front Output Shaft, Driven Bevel Gear

- Remove bevel gear cover bolt
- Remove driven bevel gear 1




CFMOTO

- Remove bolt 1 , gasket 2 , front output coupler 3, oil seal 4, front output shaft bearing ring 5(LH)
- Remove Front Output Shaft 6




Drive Bevel Gear

- Screw out driven bevel gear bearing seat bolt
- Remove driven bevel gear from left crankcase



Transmission Main Shaft


- Remove transmission main shaft 7



Shift Drum, Shift Fork, Drive countershaft

- Remove shift drum 8, shift fork 9, and drive countershaft 10


Note: Shift drum, shift fork and drive countershaft should be removed together.



5.3 Engine Removal, Inspection & Installation

Crankshaft

- Turn the crankshaft to the point indicated on the picture to level up scale and holes of the balancing shaft.
- Remove crankshaft from left crankcase




Balance Shaft

- Remove balancer shaft from left crankcase

Oil pump

- Screw out oil pump bolt
- Remove oil pump 1


Note: Oil pump bolt size M5 X 16



5

Filter Net

- Screw out the bolt
- Remove filter cap 2
- Remove filter net



2

CFMOTO

II Engine Components Inspection


Cylinder Head Cover

Check if any scratch is on the cap.

Check is any crack, crush or hardening on the sealer ring. If so, change accordingly.

1.Cylinder Head Cover

2.Cylinder Head Cover Seal Ring





Timing Chain Tensioner

● Check tensioner for any damage or poor Function. Damage, poor function: Replace

● Performance stability inspection methods

■ Insert screw driver 3 into the slotted end of adjusting screw, turn it clockwise to loosen the tension and release the screw-driver

■ Move the screw driver and let go of the arm slowly, ensuring the arm snaps back smoothly. If not, replace the chain tensioner with a new one.




Start decompression COMP

● Check if any crack is on the reducer. If any, change a new one.

● Move pressure reducing arm 4. Check if pressure-reducing rocker arm and camshaft can move flexibly and return automatically.

Timing Driven sprocket

● Check any scratch or damage on camshaft timing chain wheel. If the gear is scratched or damaged, change a new one completely (including camshaft timing chain wheel and timing chain).



5.3 Engine Removal, Inspection & Installation

Camshaft Inspection

- Check any scratch, abrasion, crack or other damage on each camshaft and journal.
- Check journal dia. and height of camshaft by micrometer

Camshaft	
Cam(intake)	
New part	32.985mm~33.025 mm
Maintenance limit	32.865 mm
Cam(exhaust)	
New part	32.971mm~33.011mm
Maintenance limit	32.871 mm

Camshaft journal(timing chain side)	
New part	34.959mm~34.975 mm
Maintenance limit	34.950 mm
Camshaft bearing shaft (ignition plug side)	
New part	21.959mm~21.980 mm
Maintenance limit	21.950 mm

- Test tolerant clearance of camshaft sides and cylinder cap

Camshaft bearing hole(timing chain side)	
New part	35.007mm~35.025 mm
Maintenance limit	35.040 mm
Camshaft bearing hole(spark plug side)	
New part	22.012mm~22.025 mm
Maintenance limit	22.040 mm


If parameters are beyond standards, change the parts.

Cylinder head cover


Remove rocker arm

- Remove rocker arm bearing
- Remove rocker arm(intake and exhaust)
Including adjusting screw and nut.


1. Rockshaft
2. Exhaust rocker arm
3. Intake rocker arm
4. Adjusting screw
5. Nut



- A. Cam(exhaust valve)
 B. Cam(intake valve)
 C. Camshaft journal(timing chain side)
 D. Camshaft journal(ignition plug side)



- A. Camshaft bearing hole(timing chain side)
 B. Camshaft bearing hole(spark plug side)



CFMOTO

- Remove Thrust washer.

CAUTION: Pay attention not to lose thrust washers or drop them into the timing chain compartment.

Rocker Arm Inspection

- Inspect each rocker arm for cracks and scored friction surfaces. If any, replace rocker arm assembly.
- Check the rocker arm rollers for free movement, wear and excessive radial play. Replace rocker arm assembly if necessary.
- Check rocker arm bore diameter. If diameter is out of specification, change rocker arm assembly.

Rocker Arm Bore Diameter	
New	12.000mm~12.018mm (0.4724in~0.4731in)
Service Limit	12.030mm (0.4736in)


- Check adjustment screws for free movement, cracks and/or excessive play.

Rocker Arm Shaft


- Check for scored friction surfaces; if any, replace parts.
- Measure rocker arm shaft diameter.

Rocker Arm Shaft Diameter	
New	11.973mm~11.984mm
Service Limit	11.960mm


Any area worn excessively will require parts replacement.




- 1.2 Thrust Washers
- 2.Rocker Arm,Exhaust
- 3.Cylinder Head Spark Plug Side
- 4.Big Taper to Spark Plug Side



- 1.Rocker Arm,Exhaust
- 2.Roller
- A.Bore for Rocker Arm Shaft



- 1.Free Movement of Adjustment Screw



- A.Measure rocker arm shaft diameter here


5.3 Engine Removal, Inspection & Installation

Valve Spring Removal

- Use valve spring compressor clamp (CF188-022006-922-001) to compress valve spring

WARNING

Always wear safety glasses when disassembling valve springs. Be careful when unlocking valves. Components could fly away because of the strong spring preload




Valve Spring Compressor Clamp




Valve Spring Compressor Cup

5



Align valve spring compressor clamp with the center of Valve

- Remove valve cotters.
- Withdraw valve spring compressor, valve spring retainer and valve spring.



1. Valve Spring Compressor Clamp
2. Valve Spring Compressor Cup
3. Valve Cotter


CFMOTO

Valve Spring Inspection

- Check valve spring for visible damages, If any, replace valve spring.
- Check valve spring for free length and straightness.

Valve Spring Free Length	
Normal New	40 mm
Service Limit	38.2 mm


Replace valves springs if not within specifications.



A. Valve Spring Length


Valve Removal

- Push valve stem, then pull valves(intake and exhaust)out of valve guide.




- 1.Intake Valve 33mm
- 2.Exhaust Valve 29mm

- Remove valve stem seal with Snap-on pliers and discard it.



Plier



- 1.Plier
- 2.Valve Stem Seal

5.3 Engine Removal, Inspection & Installation

Valve Inspection

Valve Stem Seal

Always install new seals whenever valves are removed

Valve

● Inspect valve surface, check for abnormal stem wear and bending. If out of specification, replace by a new one.

Valve Out of Round (Intake and Exhaust Valves)	
New	0.005 mm
Service limit	0.06 mm

Valve Stem and Valve Guide Clearance

● Measure valve stem and valve guide in three places using a micrometer and a small bore gauge.


NOTE: Clean valve guide to remove carbon deposit before measuring.

Change valve if valve stem is out of specification or has other damages such as wear or friction surface.

Valve Stem Diameter	
Exhaust Valve	
New	4.955mm~4.970 mm
Service limit	4.930 mm
Intake Valve	
New	4.965mm~4.980 mm
Service limit	4.930 mm


Replace valve guide if valve guide is out of Specification or has other damages, such as wear or friction surface

Valve Guide Diameter (Intake and Exhaust Valves)	
New	5.000mm~5.012 mm
Service limit	5.045 mm



5

A. Valve Stem Diameter



1. Valve Seat
2. Exhaust Valve Contaminated Area
3. Valve Face (Contact Surface to Valve Seat)

CFMOTO

Valve Face and Seat

● Check valve face and seat for burning or pittings and replace valve or cylinder head if there are signs of damage.

● Ensure to seat valves properly. Apply some lapping compound to valve face and work valve on its seat with a lapping tool (see Valve Guide Procedure below).

● Measure valve face contact width.

NOTE: The location of contact area should be in center of valve seat.

● Measure valve seat width using a caliper.

Valve Seat Contact Width	
Exhaust Valve	
NEW	1.20mm~1.40 mm
Service limit	1.80 mm
Intake Valve	
New	1.10mm~1.30 mm
Service limit	1.70 mm

If valve seat contact width is too wide or has dark spots, replace the cylinder head.


Valve Guide Removal

NOTE: Clean valve guide area from contamination before removal.

● Use valve guide remover(0800-022102-922-001)and a hammer, drive the valve guide out of cylinder head.

Valve Guide Inspection


Always replace valve stem seals whenever valve guides are removed.
Clean the valve guide bore before re-installing the valve guide into cylinder head.



A. Valve Contact Surface Width
B. Valve Seat Contact Width



Valve Guide Remover



1. Valve Guide Remover
2. Valve Guide

5.3 Engine Removal, Inspection & Installation


Injector Seat

- Unscrew the set bolt and remove the injector seat 1

Injector Seat Inspection


- Inspect Injector Seat for cracks or other damage..

Check the seal for wear or excessive using. Replace it if necessary.



Water Temperature Sensor and Thermostat

- Unscrew the Thermostat bolt,remove the Thermostat Cover,Thermostat,Thermostat Seat andWater Temperature Sensor.
- Water Temperature Sensor Inspection (Check 5. 4. 6)
- Thermostat Inspection (Check 5.6.7)



5

CFMOTO

Cylinder Head Installation

Valve Guide Installation

For installation, reverse the removal procedure. Pay attention to the following details.

- Use valve guide installer(0800-022102-922-002)to install valve guide.


NOTE: Apply loctite(antiseize lubricant) on valve guide prior to install it into the cylinder head.

- Push valve guide in the cold cylinder head as per following illustration.


Valve Guide (Measurement "A")	
NEW	14.70mm~15.30 mm



Valve Guide Installer



1. Valve Guide Installer
2. Valve Guide



1. Thrust Surface of Cylinder Head
 2. Valve Guide
- A. Measurement from Thrust Surface to Valve Guide Top

5.3 Engine Removal, Inspection & Installation

- Valve guide to be adjusted in diameter by using a reamer.

Valve Guide Diameter (Intake and Exhaust Valves)	
New	5.000mm~5.012 mm

NOTE: Ensure to turn reamer in the right direction. Use cutting oil and make brakes to clean reamer/valve guide from metal shavings.

- Apply some lapping compound to valve face and work valve on its seat with a lapping tool.

NOTE: Ensure to seat valves properly. Apply marking paste to ease checking contact pattern.

- Repeat procedure until valve seat/valve face fits together.


Note: Clear up the abradant

Valve Installation


For installation, reverse the removal procedure(Check 5-46). Pay attention to the following details.

- Install a **NEW** valve stem seal. Make sure thrust washer is installed before installing seal.
- Apply engine oil on valve stem and install it.


CAUTION: Be careful when valve stem is passed through sealing lips of valve stem seal.



1. Valve Guide
A. Valve Guide Diameter



1. Valve Seat
2. Valve Face(contact surface to valve seat)
3. Turn valve while pushing against cylinder head
A. Valve Seat Angle 45



1. Valve Spring Lower Seat
2. Sealing Lips of Valve Stem Seal

5

CFMOTO

Valve Spring Installation

For installation, reverse the removal procedure(Check 5-45). Pay attention to the following details.

- Colored area of the valve spring must be placed on top.
- To ease installation of cotters, apply oil or grease on them so that they remain in place while releasing the spring.

NOTE: Valve cotter must be properly engaged in valve stem grooves.

- After spring is installed, ensure it is properly locked by tapping on valve stem end with a soft hammer so that valve opens and closes a few times.

CAUTION: An improper locked valve spring will cause engine damage.

Rocker Arm Installation


NOTE: Use the same procedure for exhaust and intake rocker arm.

- Apply engine oil on rocker arm shaft.
- Install the rocker arm shaft with the chamfered edge first and use following procedure.
 - 1、 Insert a rocker arm pin through rocker arm pin bore.
 - 2、 Install a thrust washer then proper rocker arm(exhaust side)or (intake side).
 - 3、 Push in rocker arm shaft until its chamfer reaches the end of rocker arm bore.
- Place the other thrust washer and push rocker arm shaft to end position.


Thermostat Installation

- Install the Thermostat seat 1, Thermostat2, Thermostat cover 3 and two bolts 4


Note:Don't miss to install the "O" seal ring



1.Position of the Valve Spring
2.Valve Cotter



1.Rocker Arm
2.Thrust Washer(Timing Chain Side)
3.Thrust Washer(Spark Plug Side)




5.3 Engine Removal, Inspection & Installation

Injector Seat Installation

● For installation, reverse the removal procedure (Check 5-49).

Note: Don't miss to install the seal ring.



1 .InjectorSeat

Upper Guide Chain Inspection

● Inspect Upper guide chain, check for abnormal wear, cracks and rubber fall off. If out of specification, replace by a new one.



5

Cylinder Body Inspection


Cylinder Body Distortion

● Check the planeness of gasket surface, total 7 point to inspect with a straight edge and thickness gauge. Take clearance readings from several places. If any clearance reading is out of the service limit, replace with a new cylinder body.

Cylinder Body Distortion Service Limit:

0.05mm

Tool: Thickness Gauge, straight edge



Cylinder Body Inner Diameter Inspection



● Check the scoring or other damages in the inner wall of Cylinder Body, Replace it if necessary.

● Measure the diameter of bore by Inner diameter gauge from upper, middle and lower places of cylinder inner diameter to check with two mutual vertical direction.

Cylinder body inner diameter service limit:

90.99mm~91.01mm

Tool: Inner diameter gauge



CFMOTO

Piston



Piston Diameter

● Inspect Piston for cracks or other damage. Replace piston and piston ring if necessary.

● Vertical measure the piston on the 8mm direction between piston pin by micrometer

Replace piston if out of service limit.

Piston Parameter	
New	90.950mm~90.970 mm
Service Limit	90.85 mm



Piston Ring Groove Clearance

● Measure the one-sided clearance of piston 1 and 2 by Straight edge, if out of service limit, replace piston and piston ring.

Service limit (Clearance)

Piston ring 1 : 0.15mm

Piston ring 2: 0.15mm

Service limit (Width)

Piston ring 1: 1.21mm~1.23mm

Piston ring 2: 1.51mm~1.53mm

Oil ring: 2.50mm~2.52mm



Service limit (Thickness)

Piston ring 1: 1.17mm~1.19mm

Piston ring 2: 1.47mm~1.49mm

Tool: Straight edge

Micrometer(0~25mm)



5.3 Engine Removal, Inspection & Installation

Piston ring free gap and Piston ring end gap

● Using a feeler gauge measure each ring free gap, place the ring in the cylinder. To measure the ring end gap, if the clearance is too large, the piston and piston rings should be replaced.

Piston ring free gap (service limit)

Piston ring 1: 8.9mm


Piston ring 2: 9.5mm

Piston ring end gap (service limit)

Piston ring 1: 1.5mm

Piston ring 2: 1.5mm

Tool: Vernier caliper. Feeler gauge



5

Piston Pin and Pin Bore

● To measure the inner diameter of Piston pin bore by Bore dial indicator.

To measure the outer diameter of Piston pin by micrometer

If out of service limit, replace Piston and Piston pin



Piston Pin Bore(service limit): 22.010mm

● To measure the outer diameter of Piston Pin in three different positions by micrometer.

Piston Pin outer diameter(service limit): 21.980mm

Tool: Inner diameter gauge 18mm~35mm

Micrometer 0~25mm



CFMOTO

Piston/Cylinder Clearance

- Adjust and lock micrometer to the piston dimension. With the micrometer set to the dimension, adjust a cylinder bore gauge to the micrometer dimension and set the indicator to 0(zero).

- Position the dial bore gauge 20mm(0.787 in) above cylinder base, measuring perpendicularly(90°) to piston pin axis

Read the measurement on the cylinder bore gauge. The result is the exact piston/cylinder body clearance.

Piston/Cylinder Clearance	
NEW	0.030mm~0.050 mm
Service Limit	0.100 mm


NOTE: Make sure used piston is not worn. If clearance exceeds specified tolerance, replace piston by a new one and measure piston/cylinder clearance again.

NOTE: Make sure the cylinder bore gauge indicator is set exactly at the same position as with the micrometer, otherwise the reading will be false.


CVT Cover

- Inspect CVT Cover 1 for cracks. Replace a new CVT Case if necessary

- Inspect seal ring 2 of CVT Cover for ageing, damage. Replace a new one if necessary



1. lock micrometer to the piston dimension




1. Use the micrometer to set the cylinder bore gauge

2. Dial Bore Gauge




1. Indicator set to 0(zero)



5.3 Engine Removal, Inspection & Installation

Drive Pulley, Driven Pulley, Drive Belt




5

- | | |
|--------------------------------|----------------------------------|
| 1、 Drive Pulley Fixed Sheave | 10、 Driven Pulley Fixed Sheave |
| 2、 Drive Belt | 11、 Driven Pulley Sliding Sheave |
| 3、 Adjusting Washer | 12、 Spring holder |
| 4、 Spring, Drive Pulley | |
| 5、 Drive Pulley Sliding Sheave | |
| 6、 Centrifugal weight | |
| 7、 Cam | |
| 8、 Nut | |
| 9、 Bolt | |

CFMOTO

Drive Pulley


- Loosen Drive Pulley Nut,remove,CVT, Drive pulley fixed And Sliding Sheave
- Remove the Cam 1 and CentrifugalWeight 2



Centrifugal Weight Inspection

- Inspect CentrifugalWeight and Sliding surface for wear or damage,Replace a set of centrifugal weight if abnormal

Note: Centrifugal Weight should be replaced by complete set.



Ajusting Washer Thickness Inspecti

- Measure the thickness of Ajusting Washer byvernier caliper.Replace it If out of service limit.

Service limit: 5 mm ~7mm




Drive Pulley Fixed and Sliding Sheave Inspection

- Inspect the abnormal conditions of drive surface for multistep wear or other damage. Replace it if abnormal
- Inspect one-way clutch if equipped. Replace it if abnormal

Drive Pulley Installation

To install it as contrary process of removal

Note: The nut washer should be stucked in the hexagon shaft to stand-still locking.




5.3 Engine Removal, Inspection & Installation

Driven Pulley

Disassembly

NOTE: Before disassembly, mark on the spring installation holes and cam feet to sliders positions.




1. Cam and slider marks

2. Spring Installation Holes Marks

- As the illustration shows, place driven pulley on the special tool base.

Special tool: Driven Pulley Remover
(0800-052000-922-002)




1. Driven Pulley Remover
(0800-052000-922-002)

2. Driven Pulley

- Turn special tool handle to compress the cam and spring. Using a circlip remover (a plier), remove circlip.

Note: Use special tool to remove circlip in order to avoid any wounding if spring seat flying up.



1. Driven Pulley Remover
(0800-052000-922-002)



2. Circlip

3. Circlip Remover

5

CFMOTO

- Slowly loosen tool handle to release the spring tension and remove the special tool;
- Remove cam;
- Remove guide pin;
- Remove spring and sliding sheave of driven pulley.



1. Cam
2. Guide Pin
3. Spring
4. Sliding Sheave of Driven Pulley


Driven Pulley Inspection

Driven Pulley Fixed Sheave Inspection

- Check driven pulley faces for any abnormal conditions, such as heavy wear or visible damage. Replace if necessary.

NOTE:Clean fixed sheave of driven pulley before inspection.

NOTE:Driven pulley assembly is precisely matched.If only fixed sheave or sliding sheave is replaced,the vibration may increase.It' s recommended to replace both when necessary.



1. Drive Face of Fixed Sheave

5.3 Engine Removal, Inspection & Installation

Driven Pulley Sliding Sheave Inspection


● Inspect the drive face of sliding sheave for heavy wear and damage. Replace it if necessary.



1. Drive Face of Sliding Sheave

5


● Inspect the 4 sliders on driven pulley for wear and other damages. If the worn thickness is over the measurement illustrated in the following figure, replace all 4 sliders at the same time.



1. Slider
2. Sliding Sleeve

NOTE: Clean the sliding sheave before inspection


$A \geq 1.5\text{mm}$



CFMOTO

Cam Inspection

- Check spring cam sliding face for wear and other damages. replace if necessary.




1. Cam
2. Sliding Face

Driven Pulley Spring Inspection

- Check spring free length. If it is shorter than limit length, replace it.

Spring free limit length A:214.0mm.



1. Spring

Driven Pulley Assembly

Reverse the disassembly procedure for driven pulley assembly.

NOTE:Special tool is also required in driven pulley assembly.

Drive Belt


- To inspect Belt for greasy dirt
- To inspect Belt for cracks and damage
- To measure width of belt by vernier caliper

Replace a new one if any damage or out of service limit

Drive Belt service limit:33.5mm

Tools:Vernier Caliper

Caution:Clean the Drive belt if any greasy dirt or lubricating oil.




5.3 Engine Removal, Inspection & Installation

CVT Case Inspection

- To inspect Bearing Sleeve 1 and Oil seal 2.
- 2. Replace it if necessary


Tool: Oil seal setting tool
(0JY0-013103-921-001)

CVT Case Bearing sleeve Installation tool
(0JY0-013101-921-001)




Lower Timing Chain Guide Inspection

- To inspect the lower timing chain guide for damage or ageing. Replace it if necessary



Tensioner Plate Inspection

- To inspect tensioner plate for damage or ageing. Replace it if necessary.



Timing Chain Inspection

- To inspect the radial clearance of timing Chain.
- To inspect timing chain for excessive wear. Replace timing chain and timing chain sprocket if excessive wear or damage




Gearshift Sector Gear Inspection

Gearshif, Drive Sector Gear

- To inspect drive sector gear for cracks or other defects. Replace it if necessary.
- To measure Gear shaft diameter (A) for cracks or other defects. Replace it if out of service limit.

Service limit: 14.976mm~14.994mm



5

CFMOTO

Gearshift driven sector gear inspection

- To inspect driven sector gear for damage or abnormal. Replace it if necessary.

Water Pump Cover Inspection

- To inspect water pump cover for cracks and sealing surface for pit. Replace it if necessary.

Oil filter

- To replace a new oil filter

Note: Replace a new oil filter after Disassemble each time.

- Periodic replacement oil filter base on requirements of Maintenance period.



Crankcase(LH)Cover


- To inspect magneto coil(2), trigger coil(3) for damage or Short circuit, Replace it if abnormal.
- To inspect bearing(4) for smooth running. Replace it if clamping stagnation
- To inspect oil seal(5) for damage. Replace it if damage
- Smear Thread-locking Adhesives on nuts and fasten base on standard torque while assembling.

Torque:10N · m

- Smear lubricating oil on bearing 4 and grease on oil seal 5

Magneto rotor

- Remove the set bolt of overrun clutch by wrench



5.3 Engine Removal, Inspection & Installation

- To inspect the overrun clutch roller and Cam for wear or damage. Replace it if defected.

- To install the overrun clutch as right direction.

Note: To confirm the direction of “A” is right while Assemble the overrun clutch into magneto rotor.

- Ther arrow marking “B” should toward engine

- Smear lubricating oil on the overrun clutch

- Tighten the bolt after smear thread-locking adhesives by Wrench as standard torque.

Bolt Torque: 26N • m

Accessory: Thread-locking adhesives

- Install driven gear

- Driven gear will be locked if turn it as the direction of arrow by “B” indicated. Otherwise, it is smooth running.

- Turning the driven gear bearing. Replace it if not well running.

- Remove driven gear bearing by special tools

- Install the driven gear bearing by special tools

Tool: Bearing installation&removal tool




5

CFMOTO


Dual Gear

● To inspect the dual gear surface for scratch or bump against. Replace it if abnormal.




Oil Pump Transmission Gear

● To inspect the gear surface for scratch, bump against or plastic ageing. Replace it if abnormal




Oil Pump Dual Gear

● To inspect the gear surface for scratch, bump against or plastic ageing. Replace it if abnormal



5.3 Engine Removal, Inspection & Installation




5

- | | | |
|--------------------|------------------------|-----------------------------|
| 1.Crankcase(Right) | 10.Crankcase(Left) | 19.Bearing |
| 2.Oil seal | 11.“O” ring seal | 20.Bearing |
| 3.Bearing | 12.Speed sensor | 21.Oil seal |
| 4.Bearing | 13.Bearing bush | 22.Bearing bush |
| 5.Bearing | 14.Oil strainer | 23.Lower timing chain guide |
| 6.Bearing | 15.“O” ring seal | 24.“O” ring seal |
| 7.Bearing | 16. Oil strainer cover | 25.Gearshift sensor |
| 8.Copper spacer | 17.Copper spacer | 26.Spacer |
| 9.Bolt | 18.Drain Bolt | 27.Oil pressure sensor |

Crankcase inspection

- Check crankcase halves for cracks or other damage.replace if necessary.
- Measure plain bearing inside diameter and compare to magneto and CVT side journal diameter of crankshaft(refer to CRANKSHAFT).Replace if the measurements are out of specification.

Plain bearing inside diameter (CVT/MAG)	
Service limit	42.100mm



1、 Plain bearing bore diameter

CFMOTO

Plain Bearing Replacement

Plain Bearing Removal

Caution: Always support crankcase halves properly when ball bearings or plain bearings are removed. Damages to crankcase halves may occur if this procedure is not performed correctly.

NOTE: Always use a press for removal of plain bearing. Remove plain bearing with the proper plain bearing remove/installer.

- Carefully push the plain bearings out from the crankcase half inside towards the outside.

NOTE: Place the proper crankcase support sleeve under crankcase halves before removing plain bearing

NOTE: During disassembly, do not damage the sealing surface of the crankcase halves.

Plain Bearing Installation


NOTE: Crankcase and plain bearing must be installed as a pair as shown in the following table:

Crankcase	Plain Bearing
Red (A)	Red
Blue (B)	Blue


CAUTION: Unless otherwise instructed, never use hammer to install ball bearings or plain bearings, use press only.

Install plain bearings with the proper plain bearing remover/installer in a cool crankcase. Do not lubricate plain bearing and /or crankcase for installation.

NOTE: Place proper crankcase support sleeve under the crankcase before installing the plain bearings (refer to bearing removal procedure).



2. Plain bearing remover/installer



1. Oil bore
2. The partition of the plain bearing
3. Crankcase mark

5.3 Engine Removal, Inspection & Installation

● Carefully press-in the plain bearings in the same direction as during installation, from then crankcase inside towards the outside.

During installation ,make sure not to damage the 3 sealing surface of the crankcase.

CAUTION:Mark position of oil bore on crankcase and on plain bearing remover/installer .Align mark on plain bearing remover/installer with mark on crackcase.Wrong oil bore will stop supply to plain bearing and will cause engine damaged.

Ball Bearing and oil sealing Inspection

● To inspect the ball bearing for oil clearance,sound or turning stationarity after Cleaned and lubricated the ball bearing. Replace it if abnormal by special tools.

●To inspect all oil sealing for wear,cracks. Replace it if abnormal by special tool

●To remove and inspect the gearshift sensor (25) for breakover performance by multimeter.Replace it if abnormal



● To remove and clean the drain bolt(18) and Oil strainer(14)

●To install bearing,oil seal by special tools. Bearing with lubricating oil, Oil seal lips with lubricating grease

Note:To inspect running performance after bearing has been installed

● Install new “ O ” ring “O” ring with lubricating grease

● Install gearshift sensor(25)and speed sensor(12).



5

CFMOTO

● Install spacer(17) and drain bolt(18), tighten it as standard torque.

Torque(Drain Bolt): 25N • m

Tool: Bearing remover and installer

Multimeter

Drive Bevel Gear

● To protect the drive bevel gear shaft by one clean duster cloth and clamp by vise

● Loosen the Drive Bevel Gear Nut (3), remove Drive Bevel Gear(4) and Adjusting spacer(5).

● To inspect Drive Bevel Gear(4)and Output Driven Gear (2) for rust,cracks,wear. Replace it if necessary.



● To inspect Bearing (8)for tuning.Replace it if abnormal.

● To adjust Adjusting Spacer(5) if replace any one of Crankcase(Right),Drive Bevel Gear (4),Drive Bevel Gear cover(1).Detail to check Bevel Gear adjusting method

● To tighten tight Nut(3)by standard torque and with lubricating oil on Bearing (8) before install.

Service Limit(Drive Bevel Gear Tight Nut): **45N • m**

Note: Drive Bevel Gear(4) and Driven Bevel Gear should be together replaced.



- 1- Drive Bevel Gear Cover
- 2- Output Driven Gear
- 3- Drive Bevel Gear Nut
- 4- Drive Bevel Gear
- 5- Adjusting spacer
- 6- Drive Bevel Gear Shaft
- 7- Bearing Plate
- 8- Bearing


5.3 Engine Removal, Inspection & Installation

Front Output Shaft

- To inspect Bearing (7) for wear or well running. To inspect Oil seal (5) for damage. Replace if abnormal.
- To inspect Bearing(7) for lubrication oil and Oil seal (5)lips for grease before install output shaft
- To tighten Bearing Stop Nut(6) with thread glue as standard torque

Bearing Stop Nut Torque: 80N • m

Front and Bear Output Shaft Nut Torque:
55N • m



Driven Bevel Gear




- To remove Nut(20),Gasket (19),Land and Oil seal(17)
- To proper protect the thread of Driven Bevel gear by protector, fixed bevel gear cover(15), Push out the Driven bevel gear.
- Put one clean duster cloth①, under the bevel gear cover, to remove the Bearing stop nut(11) and Bearing By special wrench ②
- To inspect Driven Bevel Gear (8) for crack, wear. Replace it if necessary.
- To inspect bearing(10)and (12) for well running. Replace it If not
- To install by use new oil seal(17) and “O” ring seal(12)
- To adjust Adjusting Spacer(14) if replace any one of Crankcase(Right), Driven Bevel Gear (9), Driven Bevel Gear cover(15). Detail to check Bevel Gear adjusting method
- To tighten stop Nut(11) with thread glue by standard torque and with lubricating oil on Bearing (10) ,Bearing (12), Oil seal(17) and “O” ring seal before install.

Bearing Stop Nut Torque: 110N • m

Driven Bevel Gear Nut Torque: 55N • m

Bevel Gear Spacer Adjusting Method

- To adjust spacer① and ② if replace any one of Crankcase ,Bevel gear or Bevel Gear Cover.



Bevel Gear Adjustment

Caution:Keep the Gear backlash and contact surface Within the proper scope in order to best match the bevel gear mesh

Measure Bevel Gear Backlash

● To install Drive and Driven Bevel Gear on the Crankcase.

To tighten the Drive Bevel Gear by straight Screwdriver ③ with duster cloth ② into the Speed sensor hole ①

● To install special tool ③ and dial indicator ④

Tool: Bevel Gear backlash measuring tool
Dial indicator

a=46mm

● To measure backlash by running the Driven Bevel Gear shaft.



Note:Four points to measure on the mutual vertical direction.

● To adjust spacer thickness if out of service limit. Remeasure the backlash of Bevel Gear till to accord with service limit.

Bevel Gear backlash service limit :
0.1mm~0.2mm

Adjustment Method:

Backlash Value	Thickness
< 0.1mm	Reduce thickness
0.1mm~0.2mm	Suitable
> 0.2mm	Increase thickness



5.3 Engine Removal, Inspection & Installation

Gear Surface Contact Inspection

To inspect Gear surface contact after backlash adjusted. Detail as follows:


- Remove Drive and Driven Bevel Gear Shaft From Crankcase.
- Clean splodge and grease for each gears of Drive And Driven Bevel Gear.
- With dyestuff for each gears surface of Driven Bevel gear
- To install Drive and Driven Bevel Gear
- Running the Driven Bevel Gear from front and back direction.
- To inspect dyestuff of Bevel Gears after removed Drive and Driven Bevel Gear.

① Top contacted on the Gear Surface	Improper
② Middle contacted on the Gear Surface	Proper
③ Bottom contacted on the Gear Surface	Improper

● If it is proper gear contact surface ②, move to next Step.

● If it is improper gear contact surface ① and ③, adjust spacer thickness of Bevel Gear and recheck till to accord with standard requirement.

Adjusting Method	
Gear Contact Surface	Adjusting spacer thickness
Gear Contact Surface ①	Reduce spacer thickness
Gear Contact Surface ③	Increase spacer thickness



Note:

Must to inspect backlash after adjust the gear contact surface avoid to any change.

Replace the Drive and Driven Bevel Gear if gear contact surface still improper after backlash adjusting.

Gear contact surface and Gear backlash should be together according to requirement

Drive Shaft Inspection

● To inspect gear surface for hard spot, damage,excessive wear.Replace it if necessary.

Drive layshaft Combination

● To remove the layshaft as picture indication

● To inspect gear surface for hard spot, damage,excessive wear.

To inspect bearing and bush for damage or wear. Replace it if necessary.

Note: Rear Retainer couldn't reuse after removed. Must to be replaced by new one


Shift Drum,Shifting Fork

●To inspect shifting fork clearance as picture indication: Check fit clearance by feeler gauge. Replace shifting fork ,or gears, or together replacement if clearance out of service limit

Shifting fork standard gap:

0.10mm~0.35mm


Service limit:0.45mm



5.3 Engine Removal, Inspection & Installation


- To measure the width of shifting fork slot by vernier caliper

Standard values:6.05mm~6.15mm




- To measure the thickness of shifting fork by vernier caliper

Standard values:5.80mm~5.90mm




5

- To inspect shifting fork ① and ② for damage,curve. Replace it if with defects.




- Install shift fork on the shift fork rod to move it by left and right. If not smooth.Replace it.




- To roll th shift fork rod on the slab. Replace it if curve

Caution: Don't try to straightening the Shift fork rod.




CFMOTO

● To inspect the shift fork spring for broken, damage. Replace it if any defects.



● To inspect Shift Drum Cam for crack, wear. Replace it if any defects.




Installation

Reverse process for installation and removal. Attention as follows:

Note:

With right installation process to install the new retainer
To install it base on picture indication
Gears or shaft should be installed with engine lubrication oil




Caution:

Retainer ring could't reuse if removed it from shaft Install a new one.
Don't too wide open when install retainer ring.
To confirm the retainer ring has been fully installed after assembled.

● Don't reverse install the shift fork and spring when assemble the shift fork.

- 1.shift fork,shaft.
- 2.Parking Arm;
- 3.Retainer ring
- 4.shift fork
- 5.Thin shift fork spring
- 6 Thick shift fork spring
- 7.Spring seat




5.3 Engine Removal, Inspection & Installation

Crankshaft Inspection

NOTE: Check each bearing journal of crankshaft for scoring, scuffing, cracks and other signs of wear.

NOTE: Replace the crankshaft if the gears are worn or otherwise damaged.

CAUTION: Components with less than the service limit always have to be replaced. Otherwise severe damage may be caused to the engine.




Connecting Rod Small End Inner Diameter

● To measure connecting rod small end inner Diameter by bore dial indicator. Replace it if out of service limit

Service limit: 22.060mm

Tool: Bore dial indicator (18mm~35mm)



5

Crankshaft Axial Play

NOTE: Axial play of crankshaft needs to be measured before splitting the crankcase.


● Use dial gauge to measure crankshaft axial play at MAG side.

Crankshaft Axial Play	
New	0.050mm~0.450mm
Service Limit	0.6mm

If play is out of specification, replace crankcase and/ or crankshaft.

Connecting Rod Big End Axial Play

● Using a feeler gauge, measure the distance between butting face of connecting rods and crankshaft counterweight.



1. Crankshaft
2. Connecting Rod
3. Gauge

Connecting Rod Big End Axial Play	
New	0.130mm~0.350mm
Service Limit	0.7mm

CFMOTO

Crankshaft runout

● Keep crankshaft connection rod on the “V” block and slow running it to measure crankshaft runout by dial indicator as picture indication.

Replace or adjust it if runout out of service limit.

Crankshaft runout limit value:0.055mm

Tool:Dia Indicator,
“V” Magnetism Stand

Connecting Rod/Poison Pin Clearance

Refer to CYLINDER BODY CHECKING.

Connecting Rod Big End Radical Play

Remove connecting rod from crankshaft.

NOTE: Make sure the same marking of connecting rod to assemble together.

CAUTION: It is better to change the plain bearing when removing connecting rod screws and reinstalling connecting rod.


Measure the diameter of crankpin and compare to inside diameter of connecting rod big end.

Install screws of connecting rod and measure inside diameter of connecting rod big end.


Install bearing of connecting rod as original condition.

Use below-mentioned methods and torque to tighten.

Crankpin	
Standard	43.946mm~43.960mm (1.7302in~1.7307 in)
Service Limit	43.93mm(1.7295 in)
Inside Diameter of Connecting Rod Big End	
Service Limit	44.03mm(1.7335 in)
Clearance between Connecting Rod Big End and Crankpin	
Service Limit	0.09mm(0.0035 in)



- 1.Connecting Rod Screws
- 2.Plain Bearing
- 3.Connecting Rod



- 1.Crankshaft
- A.Diameter of crankpin



- 1.Inside Diameter of Connecting Rod Big End


5.3 Engine Removal, Inspection & Installation

Crankshaft Radial Play

Measure crankshaft on CVT/MAG side and compare to inside diameter of CVT/MAG plain bearing (see CRANKCASE)

Diameter of Crankshaft CVT/MAG Side	
Standard	41.960mm~41.970mm (1.652in~1.6524 in)
Service Limit	41.935 mm(1.651 in)

Clearance between Main Crankpin and Crankcase Hole	
Service Limit	0.09 mm (0.0035in)



1.Crankshaft

A.Diameter of CVT Side Crankshaft

B.Diameter of MAG Side Crankshaft

5

Crankshaft Assembly

NOTE: Follow the table below to assemble crankshaft, connecting rod and connecting rod plain bearing.

Inside Diameter of Connecting Rod Big End	Crankpin	Bearing of Connecting Rod
I	A	Black
II		Blue
I	B	Red
II		Black


Crankshaft assembly procedure is the reverse of disassembly procedure. However, the following details should be noted:

Replace and use new connecting rod bearing when inside diameter of connecting rod big end is less than service limit.

Use compressed air to clean connecting rod split surface after installing bearing into big end of connecting rod

NOTE: Oil is needed in inner surface of connecting rod plain bearing and crankshaft pin before installation.


The side with "CFMOTO" mark of connecting rod is facing to the key groove of crankshaft.



1.Plain Bearing of Connecting Rod Big End

2.Split Surface of the Connecting Rod

3.Nose of Plain Bearing in line with Connecting Rod Groove



1."CFMOTO"mark

2.Key Groove

CFMOTO

Screw of connecting rod should be tightened by following methods.

- Firstly torque to $10\text{N} \cdot \text{m}$ ($7.5\text{ lbf} \cdot \text{ft}$),
Do not apply thread locker
- Then torque to $20\text{N} \cdot \text{m}$ ($15\text{ lbf} \cdot \text{ft}$).
- Finally torque to $50\text{N} \cdot \text{m}$ ($35.25\text{ lbf} \cdot \text{ft}$)

CAUTION: Improper installation will cause screw looseness and engine damage.


ATTENTION: Bearing of connecting rod big end and piston pin's rotation way cannot be changed.



1. Torque Wrench

Trunnion Shaft

- To inspect Trunnion shaft and trunnion shaft gear Replace it if damage.
- To inspect Trunnion shaft gears for crack, scratch or others. Replace it if damage



Oil Pump Inspection

- To inspect all parts of Oil Pump. Replace it if any defects.
- To measure bottom clearance a (clearance between inner and outer rotor) and backlash b (clearance between outer rotor and crankcase), Replace oil pump if out of service limit



Bottom Clearance standard value:
 $0.07\text{mm} \sim 0.15\text{mm}$

Limit value: 0.2mm

Backlash Standard value:

$0.03\text{mm} \sim 0.10\text{mm}$

Limit value: 0.12mm



5.3 Engine Removal, Inspection & Installation

III Engine Installation

The installation essentially the reverse of the remove procedure, special attention as follows:

Note: Clean all parts before install.
Without any cracks for all parts before install All motion parts should with lubrication oil before install Oil seal lips and O ring seal with lubrication grease

Caution: Without any grease in belt, drive and driven pulley

5


Middle parts of Engine Installation

Crankcase(right),Front output shaft,Driven Bevel Gear

● To install Crankcase(right),Front output shaft,Driven Bevel Gear and fasten bolt as standard torque,Detail as picture indication.

Front output pulley erection bolt standard torque: 55N • m

Driven Bevel Gear Seat erection bolt standard torque:28N • m




- | | |
|----------------------|---------------------|
| 1.Bolt | 5.Adjusting Spacer |
| 2.Land | 6.Driven Bevel Gear |
| 3.front output shaft | 7.Drive sleeve |
| 4.Crankcase(right) | 8.Bolt |

Shifting Drum,Shifting frok, Drive layshaft

● Insert the shifting frok into the sliding sleeve,then install the drive layshaft,shifting fork,shifting drum into crankcase(left)

Main Shaft

● Install the Mail Shaft




CFMOTO

Drive Bevel Gear

- Install Drive Bevel 2 and tighten 4 Nuts (1)

Erection Bolt torque(M8X 28):32N · m




Trunnion Shaft,Crankshaft,Connection rod

Install trunnion shaft

- Turn the trunnion shaft into proper position (as picture indication),install inot crankshaft

- Keep a strip of straight line for marks on crankshaft,oil bore of trunnion shft neck

Running the crankshaft and trunnion shaft to Inspect whether match for trunnion shaft bore and gap of crankshaft.if not, reinstall



1.Marks,Crankshaft 2.runnion shaft bore
3.Crankshaft gap

Crankcase(right)

- Wipe Sealant on the crankcase(left) junction surface

Note: Sealant shuld be uniformity and continuous threadiness


- Install three locating pin and “O” ring seal as picture indicated

- Mould assembling,light touch to well done by rubber hammer

- Tighten the bolt as standard torque

Torque: M6 : 10N · m

M8 : 25N · m



Note: opposite angles cross and grading to tighten the bolt.

5.3 Engine Removal, Inspection & Installation

Gears Set Bolt


- Put in steel ball,install the set bolt(1), tighten It as standard torque

Standard torque:18N • m

Primary Strainer

- Install primary strainer and cover(2)
- Tighten bolt as standard torque


Standard torque:8N • m



5

Shift Sector Gear

- Install shift sector gear,tighten bolt
- Install locating pin and gasket
- Close the shift cover. Tighten bolt
- To inspect gears for smooth changing or others. If not, recheck all parts and install again.




- 1 .Bolt
- 2 .Shifting Drive Sector Gear
- 3 .Shifting Driven Sector Gear

Engine(left parts)Installation

Oil Pump

- Install oil pump as right picture indication
 - Tighten bolt
 - Inspect oil pump for smooth running that hold by pliers. Replace and reinstall it if not
- Standard Torque : 7N • m



- 1.Outer rotor,Oil pump
- 2.Roller pin
- 3.Inner rotor,Oil pump
- 4.Oil Pump
- 5.Oil pump shaft
- 6.Bolt

CFMOTO

Oil Pump driving gear, Oil pump dual gear

- Install dual gear and driving gear.
- Install circlip by circlip plier

Note: Don't too open when install, and the new circlip have to be used.

- Install oil baffle plate, tighten bolt as standard torque.



Torque: 8N · m

Dual gear

- Install dual gear(1) and dual gear shaft (2)

Driven gear


- Install driven gear(3)



Magnetor Rotor Combination

- Install woodruff key into crankshaft key groove
- Install Magnetor Rotor Combination


Caution: Clean out grease on the surface of Magnetor Rotor and Crankshaft Conical surface by noncombustible materials and keep drying.



Left Crankcase


- Install Locating Pin(1) and sealing gasket(2)

Note: Use new sealing gasket



5.3 Engine Removal, Inspection & Installation

- Install left crankcase
- Install left crankcase fastening bolt



5

Shaft Sleeve, Blanking Cap


- Install shaft sleeve
 - Install blanking cap and tighten bolt.
- Installation keep the Reverse procedure with removal

Oil filter

- Install new oil filter and O ring seal, tighten bolt.

Water Pump Cover

- Install water pump cover and tighten bolt.



CFMOTO

Starting motor

- Install starting motor, tighten fixed bolt

Engine right side

Timing chain

- Install timing chain

NOTE: Hook up timing chain to prevent it from falling into crankcase

Timing chain upper guide

- Install timing chain upper guide

Tensioner

- Install tensioner, tighten bolt

CVT case

- Install dowel pin 9, gasket 5 and gasket 13, install CVT case to the right crankcase.

- Install bolt 4, bolt 11 and bolt 14

- Install guide 6 and screw 7


Primary sheave, Secondary sheave, drive belt

- Use special tool to open fixed plate and sliding plate
- Install drive belt on primary sheave and secondary sheave


WARNING:

Drive belt contact surface should be free from any grease or oil.

Tool: Separator of sliding plate and fixed plate of secondary sheave (0800-052000-922-003)



1. Timing chain
2. Timing chain upper guide
3. Tensioner



1. Separator of dynamic plate and fixed plate of secondary sheave (0800-052000-922-003)
2. Secondary sheave
3. Drive belt

5.3 Engine Removal, Inspection & Installation

- Install CVT assy and tighten bolt and nut to the specified torque

NOTE: Install bolt of primary sheave anticlockwise

Primary sheave bolt tightening torque:

40N • m

Drive sheave nut tightening torque:

115N • m

Engine top side

Piston

- Install the piston rings in the order of oil ring, ② ring, ① ring.
- the first member to go to the oil ring groove is spacer ①, after placing the spacer fit the two side rails ②.

WARNING: When installing the spacer ①, do not overlap its two ends in the groove.


- Install the second ring A and the first ring B.

NOTE:





Ring 1 and ring 2 differ in shape.
Ring 1 and ring 2 marks "N and TOP"
The marks should be face up when installing

- After installing, inspect the smoothness of piston ring moving.
 - The gaps of three rings should stagger 120° , and the gaps should not face the axial direction of piston pin or the main push surface of piston.
1. Do not face to the main push surface of piston.
 2. Do not face to the axial direction of piston pin.

A.120°



1. CVT assy
2. Bolt
3. Nut



5

CFMOTO

- Apply a light coat of moly oil to the piston pin.

- Install piston pin into holes of piston and connecting rod small end

NOTE: When installing the piston, the “▲” mark on piston top is located to the intake side

NOTE: Piston and cylinder should be installed according to grouping pairing

- place a clean rag beneath piston and install piston pin circlip ①;

NOTE: While rotating crankshaft, pull the cam chain upward, or the chain will be caught between sprocket and crankcase.

- Install the dowel pins and the new cylinder gasket.

WARNING: Use a new cylinder gasket to prevent oil leakage

Cylinder

- Apply engine oil to piston skirt and cylinder wall.

- Hold each piston ring with proper position, insert piston into the cylinder.

NOTE: Pull timing chain from chain cavity, and then install cylinder properly.

NOTE: Piston and cylinder should be installed according to grouping pairing





Chain Guide

- Install chain guide 2

- Install dowel pin 1 and new cylinder gasket 3

WARNING: Use new cylinder gasket to prevent oil leakage.

- Rotating crankshaft, and rotate the piston to upper dead center of crankshaft



1. Dowel pin 2. Chain guide
3. Cylinder gasket

5.3 Engine Removal, Inspection & Installation

Cylinder head


- Install cylinder head , tighten bolts diagonally to the specified torque.

Cylinder head cover bolt tightening torque:

Initial: 20N • m

Final: 40N • m

- Install bolt M6




5

1. Cylinder head cover bolt M10

2. Nut M6

Camshaft, Rocker Arm

- Install camshaft
- Install rocker arm
- Install rocker shaft



1. Rocker arm 4. Adjusting screw


2. Exhaust rocker 5. Nut

3. Intake rocker 6. Camshaft

- Install camshaft holder into the groove of camshaft.

- Tighten nut


1. The position of camshaft holder
2. The locating groove of camshaft
3. The moving direction



CFMOTO

Timing Driven Sprocket

- Remove speed sensor and align the carved line of magneto and mark of left cover. If not alignment, rotate camshaft and make them be aligned.




1 .carved line of magneto

- Install timing driven sprocket, make the carved line of sprocket and the contact surface of cylinder head cover be parallel

- Hitch timing chain
- Tighten the fastening bolt to the specified torque

NOTE: make sure to apply screw locker on the fastening bolt of chain sprocket



1 .chain sprocket fastening bolt
2 .carved of timing chain sprocket
3 .the contact surface of cylinder head cove


Specified torque: 15N • m

Decompressor Starter

- Install decompressor starter
- Tighten the bolt to the specified torque


Decompressor starter bolt specified torque:

30N • m



Timing Chain Tensioner

- Insert flat head screw driver into the end of tensioner groove, rotate clockwise and lock tensioner spring



5.3 Engine Removal, Inspection & Installation

- Install timing chain tensioner and new seal gasket 1
- Install fixed bolt 2 and fasten it to the specified torque

Chain tensioner bolt specified torque:
10N • m

- after installing tensioner, use flat head screw driver to rotate it anticlockwise and make the spring press the tensioner adjuster to compress timing chain.

- Install new gasket 3
- Install tensioner screw to the specified torque:

Tensioner screw specified torque:
8N • m

Throttle body adjustment

- Adjust the gap of throttle body according to 2-3 throttle body gap adjustment procedure
- Install speed sensor, tighten the bolt

Cylinder Head Cover




- Put rubber ring on cylinder head cover
- install cylinder head cover
- tighten bolt

Spark plug


- install and tighten spark plug 1

CVT cover

- install CVT cover and tighten bolt



5



CFMOTO


5.4 Cooling and lubrication system

5.4.1 Engine cooling system chart	5-95
5.4.2 Engine coolant	5-96
5.4.3 Cooling cycle leakproofness check	5-96
5.4.4 Radiator and water hose check and clean	5-97
5.4.5 Cooling fan check	5-98
5.4.6 Water temperature transducer check	5-99
5.4.7 Thermostat check	5-100
5.4.8 Water pump	5-101
Water pump disassembly	5-101
Water pump check	5-102
Water pump assembly and installation	5-105
5.4.9 Engine lubrication system chart	5-107
5.4.10 Lubrication system check	5-108
5.4.11 Engine oil pump and decompressor check	5-108

5.4 Cooling and lubrication system

5.4.1 191Q Engine cooling system chart

- 1. Left crankshaft case;
- 2. Left crankshaft cover;
- 3. Water pump;
- 4. Water outlet;
- 5. Thermo switch;
- 6. Radiator;
- 7. Radiator cap;
- 8. Fan Motor;
- 9. Reservoir tank;
- 10. Water inlet;
- 11. Cylinder head;
- 12. Thermostat housing;
- 13. Thermostat;



5

CFMOTO

5.4.2 Engine Coolant

The cooling used in cooling system is mixture of 50% distilled water and 50% ethylene glycol antifreeze. This 50:50 mixture provides the optimized corrosion resistance and the fine heat protection. The coolant will protect the cooling system from freezing at temperature above -30°C , the mixing ratio of coolant should be increased to 55% or 60% according to the figure on the right.

WARNING:

Use high quality ethylene glycol base antifreeze and mixed with distilled water. Never mix alcohol base antifreeze and different brands of antifreeze. The ratio of antifreeze should not be more than 60% or less than 50%. Do not use anti-leak additive.

DANGER:

DO NOT open radiator cap when the engine is still hot. Or you may be injured by scalding fluid or steam; Coolant is harmful. DO NOT swallow or stain your skin or eyes with coolant. In case of accidental swallow or stain, flush with plenty of water and consult the doctor immediately; Keep coolant away from reach of children.





5.4.3 Inspection of cooling circuit

- Remove radiator ① and connect tester ②

DANGER: DO NOT open the radiator when the engine is still hot, or you may be injured by scalding fluid steam.

- Give a pressure of 105kPa, and check if the cap hold the pressure for at least 10 seconds

Anti-Freeze Density	Freezing Point
50%	-30°C
55%	-40°C
60%	-55°C



5.4 Cooling and lubrication system

WARNING:When removing the radiator cap tester put a rag on the filler to prevent splash of coolant DO NOT allow a pressure to exceed the radiator cap release pressure.

WARNING:When removing the radiator cap tester put a rag on the filler to prevent splash of coolant DO NOT allow a pressure to exceed the radiator cap release pressure.

● If the pressure drops during 10 seconds, it indicates that there is leakage with the cooling system. In this case, check the complete system and replace the leaking parts or components.

5.4.4 Inspection and cooling of Radiator and Water Hoses Radiator Cap




- Remove radiator cap ①
- Install radiator cap to cap tester ②
- slowly increase pressure to 108kPa and if the cap hold the pressure for at least 10 seconds
- If the cap cannot meet the pressure requirement, replace it.

Radiator Cap Valve Opening Pressure
Standard: 108kPa

Tool: Radiator Cap Tester


Radiator Inspection and Cleaning

- Remove dirt or trash from radiator with compressed air
- Correct the radiator fins with a small screwdriver



Radiator Hose Inspection

- Check radiator hoses leakage or damage. If the hoses are leakage and damaged, replace them
- Check tightening of clamps. Replace the clamps if necessary
- After inspection and cleaning of radiator and hoses, check coolant level. Fill coolant if necessary




5.4.5 Inspection of Fan Motor

- Remove fan motor from radiator
- Turn the vanes and check if they can turn smoothly
- Check fan motor. Make sure that the battery applies 12 volts to the motor and the motor will run at full speed while the ammeter will indicate the ampere not more than 5A. If the motor does not work or the ampere exceeds the limit, replace the motor
- Installation: Apply a little thread locker to the bolts and tighten to the specified torque.

Fan Motor Bolt Tightening Torque:
10N • m


1. Radiator;
2. Radiator Cap;
3. Fan Motor;
4. Mounting Bolt;



5.4 Cooling and lubrication system

5.4.6 Inspection of Water Temperature Sensor

- Place a rag under water temperature sensor 1 and remove it from cylinder head
- Check the resistance of water temperature sensor as illustrated on the right. Connect the temperature sensor 2 to the circuit tester, place it in a vessel with engine oil. Place the vessel above a stove



Tool: ohmmeter, thermometer


5

CFMOTO

- Heat the oil raise the temperature slowly and take the reading from ohmmeter ④ and thermometer ③

Resistance and Water Temperature

Temperature (°C)	50	80	100	120
Resistance (Ω)	154±16	52±4	27±3	16±2




- Installation: Apply a little thread locker and install it to the cylinder head by tightening to the specified torque

Water temperature Sensor Tightening Torque: 16N • m

WARNING:

Avoid sharp impact on temperature sensor; Avoid contact of temperature sensor with thermometer or vessel



- After installation, check the coolant level. Fill coolant if necessary



5.4.7 Inspection of Thermostat

- Remove thermostat housing
- Remove thermostat
- Check thermostat pellet for cracks. If necessary, replace it.
- Test the thermostat according to the following steps:
 - ☆ Pass a string between thermostat flange as illustrated on the right

5.4 Cooling and lubrication system

☆ Immerse the thermostat in a beaker with water. Make sure the thermostat is in the suspended position without contact to the vessel. Heat the water by placing the beaker above a stove and observe the temperature rise on a thermometer

☆ Take the temperature reading from thermometer when the thermostat valve opens.

Thermostat Valve Opening

Temperature: $71^{\circ}\text{C} \pm 3^{\circ}\text{C}$

Tool: Thermometer

☆ Keep heating the water to raise the water temperature. When the water temperature reaches the specified valve, the thermostat valve should have been lifted by 3.5mm~4.5mm




☆ If thermostat valve opening temperature or thermostat valve lift does not reach the standards, replace it.

● Install thermostat: reserve the removal procedure for installation

☆ Apply coolant to the rubber seal of thermostat

☆ Install thermostat housing. Tighten to the specified torque:

Tightening Torques: 10N • m



5.4.8 Water Pump

Water pump cover


Water pump cover is on engine left crankshaft cover

Removal and Disassembly

WARNING:

When engine is hot, DO NOT remove radiator cap or loose coolant discharge plug screw to prevent from injury.

- Drain coolant
- Remove radiator water outlet from water pump cover
- Remove mounting bolt from water pump cover
- Remove water pump cover



Illustration

1. coolant drain plug screw
2. Seal gasket
3. bolt
4. water pump cover

Inspection of water pump cover

- Check water pump cover seal gasket, if necessary, replace it

Installation of water pump cover

- Install water pump cover reverse the removal procedure for installation

WARNING:

Install seal gasket in the groove of water pump cover correctly to prevent from leakage.





Illustration:

1. seal gasket

Removal of water pump impeller, water seal, oil seal, bearing and gears

Drain coolant

- Remove water pump cover
- Remove left crankshaft case housing cover
- Use proper clipper to remove the retainer ring and discard it
- Remove water pump gears
- Remove bearing from water pump shaft




1. Water pump impeller
2. Retainer ring
3. Bearing

5.4 Cooling and lubrication system

- Push water pump shaft to remove impeller from left crankshaft housing cover.

WARNING:

Avoid damaging water pump impeller.




- Remove seal ring ① and rubber seal ②
- Use flat head screwdriver to pry locate ring of seal.

NOTE:

The seal does not need to be removed, if there is no abnormal condition.

WARNING: DO NOT reuse a removed locate ring of seal.



5

1. locate ring
2. flat head screwdriver


- Leave a rag on water pump body
- Use flat head screwdriver to remove oil seal

NOTE:

The oil seal does not need to be removed, if there is no abnormal condition.

WARNING:


DO NOT reuse a removed oil seal



- Remove bearing with special tool.

NOTE: The bearing does not to be removed, if there is no abnormal condition noise.

WARNING: DO NOT reuse a removed bearing.



CFMOTO

Inspection of Water Pump


☆ Bearing

- Check the bearing clearance by hand, while it is still in the water pump body.
- Turn inner race of bearing to check for abnormal noise and smooth rotation.
- Replace the bearing, if there is abnormal condition



☆ Water Seal

- Check water seal for damage, pay attention to the seal surface
- In case of leakage or damage, replace the water seal. If necessary, also replace the seal ring



☆ Oil Seal

- Check oil seal for damaged. Pay attention to the oil seal lip.
- In case of damage or leakage, replace the oil seal.




☆ Left crankshaft housing cover

- Inspection left crankshaft housing cover and bearing, the connect surface of water seals. If necessary, replace new parts.

☆ Water Pump Impeller

- Check the impeller and shaft for damage.
- If the impeller or shaft are damaged, replace a new part.



5.4 Cooling and lubrication system

Assembly and Installation of Water Pump

- Install oil seal with special tool

Tool: Oil Seal Installer
(172MM-080005-923-001)

NOTE: The stamped mark on the oil seal faces outside.

- Apply a little grease to the oil seal lip
- Install new bearing with special tool

Tool: Bearing Installer
(1P72MM-081001-923-001)

NOTE: the stamped mark on the bearing faces outside



- Install new water seal with proper wrench

NOTE: Apply sealant to “A” side of water seal



- Install seal ring to impeller
- Clean off the oil and grease from water seal and install into the impeller

NOTE: “A” side of water seal faces impeller

- Apply grease to impeller shaft
- Install impeller shaft to left crankshaft housing cover



5



CFMOTO

- Install ring to water pump shaft




- Install water pump cover and tighten the bolts and bleed bolt
Water pump cover bolts tightening torque:
6N • m



- Check impeller for smooth turning
- Install left crankshaft housing cover (5-89)


- Connect water tubes
- Inject coolant(refer to 5-32)



5.4 Cooling and lubrication system

5.4.9 Illustration of Engine Lubrication System

1. Engine oil pump
2. Decompressor
3. Oil Filter
4. Camshaft
5. Oil path
6. Crankshaft connecting rod



5

CFMOTO

Add oil to the engine parts (piston, cylinder body, camshaft and so on) which run at high speed.

Engine lubrication should be special oil.

Engine oil is not only used as lubrication, but also used to wash, rustproof, seal and cool.

5.4.10 Inspection of Lubrication system

(Refer to 5.2.8 inspection of lubrication system)

5.4.11 Inspection of engine oil pump

(Refer to 5-78)

6 Vehicle chassis

Maintenance information	6-2
6. 1 Troubleshooting	6-3
6. 2 Front wheel	6-3
6. 3 Brake system.....	6-4
6. 4 Front suspension system.....	6-8
6. 5 Steering system.....	6-11
6. 6 Front & Rear differential	6-18
6. 6. 1 Maintenance information.....	6-18
6. 6. 2 Front & Rear differential disassembly and installation	6-20
6. 6. 3 Front differential exploded view.....	6-21
6. 6. 4 Inspection After Front Differential Disassembly.....	6-22
6. 6. 5 Front Differential Assembly and Adjustment.....	6-23
6. 6. 6 Rear differential exploded view.....	6-26
6. 6. 7 Inspection After Rear Differential Disassembly.....	6-27
6. 6. 8 Rear Differential Assembly and Adjustment.....	6-28
6. 7 Drive shaft	6-31
6. 7. 1 Maintenance information for CV drive shaft and Front & Rear drive shafts.....	6-31
6. 7. 2 Disassembly and Installation for CV drive shaft and Front & Rear drive shafts.....	6-32
6. 7. 3 Front & Rear CV drive shaft exploded view.....	6-34
6. 7. 4 Inspection After Front & Rear CV drive shaft Disassembly.....	6-35

MAINTENANCE INFORMATION

Operation Cautions

- Securely support the vehicle when doing check and repair the wheel and suspension.
- The overhaul or inspection of Light, meter, switch refers to related sections.
- Do not overexert on the wheel, avoid any damage to the wheel
- When removing tire, use the special tire lever and rim protector

Overhaul standard

Item		Standard	Service limit
Wheel rim	Axial run out	0.8mm	2mm
	Radial run out	0.8mm	2mm
Tire	Tread Depth		3mm
	24 inch pressure	Front: 56kPa(0.57kgf/cm ²) Rear: 42kPa(0.43kgf/cm ²)	
	25 inch pressure	Front and rear:45kPa (0.46kgf / cm ²)	
Front break	Break lever clearance	0mm	

Tightening Torque

Nut, Steering Tie-Rod	GB9457 M10×1.25	(30~40) N·m
Lock Nut, Steering stem	GB6187 M14×1.5	(100~120) N·m
Bolt, front brake disc	901-08.00.03	(25~35) N·m
Bolt, front brake caliper	GB5789 M10×1.25×20	(35~45) N·m
Bolt rear breaking disc	901-08.00.03	(25~35) N·m
Bolt rear caliper	GB5789 M10×1.25×30	(35~45) N·m
Wheels nut	GB9459 M24×2	(320~350) N·m
Bolt, front shock absorber	GB5789 M10×1.25×50、GB5789 M10×1.25×70	(40~50) N·m
Mounting nut, rim	9010-070002	(70~80) N·m
Bolt, A-arm	GB5789 M10×1.25×70	(40~50) N·m

Special tools:

air wrench	S17	air wrench	S15
air wrench	S13	air wrench	S35
allen wrench	M8	allen wrench	M6
allen wrench	M5	allen wrench	S10
ratchet wrench	S13	ratchet wrench	S15
open end wrench	S8-S10	open end wrench	S14-S17
open end wrench	S18	slotted screwdriver	
cross screwdriver		nipper pliers	
hammer		outside spring pliers	

Assemble tools shaft

6.1 Troubleshooting

Handle bar heavy

- Upper thread is over tightened
- Steering bearing is damaged or worn
- Inner & outer bearing races are damaged or not well tightened.
- Steering stem is distorted
- Low tire pressure
- Tire worn

Excessive handlebar free play

- Steering bearing is damaged or not well tightened
- LH and RH shock absorber not matched
- Deflected tires
- Deformed frame
- Worn tire
- Shaking wheel bearing

Severe front wheel runout

- Wheel rim distorted
- Faulty wheel bearing
- Faulty tires
- Improper balance of wheels
- Improper tightening of wheel shaft

Wheel cannot turn freely

- Faulty wheel bearing
- Wheel installed improperly
- Brake drag

Front suspension too soft

- Weakend front shock absorber
- Tire pressure is too low

Front suspension too hard

- Faulty front shock absorber
- Tire pressure is too high

Noise from front shock absorber

- Faulty front shock absorber
- Loosened tightening parts of front shock absorber

Poor brake performance

- Faulty brake adjustment
- Stained brake disc
- Brake pads worn

6.2 Front wheel

Removal

Securely support front wheels, Make sure no forces on the wheel

Remove wheel cap
 Remove the 4 wheel nuts no.1;
 Remove front wheel.

Inspection


Rim

Check rim for damages, deformation, nicks.
 If any abnormal condition has been found,
 replace it.

Service limit: 2.0 mm (Axial)
 2.0 mm (Radial)

Install


Press rim into tire with special tool;
 Fix wheel on the hub; Wheel nuts tightening
 Torque: 70N·m~80 N·m



FRONT WHEEL HUB

Removal

Remove front wheel
 Remove front brake caliper 6
 Take out cotter pin 2 Remove rim axle nut no. 3
 Remove brake disc and hub together;
 Remove the 4 brake disc bolts no. 8
 Remove front wheel hub no.4



Install

Reverse the removal procedure for installation

Tightening torque of axle nut: 320N·m~
 350N·m

Tightening torque of brake disc bolts no.8
 : 25N·m~35N·m

(Apply screw locker)


Note: Rear wheel is the same as the front.

6.3 FRONT BRAKE SYSTEM

Front Brake Caliper

Removal

Remove front wheel
 Remove the two bolts 2;
 Remove caliper 1.



Inspection

Check any cracks of brake calipers and oil
 leaks from tightening areas. Replace if neces-
 sary


Tightening torque of brake caliper bolt

35N·m~45N·m

(Apply thread locker)

Brake pads

Remove main sliding shaft of brake pads
 with Allen wrench;
 Remove brake pads;



6 Vehicle chassis

Remove brake pads;
Measure thickness of brake pad friction surface no.4, if it is less than 1mm, then replace both pads at the same time.

BRAKE DISC

Removal

Remove front wheel. Remove brake calipers
Remove brake disc and wheel hub from vehicle.

Remove the 4 brake disc bolts 1 shown in the right picture, then remove brake disc 2.

Inspection:

Thickness of brake disc: If less than 4 mm, replace it.

Install

Reverse the removal procedure for Installation.

Tightening torque of brake disc bolts:
: 25N · m ~ 30N · m

FRONT BRAKE MASTER CYLINDER

Removal

Remove bolt 2

Separate the master cylinder 1 of front brake from handlebar.

Attention:

Do not hang the master cylinder by brake line, Keep master cylinder in place (not inclined) while installing it to avoid air entering brake line. Keep brake line routed properly (refer to Chapter1) and ensure it is not kinked. After installation of brake system, check brake performance.

MASTER CYLINDER

Removal

Remove expansion screw 8, remove master cylinder 9

Remove footrest board, remove bolt 5.

Remove bolt 7

Remove cotter pin and pin roll 3



Remove master cylinder 4 and fluid reservoir 6 from vehicle

Install




Reverse the removal procedure for installation

Attention

In order to avoid air entering master cylinder, keep it in place while installing it.



6



CFMOTO

Keep brake line routed properly (refer to Chapter 1) and ensure it is not kinked. After installation, check brake performance.

T-FITTING

Removal

Remove bolt no.1 and T-fitting 2.

Install

Reverse the removal procedure for installation.

Attention: Keep brake line routed properly (Refer to Chapter 1) and ensure it is not kinked.

After installed, please check the breaking performance. If front and rear breaking system cannot working together. Please check the connectors to see if trouble comes.

REAR BRAKE CALIPER

Removal

Remove the rear wheel

Remove bolt 3 and then disassemble rear brake caliper 4

Inspection

Inspect the caliper to see the cracks or leaking. Replace the part if so.

Install

Reverse the removal procedure for installation.

Caliper mounting bolt 2 torque: $35\text{N} \cdot \text{m} \sim 45\text{N} \cdot \text{m}$

(With screw locker)

Attention: Keep brake line routed properly (refer to Chapter 1) and ensure it is not kinked.

After installation, check if 4-wheel brake lever or brake pedal can control front brake. Maintain brake fluid level between UPPER and LOWER, if necessary; add DOT 4 fluid (CFMOTO recommended) into brake fluid reservoir. Check brake light and switch.

Rear breaking pad





Removal

Remove the breaking caliper.

Remove the breaking pad holding shaft.

Remove the breaking pad

See the thickness a of the pad. If thickness a is thinner than 1.5mm. Replace all the breaking pad.



6 Vehicle chassis

Rear breaking disc.

Removal


Remove the rear wheel
Remove the rear wheel caliper
Remove the disc 2 and rear wheel bracket 1 together by loose four mounting bolts 3.
Separate the breaking disc 2.

Inspection:

Breaking disc service limit: 4mm
If the disc is thinner than standard. Replace the disc.

Install


Install the disc by mount the bolts up
Breaking disc mounting bolt
torque:25N·m~30N·m



Parking breaking system

Removal

Loose the adjusting nut 4 on breaking caliper. Remove one side of the parking breaking cable.
Loose two screws 5 to remove the cable box 6.
Loose two bolts 9. To remove the parking lever 7 from the handle bar.
Remove the parking break cable 8





Inspection:

The cable should have no sharp points, with lubricating grease inside and working smoothly.

Install:

Reverse the removal procedure for installation



CFMOTO



6. 4 FRONT SUSPENSION

Front LH Suspension


Removal

ATTENTION: Do not remove left and right suspension at the same time, Otherwise, vehicle may tip or fall.

- Park the vehicle on a level ground and securely support the front part of vehicle
- Remove LH front protector of suspension
- Remove front wheel; Remove brake caliper
- Remove front wheel hub
- Remove bolts 1 and nuts no.2 of front LH shock absorber 3
- Remove the bolt on upper A-arm (LH) and the nut no.4;
- Remove the cotter on upper A-arm(LH) and nut no.6;
- Remove upper A-arm(LH) no.5;
- Remove the cotter & locknut no.9 on the steering rod;



6 Vehicle chassis



- Loose up the rocker arm mounting bolt 4
- Remove the ball pin cottor and loose the nut 6
- Remove the rocker arm 5
- Remove the cottor on steering lever and loose the nut 9
- Remove the rocker mounting bolt and nut 7
- Remove the ball pin locking bolt 10
- Remove the lower rocker arm LH 8
- Pull steering joint from CV shaft.

This vehicle has different suspension equipment for different customers. For here, we introduce basic style. Other equipment can follow the way mentioned to maintainance.

- 1、 Bolt. 2、 Suspension fender LH. 3、 Lower ball pin assy. 4、 Lower A-arm assy LH. 5、 Bolt. 6、 Cushion collar protecting hood. 7、 Cushion

Front rocker arm assy LH

Removal

- Remove LH absorber 1
- Remove the bolt 18 & the nut 2
- Remove the rim, brake caliper & rim stand before remove the absorber;
- Remove the steering rod before remove the bolts
- Pull out the steering knuckle from drive shaft before remove the LH A-arm

- collar assy. 8、 Bolt. 9、 Bolt. 10、 Snapping for shaft. 11、 Front brake flap. 12、 Bolt. 13、 Rim bearing. 14、 Snapping for hole. 15、 Left steering knuckle. 16、 Cottor 17、 Slotted nut 18、 Upper ball pin. 19、 upper A-arm assy. 20、 Front absorber. 21、 Bolt. 22、 ϕ 10 Washer. 23、 Bearing kit, fixing end. 24、 Midium shaft. 25、 Front CV shaft. 26、 RH BEARING KIT, MOTION END.

Install

Reverse the removal procedure for installation. As for removal, installation and check procedure of front shock absorber (RH), refer to front shock absorber (LH)

Attention: This vehicle have totally 8 suspension Aarms, and the way of removal, disassemble, inspection, installation are all the same, so this manual will only introduce removal, disassemble, inspection, installation of upper A-arm (LH) & lower A-arm. As for other arms, please refer to upper A-arm (LH) & lower A-arm.

6

CFMOTO

Removal LH A-arm

Check upper & lower A-arm

Remove front Lower A-arm (LH) 3

Remove circlip 2 (model no:GB894.1 34)

Remove top ball pin 1.

Make sure the grease in ball pin is good (greese type: No.2, lithium grease GB7324-87). Make sure the dust boot of ball pin is not damaged or aging, otherwise, replace it.

Remove the cushion hood 5 and check it if any damage or aging, replace it if necessary.

Remove the LH lower A-arm 2

Remove the circle for shaft 3 (type: GB894.1 34)

Remove the lower ball pin 1.

Check lower ball pin 1 if it can move freely and also check its clearance. If it cannot move freely or too big clearance, replace it
Check the grease in the ball pin to make sure it's good (greese type: No.2 lithium grease G B 7324- 87)

Check dust boot of ball pin if damaged or aging. Replace it if have any above problem.

Remove the cushion hood 5 and check it if any damage or aging, otherwise, replace it.




Install

Use special tool to press ball pin into A-arm.

Reverse the removal procedure for installation.

Note:Upper and Lower A-arms should not vibrate after installation, otherwise replace cushion hood 5

Check the left knuckle; Remove the left knuckle 3; Remove circle 1 (type:GB893. 1 55)Use special tool to remove hub bearing 2 (type:DAC3055W) Check hub bearing if any damaged and move freely, or big clearance. Replace it if necessary.



6 Vehicle chassis

6.5 Steering system

Handlebar (See pic 061101)

Front handbrake pump handguard

Removal

Remove handguard 1

Install

Reverse the removal procedure for installation



061101

Winch control switch (See pic 061102)


Removal

Remove bolt 2;

Remove control switch 1;

Install

Reverse the removal procedure for installation



061102

Right handlebar switch assy

(See pic 061103)

Removal

Remove bolt 1;

Remove right handlebar switch assy 2.

Left handlebar switch assy (See pic 061104、061105)

Remove bolts 3;


Disconnect the connectors;

Remove left handlebar switch connector 4;


Disconnect right handlebar switch connector 5

Installation L&R handlebar switch assy


Reverse the removal procedure for installation



061103



061104



061105

Rearview mirror


Removal

Slide sleeve no 1; Loosen the nut no.2 with counterclockwise. Remove rear view mirror no.3 in counterclockwise Direction.

NOTE: As for rear view mirror (LH), it is right hand threads, so remove it by turning it counter-clockwise.

Unscrew nut in clockwise direction and unscrew rear view mirror (RH) to remove

NOTE: As for rear view mirror (RH), the threads are left hand, so remove it by turning it counter-clockwise




Install

Reverse the removal procedure for installation

Handlebar

Removal

Remove handguard; Remove left & right handlebar switch;
Remove winch switch;
Remove parking lever;
Disconnect the hand brake master cylinder from handle bar;
Remove left & right handguard;
Remove bolt no.1;
Remove alu.cap no.3;
Remove handle bar no.2.



Install

Reverse the removal procedure for installation Handlebar alu.cap installation bolt M8X 55

Torque: 30N·m~40N·m(3.0kgf·m~4.0kgf·m)

Note: Main cable, Throttle Cable, brake tube, other cable installation pls follow the drawing.

6 Vehicle chassis


Throttle Cable

Removal

- Remove screw 1
- Remove right handlebar cover 4
- Remove throttle cable connector 5
- Remove the throttle joint 3
- Remove the throttle cable no.2


Install

Reverse the removal procedure for installation.



Steering system

- 1、 Bolt M8 × 55. 2、 Alum cover
- 3、 O-Ring. 4、 Bolt
- 5、 Steering stem. 6、 Bolt
- 7、 Steering bearing seat 8、 Nut.
- 9、 Cottor
- 10、 Nut M10 × 1.25
- 11、 Washer. 12、 Steering rod.
- 13、 Steering stem busher.
- 14、 Locker washer. 15、 Linking
- 16、 Busher 17、 Steering shaft bu
- 18、 Steering shaft inner bush.
- 19、 Outer ball bearing




6

Steering shaft

Removal

- Remove handlebar cover;
- Remove plastic parts;
- Remove front wheel;
- Remove handlebar;
- Remove rear brake lever;
- Remove hand brake master cylinder;
- Remove connector of handlebar switches;
- Remove steering rod;
- Hammer out the lock washer no.1 by screw driver and hammer;
- Remove bolt no.2;
- Remove bolt no.6;
- Remove nut no.8;
- Remove cotter no.9;
- Remove nut no.10;
- Remove steering rod no.12;
- Lift the steering shaft no.3;
- Remove the steering shaft.




CFMOTO

Install

Reverse the removal procedure for installation

Note: After installation, be sure to check steering agility, cable installation according to chapter 1, be sure steering arm in the middle, be patient when install steering shaft, then lock other parts.



EPS steering system

- 1、 Bolt M8 × 55
- 2、 Handlebar alum cover.
- 3、 O-ring.
- 4、 Steering shaft outer busher.
- 5、 Steering shaft inner busher.
- 6、 EPS steering shaft assy.
- 7、 Busher
- 8、 Linking plate assy
- 9、 lock washer.
- 10、 Bolt M8 × 75
- 11、 Steering stem busher
- 12、 Bolt
- 13、 Washer.
- 14、 bearing kit, steering shaft.
- 15、 EPS driver.
- 16、 EPS mounting plate
- 17、 Bolt
- 18、 Bolt
- 19、 Bolt
- 20、 EPS steering arm.
- 21、 Cottor
- 22、 Nut
- 23、 Washer
- 24、 Steering tie rod
- 25、 EPS controller
- 26、 Bolt.

Removal

- Remove the handlebar cover
- Remove the plastic parts

- Remove the front wheels
- Remove the handle bar assy
- Remove the rear parking break handle.
- Remove the hydraulic handbreaking pump.
- Remove all the switches on handlebar.
- Loose the steering rod nut to remove the rod
- Loose four bolts 17
- Use screw driver and hammer to thump the locker washer 1 flat.
- Remove the bolt 2
- Loose the bolt 19
- Remove the steering rocker arm 20
- Loose the bolt 12
- Remove the steering joint 14
- Pull up the steering stem 6 to remove the stem.

Install

- Reverse the removal procedure for installation.

6 Vehicle chassis

Note:after installation, be sure to check steering agility;cable installation according to chapter 1,be sure steering arm in the middle,be patient when install steering shaft, then lock other parts.

Steering stem:Be patient to install the steering stem. Make sure the steering angle is totally the same each sides before lock up.

EPS Driver

Removal

- Remove plastic parts
- Remove front wheel
- Remove handlebar
- Remove EPS steering shaft
- Loosen connector 1
- Remove 4 bolt 17
- Remove steering stem plate 3
- Remove bolt 19
- Remove steering arm 20
- Remove bolt 18
- Remove EPS driver 2

Install

Reverse the removal procedure for installation.

Note:Cable installation according to chapter 1,be sure steering arm in the middle, then install EPS driver, be patient when install steering shaft, first to fix one side of the steering shaft on EPS driver, then install EPS steering shaft. Make sure the same steering angle both on the left & right, then lock other parts.


EPS Controller

Removal

Remove plastic parts; Loosen the connectors. Remove bolts no.26; Remove EPS controller no.25;

Install

Reverse the removal procedure for installation.



6

CFMOTO

EPS steering system

The EPS indicator light works when the vehicle is equipped with EPS system ①. Under normal conditions, EPS indicator light is on ② after turning power switch on. EPS doesn't work; EPS indicator light is off after engine is started. EPS begins to work.)

NOTE: Spare parts in the EPS system cannot be taken apart by user. If there is something wrong with the EPS system expect track junction problem, please contact dealer.

Appendix 1: EPS system fault code table

(EPS indicator light on the instrument flashes when fault occurs. At that time, do not cut the power off but observe the frequency of flashing and record the orderliness in a period. Then please check with this table to find troubleshooting.)

(EPS indicator light represents fault code. Every fault code consists of two digits. Each digit means long-flashing times (the first number) and short-flashing times.(the second number). Long-flashing lasts two seconds while short-flashing lasts a second, interval lasts a second. Repeat the process after three second with indicator light is off.)

Code	waveform	diagnosis	solution
21		Main sensor is disconnected	Check sensor harness
22		Output exception of the main sensor (Voltage is too high or low)	Check sensor harness
23		Deputy sensor is disconnected	Check sensor harness
24		Output exception of the deputy sensor (Voltage is too high or low)	Check sensor harness
25		Discrepancy of the main and deputy torque is too large	Check sensor harness
26		Deviation of phase compensation of main torque sensor is over the limit	Replace EPS controller
32		Main sensor is disconnected	Check sensor harness
33		Output exception of the main sensor (Voltage is too high or low)	Check sensor harness
34		Deputy sensor is disconnected	Check sensor harness
35		Output exception of the deputy sensor (Voltage is too high or low)	Check sensor harness
36		Discrepancy of the main and deputy torque is too large	Check sensor harness

6 Vehicle chassis

Appendix 2: EPS malfunction analysis and solution

No.	Failure Phenomenon	Probable Reason	Troubleshooting
1	Steering without assistance	<ol style="list-style-type: none"> 1、 connectors of wire is bad contact 2、 The fuse blew out 3、 Relay damage 4、 The controller、 motor or sensor is damaged 	<ol style="list-style-type: none"> 1、 Check whether wire connectors are fully inserted 2、 Replace the fuse (30A) 3、 Replace the relay 4、 Contact with suppliers and replace it
2	Power don't weighs the same for left and right	<ol style="list-style-type: none"> 1、 The median output voltage have deviation 2、 controller、 motor or sensor is damaged 	<ol style="list-style-type: none"> 1、 Disconnect motor connectors, loosen the sensor adjustment screw, adjust the sensor position to keep the voltage in $1.65V \pm 0.05V$ 2、 Contact with suppliers and replace it
3	when system is on, the steering wheel swings on both sides	<ol style="list-style-type: none"> 1、 Motor is mounted backwards 2、 controller or sensor is damaged 	<ol style="list-style-type: none"> 1、 Exchange the position of (thick line) red line and black line at the motor terminal 2、 Contact with suppliers and replace it
4	Steering becomes heavy	<ol style="list-style-type: none"> 1. Battery have power loss 2. Motor damage (power reduction) 3. air pressure of the tires (front) is insufficient. 	<ol style="list-style-type: none"> 1、 Charge 2、 Contact with suppliers and replace it 3、 Inflate tires
5	System has noise	<ol style="list-style-type: none"> 1、 Motor damage 2、 Gap of lower steering shaft assembly or mechanical steering assembly is too large 3、 Installation of lower steering shaft assembly or mechanical steering assembly is unfirm 	<ol style="list-style-type: none"> 1、 Replace 2、 Replace 3、 Check whether the installation screw is tight, reinforcement

6

CFMOTO

6. 6 Front & Rear Axle

6. 6. 1 Front & Rear axle maintain info

lubricating period				
Item	Type	capacity	interval	
			initial	next
Front axle	SAE15W/40SF or SAE80W/90GL-4	Initial 0.33L	350km	5000km
Rear axle		Initial 0.20L		

Tightening torque table

Item	QTY	Specification	Torque (N·m)	Remark
Front axle case bolt	5	M8×25	25	
Front /rear axle motor bolt	4 each	M8×18	8	
Front/rear axle pin bolt	1 each	M8×10	13	
Front/rear axle bolt	1 each	M10×1.5×20	50	With fastening glue
Diff. bolt, front axle	8	M8×1×22	45	With fastening glue
Oil bolt. Front/rear axle	1 each	M14×1.25 ×12	25	
Drain bolt front/rear axle	1 each	M14×1.25 ×12	25	
Bearing seat bolt, front axle	4	M8×25	25	
Bearing seat bolt, rear axle	4	M8×25	25	
Rear axle case bolt	8	M8×25	25	
Diff. bolt, rear axle	8	M10×1.25 ×22	45	With fastening glue

● Inspection & maintain

If any one of below problem happens, pls check and repara the front & rear axle.

Problem descriptions	causes
1. run stable moving during accelerating.decerating or constant speed.	A.bearing broken B.gear clearance over/under size C.gear severely worn
2. abnormal sound in front or rear axle.	D.gear blocked E.drive shaft broken
3. engine power transmission failure to front or rear wheels.	F.lack of lubricant G.foreiggn matter in front or rear gear

Note: A , B , C problem is difficult to judgement, need detail fault phenomenon to analyse.

Disassemble the axle if necessary.

6

Observation and judgement

1.Never ignore abnormal sound

a. Abnormal sounds during accelerating,decelerating ,if it As not engine problem.so possibly the gear worn;

b. Constant abnormal sounds during accelerating or decelerating might because by gear clearance wrongly adjusted during assembling;

Note: Wrong assembly or adjustment of the front or rear axle will aggravate gear worn and block.

c. Slight sounds will be noticed during low-speed driving and should not be hear during high-speed driving. This is caused by gear block

Warning If the vehicle has the trouble mentioned. Please stop the vehicle immediately to check. Or it will cause accident.

2. Check lubrication

Regularly check the consumption of lubrication is normal or not, and check if the metal particle content in lubrication oil is normal.

3.Check lubrication leakage

a.Check if any oil stains on front or rear axle.

b.Check if any oil stains around parking lot.

c.Check if any oil splash.


Judge the pb is gear box or oil seal leakage, then replace the broken part.

6.6.2 Front & Rear Axle disassembly and installation


Removal: Hanging the vehicle firmly

Remove the front and rear wheel,A-arm,(see chapter 6.2 and 6.3)

Remove the bolt,nut(item 1 , item 2) , see below pic.



Remove the bolt,nut (item 1、 item 2) , see below pic




Installation: Reverse the removal procedure for installation.

Front axle bolt(GB5789 M10 × 1.25 × 90) torque:40N • m~50N • m

Front, Rear axle bolt(GB5789 M10 × 1.25 × 110) torque:40N • m~50N • m

6 Vehicle chassis

6.6.3 Front axel disassemble



6

No.	Item	Qty	No.	Item	Qty
1	Bolt M10 × 1.25 × 20	1	19	Circlip 55	1
2	Wsher 10×27×4	1	20	Bearing 6006	1
3	coupler	1	21	Stooped screw M8 × 10	1
4	O-seal ring 25 × 2	1	22	Pin shaft	1
5	Oil seal 35 × 50 × 7	1	23	Drain bolt M14 × 1.25 × 12	1
6	Bearing 33005	1	24	Gasket 14	2
7	Bolt M8 × 25	9	25	Front axle case	1
8	Bearing seat	1	26	Bolt M14 × 1.25 × 12	1
9	O-seal ring 55 × 2.5	1	27	Oil seal 24 × 38 × 8	2
10	Adjust washer	1~3	28	Fork	1
11	Adjust washer 32 × 25.4	2	29	Rack	1
12	Adjust gasket, bevel gear	0~1	30	O-seal ring 67.5 × 2	1
13	Bearing 32006	1	31	Motor assy, front axle	1
14	Drive bevel gear, front axle	1	32	Bolt M6 × 18	3
15	Differential	1	33	Adjust washer 54.5 × 43	1~2
16	Adjust washer 79.5 × 68	1~2	34	O-seal ring 130 × 2	1
17	Spline	1	35	Cover, Front axle case	1
18	Spline	1			

CFMOTO

6. 6. 4 Inspection after front axle disassembly

● Check if there is damage or crack on the front differential gear casecover and bearing assembling hole is OK, replace casecover if necessary.

● Check if front axle bearing clearance OK or turning stable and roll way, steel ball, needle and plate are OK, replace bearing if necessary. (using special tools)

● Check if oil seal lips and O-ring shape are OK, replace if necessary

● Check cylindrical surface of front axle and oil seal lips, replace broken parts if necessary

● Check drive pinion gear and differential gear, inspect worn surface, replace broken if necessary;

● Check driven gears surface gear (center) differential, bracket differential wearing situation on the differential gear assembly, replace parts if necessary.

● Check inside and outside spline washer wearing status in front axle, replace parts if necessary.

● Inspect the steering rack, replace if any trouble comes out.

● Check gear motor working status, replace with new parts if necessary.

Gear motor inspection must be carried out with special equipment or acted on the vehicle

● Check other parts, replace broken parts if necessary.

6 Vehicle chassis

6. 6. 5 Front axle assembly and adjustment


● Drive bevel gear of front axle assembly
 a During assembly, by adjusting gasket "7" and "18" to ensure axial play is less than or equal to 0.05.

Item 1 tightening torque 50 N.m

Note: Apply engine oil on oil seal, bearing and drive clutch, during assembly. Apply thread locker on Item 1.

Shim 11 thickness				
2.10	2.20	2.30	2.40	2.42
2.44	2.46	2.48	2.50	2.60
2.70	2.80	2.90	3.00	

Adjust washer "8" thickness 0.3




6

● Differential gear assembly

M8 × 1 × 22 Torque: 45N • m

Note: During assembly, apply engine oil on bearing and differential gear. Use proper shim to ensure gears rotate smoothly. Differential driven gear axial play is 0.1~0.4. Semiaxis gear axial play is 0.1~0.4. Apply thread glue on bolt M8 × 1 × 22.

Shim thickness	0.1	0.2	0.3	0.4
	0.5	1.0		



CFMOTO

● Front axle assembly and adjustment
As illustration shown:

Tightening torque	
Item “7”	25N • m
Item “21”	13N • m
Item “32”	8N • m
Injecting oil bolt	25N • m
Draining oil bolt	25N • m

a. During assembly, use proper locating distance adjusting shims ”10 ” and adjusting shims “16 “and “33 “ thickness to adjust the locating distance and gear clearance between front axle drive bevel gear and driven bevel gear, and ensure gear contact properly. Gear clearance 0.10 ~ 0.25.




Adjust washer 16.33 thickness	0.1 0.2 0.3
	0.4 0.5 1.0

washer 10 Thickness	0.2 0.3
---------------------	---------

b. The clearance measurement of bevel gear as right illustration: install assistant measurement tool, tighten fixing bolt (M10 × 1.25 × 60) and ensure 37mm distance between measuring point and the center of assistant measurement tools. And rotate assistant measurement tool forward and reverse and read the data

standards: 0.17~0.34


c. During front axle assembly, rack, fork and rectangular sleeve should abut upon following the direction of the arrow as shown.



6 Vehicle chassis

d Before front axle motor assembly , front motor should be rotated to the diff-lock position by using special instruments or vehicle control circuit


e During assembly of front motor and front axle motor, on the premise of ensuring c, d, use $\phi 5$ mandrel positioning as shown to assemble.



6

CFMOTO

6. 6. 6 Rear axle exploded view



No.	Name	Qty	No.	Name	Qty
1	Bolt M10×1.25×20	1	23	Plant gear shaft short	2
2	Washer 10×27.5×4	1	24	Shaft gear RH	1
3	Couple	1	25	Wearing washer	4
4	O-ring 25×2	1	26	Gear(center) differential	4
5	Oil 35×50×7	1	27	Plant gear shaft	1
6	Bearing 33005	1	28	Cross bushing	1
7	Bolt M8×25	12	29	Gear LH shaft	1
8	Bearing seat	1	30	Guide pin 8×30	3
9	O-ring 55×2.5	1	31	Differential	1
10	Adjusting washer	1~3	32	Rectangluar sleeve	1
11	Washer 32×25.4	2	33	Rectangluar sleeve 62	1
12	Bolt 32006	1	34	Bearing 16007 GB/T276	1
13	Bevel gear comp rear axle	1	35	Case rear axle	1
14	Bolt M10×1.25×22	8	36	Drain bolt,magnetic M14×1.25×12	1
15	Adjusting washer 61×50.5	4~6	37	Oil seal 35×58×5	1
16	Bearing 32910	2	38	O-ring 67.5×2	1
17	O-ring 141×2.4	1	39	Fork	1
18	Cover rear axle case	1	40	Rack	1
19	Oil seal 24×38×8	1	41	Motor assy, Front axle	1
20	Bolt M14×1.25×12	1	42	Bolt M6×18	3
21	Washer 14	2	43	Pin shaft	1
22	Gasket semi axis gear	2	44	Fixing bolt M8×10	1

6. 6. 7 Rear axle inspection after disassembly

- check if there is damage or crack on the rear differential gear casecover and bearing assembling hole is OK, replace case cover if necessary;
- check if rear axle bearing clearance is OK or turning stable and roll way, steel ball, needle and plate are OK, replace bearing if necessary; (using special tools)
- check if oil seal lips and O-ring shape are OK, replace if necessary;
- check cylindrical surface of rear axle and oil seal lips, replace broken parts if necessary;
- check drive pinion gear and differential gear, inspect worn surface, replace broken if necessary;
- check driven gears surface gear (center) differential, bracket differential wearing situation on the differential gear assembly, replace parts if necessary;
- check inside and outside spline washer wearing status in rear axle, replace parts if necessary;
- check gear motor working status, replace with new parts if necessary; gear motor inspection must be carried out with special equipment or acted on the vehicle;
- check other parts, replace broken parts if necessary;

6. 6. 8 Rear axle assembly and adjustment

● Assemble rear axle as left illustration

Adjust the clearance by using adjusting pad "11" to make sure "13" working smooth and clearance is less then 0.05.

Item 1 tightening torque: 50N • m

Note: Apply engine oil on oil seal, bearing and drive clutch, during assembly. Apply thread locker on Item 1.

Thickness of adjusting pad 11

2. 10	2. 20	2. 30	2. 40	2. 42
2. 44	2. 46	2. 48	2. 50	2. 60
2. 70	2. 80	2. 90	3. 00	

● Differential assembly

Item 14 tightening torque: 45N • m



Use proper item 22 to ensure gears parts 24, 26, 29 rotate smoothly. Parts 24, 29 axial play is 0.1~0.3

Apply thread locker on item 14

Note: Apply engine oil when differential gear assembly.

Item "22" thickness

1. 0	1. 2
------	------



6 Vehicle chassis

●Rear axle assemble and adjustment

Follow the drawing on the right to assemble

Tightening torque	
Item 7	25N • m
Item 44	13N • m
Item 42	8N • m
Oil injecting hole bolt	25N • m
Oil leaking hole bolt	25N • m

a During assembly adjusting shims"10" and"15" thickness to ensure:


1. Rear axle bevel gear"13" installs correctly and contact normal, gears clearance is 0.10~0.20;
2. Bearing "16" Axial clearance is less than or equal to 0.06.
3. The rotating parts turn freely without sticking.

washer "15" thickness				
0.1	0.3	0.5	0.9	0.92
0.94	0.96	0.98	1.00	


washer "10" thickness	
0.2	0.3

The clearance measurement of bevel gear as right illustration: install assistant measurement tool, tighten fixing bolt (M10 × 1.25 × 60) and ensure 37mm distance between measuring point and the center of assistant measurement tools. And rotate assistant measurement tool forward and reverse and read the data

standards: 0.17~0.34




6




CFMOTO

c During rear axle assembly, rack, fork and rectangular sleeve should abut upon following the direction of the arrow as shown.



d Before rear axle motor assembly , rear motor should be rotated to the diff-lock position by using special instruments or vehicle control circuit

e During assembly of rear motor and rear axle motor, on the premise of ensuring c, d, use $\phi 5$ mandrel positioning as shown to assemble.



6.7 Drive Shaft

6.7.1 Maintenance information for CV drive shaft and Front & Rear drive shafts Inspection and maintenance

Inspection and maintenance is required if any of following problems happened on front and rear drive shaft and CV shaft.

Problem description	Failure cause
① a pronounced hesitation or jerky movement during acceleration deceleration or sustained speed	A. CV shaft drop off from axle B. front shaft of CV shaft brake or universal joint damage
② abnormal noise in front and rear drive shaft or CV shaft	C. seal enclosure of CV shaft brake D. cross type universal joint of front drive shaft brake
③ shed oil from CV shaft joint	E. rear drive shaft brake or spline damage
④ no power transmitted from engine to front or rear wheel	F. Fixed bolt loose

6

Note: Inspect failures according to problem description. If problem is not caused by engine or front and rear axle, remove and inspect shafts.

Observation and Judgement

- Investigate any unusual noise
 - Unstable noise or constant noise during acceleration or deceleration, and the noise does not relate to engine or front or rear axle
 - Possible relates to the damage of universal joint
 - Possible relates to the damage of wheel bearing
- Check CV shaft and drive shaft seal enclosure. If damage, replace it.
- Improper CV shaft assembly damage splines, and lead to no power be transited.

WARNING:

In case of above mentioned itmes, stop riding immediately for inspection and fix the problem before successive use. otherwise it will cause loss of control of the machine and possible injury to the rider.


6.7.2 Disassembly and Installation for CV drive shaft and Front & Rear drive shafts

Disassembly of front and rear CV shaft

Suspend vehicle and make sure it does not fall

Remove front and rear wheels and A-arms

Pull item 1, 3, 4, and 6 from front and rear axle at horizontal, never exert an excess force in order to avoid damaging limit circlip, rotate CV shaft try again if failed several times.



Disassembly of front drive shaft:


Suspend vehicle stable and make sure it does not fall .

Remove front wheel

Remove eight bolts of front axle and engine(as illustration, item 3).

Push front drive shaft(item 2) from one end to another end by hands to remove it.

Note: Apply butter(15g-18g) on the joint at both ends of spine or some other higher lubricating



6 Vehicle chassis

Disassembly of rear drive shaft:


Suspend vehicle stable and make sure it does not fall .

Remove front and rear wheels and swing arms (refer to Chapter 6.2 and 6.3)

Rear rear axle

Remove washer of engine(as illustration, item 1) by special tool. Remove four bolts of rear axle(as illustration, item 3) Remove rear drive shaft.

Note: Apply butter(15g-18g) on the joint at both ends of spine or some other higher lubricating



6



Installation: Reverse the removal procedures for installation.

Torque of mounting bolt of front drive shaft(GB/T 70.1 M10×1.25×25) : 40N. m~50N. m

Torque of mounting bolt of rear drive shaft (GB/T 70.1 M10×1.25×25) : 40N. m~50N. m

CFMOTO

6.7.3 Front & Rear CV Drive Shaft Exploded View



6 Vehicle chassis

6.7.4 Inspection After Front & Rear CV Drive Shaft Disassembly


- Universal joint of shafts should move smoothly. If not or with abnormal noise, replace it
- Check clearance of universal joint and middle shaft's spline, if over $1^{\circ} 30'$, replace it
- Check seal enclosure of shaft ends, if broken or leakage, replace it.
- Check limit circlip and spline surface of shaft, if abnormal wore or damage, replace it.
- Check shaft cage inner frame, star cage, steel ball, steel ball track and middle shaft spline, if broken, replace it
- Check other parts of shaft, if necessary, replace it.

Note:

Shaft cage universal joint with MoS2 lithium grease, fill $28g \pm 5g$ grease in fixed end cage universal joint, $32g \pm 5g$ grease in fixed end seal enclosure, $65g \pm 10g$ grease in axial movement cage universal joint.

6


6.7.5 Front Drive Shaft Disassembly and Inspection



- Bearing kit of front drive shaft should be flexible. if there is unflexible and abnormal noise, replace with new parts
- Bearing kit of rear drive shaft should be flexible. if there is unflexible and abnormal noise, replace with new parts
- Check the turning clearance between front drive shaft and male splines. If the clearance is too big, replace with new parts.

CFMOTO

6.7.6 Rear Drive Shaft Disassembly and Inspection



- check rubber sleeves at the both ends of rear drive shaft(item 2 and 6), replace if broken
- Apply butter(15g-18g) on rubber sleeves at both ends of shaft, otherwise spline would be worn or damaged.

Note: Apply butter(15g-18g) on the joint at both ends of spine or some other higher lubricating

7 lighting system and signal system

7 Signal and lighting system

Overhaul Info	7-1	7.5 Handlebar Switch.....	7-7
7.1 Troubleshooting.....	7-2	7.6 Brake light Switch	7-8
7.2 Bulb replacement	7-3	7.7 Horn	7-8
7.3 Headlight.....	7-3	7.8 Dashboard	7-9
7.4 Ignition Switch.....	7-6	7.9 Fuel Sensor.....	7-10

Overhaul Information

Operation instructions

Warning:

- Headlight bulb will be very hot when it is turned on. Do not touch it after it is just turned off. Operation should be done when the bulb is cooled down.
- Inspection of water temperature alarm may use heat source and liquid of high temperature. Do not put flammable matters nearby and take care not to get burnt.
- The temperature of headlight is quite high when turned on. Replacing with bare hand or stained glove will cause oil stains on the glass face which may form hot spot and cause deformation of glass face and damage to bulb.
- Pay attention to the following when replacing the bulb
 - Do not replace the bulb when it is turned on. Keep ignition switch in the OFF position, and replace after the bulb is cooled down.
 - Replace the bulb with hands in clean gloves to avoid oil stains on the glass surface.
 - Clean the glass with a clean rag dipped in alcohol or isoamyl acetate in case of any oil stains on the glass surface.
- If the Inspection has to be done with battery, check if the battery is normal.
- Inspection of switch continuity can be done without removing the switches from the vehicle.
- After the inspecting and overhauling of each part, cables and wires should be routed properly (Chapter1).
- Refer to Chapter 2 for removal and installation of taillight and rear turning lights.

7

Maintain standard

Item		Standard
Fuse	Main	30A
	Vice	30A×1 15A×4 10A×1
Bulb	Bulb (Hi / Lo)	12V-35/35W
	Breaking light / Tail light	12V-21/5W×1
	Steering light	12V-W16W×2 12V-R10W×2
	Dashboard light	12V-1.7W
	Indicators	12V-3.4W

CFMOTO

7.1 TROUBLESHOOTING

Headlight Cannot Turn On

- Broken fuse
- Open circuit of main cable
- Burnt Bulb
- Faulty Switch
- Damaged relay or poor contact

7 lighting system and signal system

7.2 Replacing Bulb

Headlight Bulb

Cautions

Headlight bulb will be very hot when it is turned on. Do not touch it after it is just turned off. Operation should be done when the bulb is totally cooled down.



Remove headlight

Disconnect the head light connector 1. Remove dust-proof cap, headlight connector, circlip and replace with a new bulb.

Warning

Wear clean gloves when replacing bulb. Oil stains on the glass surface may cause break of bulb. Clean the stained surface with alcohol or isoamyl acetate. Make sure that the three pins of the bulb should be in line with the three positioning holes in the socket when replacing the bulb.

Bulb specification: **HS1 12V-35/35W**

Reverse the removal procedure for installation



①

7

After replacing the bulb, adjust headlight beam.

7.3 Inspection of Headlight

Turn the ignition switch to ON position, turn light switch to the illuminating position and check if the headlight is on

-ON: Normal

-Off:

- Short circuit of main cable or broken main cable
- Broken fuse
- Faulty Switch

CFMOTO


Brake Light/ Tail Light bulb

Remove 2 tapping screws Remove tail light cover. Turn brake light/tail light bulb counter clockwise and remove it. Replace brake light/tail light bulb Bulb Specification: 12V-21/5W.

Reverse the removal procedure for installation.



①



②

③

7 lighting system and signal system

Front Turning Indicator Bulbs

Remove headlight
Remove cover of front turning light
Replace front turning light bulbs
Bulb Specification: 12V-10W
If the turning indicator light is LED. You need to replace the whole assy.

Reverse the removal procedure for installation, Refer to the dismounting of Headlight.



①

Rear Turning Indicator Bulbs

Remove the screw 3 to separate the cover.
Remove rear turning indicator cover. Replace rear turning indicator bulbs. Bulb Specification: 12V-10W.
If the light is LED. You need to replace the whole assy.

Reverse the removal procedure for installation.



②



③

④

7


CFMOTO

7.4 Ignition Switch

Inspection

Remove front top cover

Disconnect 3P connector of ignition switch



Ignition
Switch Lock

Check according to the following table if the connector terminals are in continuity.

● - ● in continuity

OFF		
ON	●	●
	R	B

Disassemble

Remove front cover

Disconnect 3P connector of ignition switch

Loosen bolt and remove ignition switch

Reverse the removal procedure for installation.



Ignition switch
connector

7 lighting system and signal system

7.5 Handlebar switch


Remove front cover.

Disconnect left and right handlebar switch connector. Check according to the following table if the connector terminals are in continuity.

● continuity

Lighting Switch

	black /palm	palm	palm /white	blue	white /blue	white
	●	●	●	●	●	
	●	●	●		●	●
OFF						




Ignition switch connector

Engine stop switch Electric start switch

	black /white	black /palm	yellow	yellow	gray /red
				●	●
	●	●	●		

Lighting Switch



Electric start switch

Engine stop switch

Emergency switch

Emergency switch

	orange	gray	Sky blue
	●	●	●

Over-ride switch




Over-ride Switch

	gray /black	black /palm
	●	●


7

CFMOTO

Turn Switch



Horn switch wiring diagram



2 wd, 4wd, 4wd lock switch

	L/B	L/G	Br/R	Br/G	Gr	Gr/W	Lg/Br	G
2WD	●	●				●		
F-WD	●	●	●	●				
F-LOCK			●	●	●	●	●	●

Differential switch

	L/B1	L/G1	Br/R1	Br/G1	Gr1	Dr/W1
R-WD	●	●	●	●		
R-LOCK			●	●	●	●

If inspecting result has trouble. Replace the switch



7. 6 Brake Light Switch

Disconnect brake light switch connector and check terminators for continuity
 Hold the brake lever ---Continuity
 Release the brake lever----No continuity
 Replace the switch if wrongly function.

7. 7 Horn

Inspection

Remove front vent grille
 Disconnect horn Connect with a fully charged 12V battery and check if the horn sounds
 Faulty Horn: Replace



①

②



Horn

Horn mounting bolt

7 lighting system and signal system

Disassemble

Disconnect horn connector

Loose the mounting bolts to remove horn

Reverse the removal procedure for installation.



Horn

Bolt

7.8 Dashboard

Run the vehicle at low speed and check if the speed indicator moves
Faulty speedometer: Replace



7

①

Removal and Installation


Remove front top cover

Remove front cover of dashboard

Disconnect dashboard wire connector.

Remove fixing nut and remove dashboard in the direction as illustrated on the right.

Reverse the removal procedure for installation.



Bolt (2)

Note

Main cables and wires shall be routed properly.

CFMOTO

7.9 Fuel Sensor

Remove

Fuel tank top cover

Loose 4 mounting bolt to remove the fuel sensor from the fuel tank.

Disconnect 2P connector



Fuel Sensor

Inspection

Remove fuel sensor.(refer to above steps)

Connect 2P connector.

Turn ignition switch to ON.

Shake fuel sensor float with hand, locate the float position and check if it conforms to the fuel gauge reading.

If non-conformity check main cable for damage or short circuit.

Check fuel sensor and fuel gauge



Fuel Sensor connector

Remove fuel sensor 2P connector

Connect multimeter between 3P connector terminals.


Shake float with hand and measure the resistance of float at different positions.

Connection Terminal °C:

Upper: Blue/White-Green: $4 \Omega \sim 10 \Omega$
(20 °C)

Lower: Blue /White-Green : $90 \Omega \sim 100 \Omega$
(20 °C)

Faulty fuel sensor: Replace



Fuel Sensor

Fuel sensor connector

7 lighting system and signal system

Installation

Put fuel sensor into installation hole of fuel tank. Fuel sensor should be fitted properly, No fuel leakage is allowed.

Connect fuel sensor 2p connector

Inspection of Fuel Gauge

Switch on power supply and check if fuel level gauge functions normally.



Fuel Sensor connector


If fuel gauge works normally, Reverse the removal procedure for installation of plastic parts and seat.

8 Electrical System

8.1 Charging System	8-2
8.2 Starting System	8-4
8.3 EFI System	8-8
8.3.1 EFI Structure	8-8
8.3.2 EFI system Maintenance Notice	8-9
8.3.3 EFI Service Tool	8-10
8.3.4 EFI Components and Function	8-12
(1) ECU	8-12
(2) Throttle Body	8-13
(3) Intake air pressure sensor	8-15
(4) Intake air temperature sensor	8-16
(5) Water Temperature Sensor	8-17
(6) Oxygen Sensor	8-18
(7) Crankshaft position sensor	8-20
(8) Mileage sensor	8-21
(9) Gear Position Sensor	8-23
(10) Fuel Pump	8-24
(11) Fuel Injector	8-25
(12) Step motor	8-26
(13) Ignition Coil	8-27
8.3.5 EFI Self-diagnosis	8-29
(1) M I L trouble indicator	8-29
(2) PDA	8-30
(3) Trouble Code	8-32

8.1 Charging System

Charging Circuit



Magneto Coil Resistance


- Measure 3-phase magneto stator coil resistance;
- If the resistance is out of specification, replace with a new stator.
- Check for the insulation between stator and core
Turn multimeter to $1 \times 10 \Omega$

MAG Coil Resistance:

$0.5 \Omega \sim 1.5 \Omega$ (Yellow-Yellow)

Resistance between Stator Coil and Core

$\infty \Omega$ (Yellow-Ground)



Resistance measuring


MAG Non-loaded Performance

- Start the engine and allow it run at 5000RPM
Use multimeter to measure the voltage between 3 output lines.
- If the reading is below specification, replace with a new magneto.

Turn Multimeter to V (AC)


Voltage between Output Lines When MAG Non-loaded:

>200V(AC) at 5000RPM



Voltage measuring

Rectifier



8

● Connect multimeter between terminals to see resistance. If any reading is out of specification, replace with a new regulator.

Turn multimeter to DIODE

● After engine running and at the state of battery full charged, if the voltage between positive and negative terminal exceeds 15V or is lower 12V, replace with a new MAG.

NOTE

If multimeter reads below 1.4V when probes unconnected, replace its battery.


		Red ⊕				
		1	2	3	(-)	(+)
Black ⊖	1		∞	∞	100~800	∞
	2	∞		∞	100~800	∞
	3	∞	∞		100~800	∞
	(-)	∞	∞	∞		∞
	(+)	100~800	100~800	100~800	100~800	

CFMOTO

8.2 Electrical start system

Start wiring diagram (See attached 1)

Start motor



1. Side cover

2. Brush bracket

3. Brush spring

4. O-ring

5. Brush connector

6. Motor can

7. Brush

8. ARMATURE


9. Washer

10. Inner side cover

11. O-ring

BRUSH

- Check brush for damages or cracks
- If any damages, replace with a new brush.




8 Electrical and EFlsystem

COMMUTATOR

- Check for color change, damages or wear
- If any damages, replace with a new commutator
- If the color changes, polish the commutator surface with sand paper and wipe it up with a clean, dry cloth.
- If over wear, cut a part of insulator B and the distance between A and B as d.

$$d \geq 1.5\text{mm}$$




8

ARMATURE

Use a multimeter to check the armature coil continuity and the one between coil and the shaft.

If armature coil has no continuity or there is continuity between the coil and the shaft, replace the armature with a new one.



OIL SEAL

Check for damages or leaks.

If damages or leaks, replace with a new starter motor.



CFMOTO

STARTER RELAY

- Put 12V between positive and negative terminal. Use multimeter to check if there is continuity between 2 contacts.
- If multimeter clicks, there is continuity between contacts.
- If 12V is removed, no continuity remains between contacts.
- If both above 2 items are ok, it indicates the replay is ok.



Turn multimeter to DIODE

CAUTION: The voltage loaded between terminals cannot exceed 2 minutes, otherwise, starter relay may overheat or burn.

- Use multimeter to measure starter relay coil resistance, if the reading is out of specification, replace a new relay.

- Turn multimeter to $1 \times 10 \Omega$

Starter Relay Coil Resistance: $3 \Omega \sim 5 \Omega$



8 Electrical and EFIsystem

AUXILIARY STARTER RELAY, FUEL PUMP RELAY

● Put 12V between auxiliary starter relay positive and negative terminal; use multimeter to check the continuity between A and B

Turn multimeter to DIODE

● If multimeter clicks, it indicates there is continuity between A and B.

● If 12V is removed, no continuity remains between contacts


● If both above 2 items are ok, it indicates the relay is ok

● Turn multimeter to $1 \times 100 \Omega$; measure auxiliary starter relay resistance.

Auxiliary starter relay resistance:

$90 \Omega \sim 100 \Omega$

NOTE:At the back of auxiliary starter relay, parallel to diode, it fs the relay coil positive terminal.



8

ENGINE STARTING NOTICE

● Properly route according to starting schematic diagram.

● Before starting, check if all parts are fitted correct

● Check air intake system.;

● Check fuel supply system; ensure there is no block or leaks.

● Test fuel pressure with fuel pressure gauge.

Pressure in fuel pump outlet:

$0.33\text{MPa} \pm 0.02\text{MPa}$

● Place the transmission in Neutral


● Check EFI with PDA for fault; if there is, eliminate the trouble according to DTC (Diagnostic Trouble Code).

● Close the throttle and turn the engine stop switch to "RUN", then push starter switch for 3~5 seconds to run the engine.

● After starting, warm up until idle speed is stable and check it

Idle Speed: **$1500\text{r/min} \pm 150\text{r/min}$** ;


Note: If the engine idle speed cannot stable or too high. Please stop the engine for while then start again.



CFMOTO

8.3 EFI system

8.3.1 EFI SYSTEM STRUCTURE



EFI system is composed of three

subsystems:

(1) Sensors:

A sensor is a device that measures a physical quantity and converts it into a signal which can be read by an observer or by a meter. Sensors in EFI system include

- **Intake pressure sensor** (Load information)

- **Intake temperature sensor** (Air density information)

- **Throttle Position Sensor** (Loading information, loading range information, Acceleration information)

- **Crankshaft Position Sensor** (Crankshaft position information)

- **Water Temperature Sensor** (Engine temperature information)

- **Gearing Position Sensor** (Gear information)

- **Mileage sensor** (Output RPM information)

- **Oxygen Sensor** (Excess air coefficient information)

- **4WD/Lock** (4WD lock information)

- **Over-ride Switch** (Relieve speed limit information)

(2) ECU:

Electronic Control Unit, the brain of EFI system, which determines the amount of fuel injection, ignition timing and other parameters an engine needs to keep running by calculating and analyzing values provided by sensors.

(3) Actuator:

Execute the EFI instruction. Main actuators include

- Fuel Pump (supply high pressure fuel)

- Fuel Injector (inject fuel, make fuel spray excellent)

- Ignition Coil (Provide high pressure ignition energy to spark plug)

- Idle Air Control Valve (Provide idle speed air inlet)

8.3.2 EFI System Maintenance Notice

- Always use genuine CFMOTO parts for maintenance, otherwise it cannot assure a normal performance to EFI system.
- During the maintenance procedure, never try to break down the EFI components.
- In the course of maintenance, EFI parts must be handled carefully.
- Ignition switch must be shut off before connecting or disconnecting connectors, otherwise, it may cause the EFI parts damage.
- When removing fuel pump from fuel tank, do not energize the fuel pump, otherwise, a spark can cause a fire.
- Fuel pump is not allowed to operate in a dry environment or under water, otherwise, its life would be shortened. Besides, reverse connections between positive and negative terminal of fuel pump is not permitted.
- The fuel pressure in EFI fuel supply system is very high (about 300kPa), accordingly, all fuel lines are high pressure resisting. Even if the engine is not running, the fuel pressure is high. Therefore, do not disassemble the fuel line unless it's necessary.

When the fuel line needs to be repaired, release the fuel pressure as follow shows:

Remove fuel pump relay, start the engine and allow it to idle until the engine stalls automatically.

Fuel line removal and fuel filter replacement should be practiced by a professional person in a well-ventilated place.

- If possible, don't do the spark test. If spark test is done unavoidably, try to complete the test as soon as possible. Besides, don't open the throttle, otherwise, a large quantity of unburnt fuel would enter muffler, causing the catalytic converter damage.
- Idle speed is controlled by ECU, so it's unadjustable. The throttle limiter screw has been adjusted by manufacturer before sale, therefore, it's not recommended to adjust it by the user.
- Don't reverse the battery cable connections. This may damage electrical components.
- Never remove the battery cables, when the engine is running.
- Always remove cables and electrical control units which are connected with battery terminals before welding work
- Never test the component input and output electric signal by piercing the cable plastic jacket.
- Respect the environment and dispose of the waste left during maintenance.

8. 3. 3 EFI SERVICE TOOL

Tool Name: PDA

Function:

Read/clear EFI system trouble codes, observe data stream.



PDA

Tool Name: Digital AVO Meter

Function :

Read/clear EFI system trouble codes, observe data stream.



AVO meter

Tool Name: Vacuum Gauge

Function :

Check the manifold for air pressure



Vacuum gauge

Tool name: Timing Light

Function:

This light is used to check engine ignition timing.



Ignition timing light

Tool name: Compression Tester

Function:

This tester is used to check cylinder compression, so as to determine if the rings or valves are bad and leaking pressure.



Cylinder pressure gauge

Tool Name: Fuel Pressure Gauge

Function:

This gauge is used to test the fuel pressure, so as to check fuel pump and fuel pressure regulator working conditions.



Fuel pressure gauge

Tool Name: Fuel Injector Analyzer

Function:

This analyzer is used to clean and analyses fuel injectors.




Injector analyzer and cleaner.


8. 3. 4 EFI COMPONENTS AND FUNCTION

(1) ECU

ECU, it is the brain of the whole EFI system. It analyzes and process the information received by sensors, reach a conclusion, then transmit the conclusion to the actuator as instruction so as to make the engine operation in optimal state.



ECU view



ECU pin position

ECU Pin function:

- | | | |
|--------------------------------|----------------------------|-----------------------|
| 1、 None | | |
| 2、 Oxygen sensor heating 1. | | |
| 3、 Ignition 1 | | |
| 4、 None | | |
| 5、 Ignition ground | | |
| 6、 None | | |
| 7、 None | 19、 Oxygen sensor signal 1 | 37、 Reverse switch |
| 8、 Incontinuously power | 20、 None | 38、 None |
| 9、 Intake pressure sensor | 21、 P switch | 39、 None |
| 10、 Sensor ground 1 | 22、 None | 40、 Engine RPM output |
| 11、 Intake temperature sensor. | 23、 4WD lock switch | 41、 Speedsensor |
| 12、 Throttle position sensor | 24、 Turbo switch | 42、 Rpm sensor B |
| 13、 Engine temperature sensor | 25、 Breaking switch | 43、 Rpm sensor A |
| 14、 Main relay | 26、 Starting relay | 44、 Headlight relay |
| 15、 CAN L | 27、 Step motor position A | 45、 Cooling fan relay |
| 16、 CAN H | 28、 Step motor position B | 46、 Fuel pump relay |
| 17、 Step motor position D | 29、 MIL indicator | 47、 None |
| 18、 Step motor position C | 30、 5V output 1 | 48、 Injector 1 |
| | 31、 None | |
| | 32、 Ignition switch | |
| | 33、 Continously power | |
| | 34、 K-Line | |
| | 35、 Neutral switch | |
| | 36、 None | |

8 Electrical and EFlsystem

Limit Data:


Item		Data			Unit
		Min	Midium	Max	
Battery volt	Normal	9.0	14.0±0.1	16.0	V
Limit standar		6.0~9.0		16.0~18.0	V
Battery over voltage	26.0V	Keep several functions and can be measured		5	min
Working temp.		-40		70	°C
Stocking temp.		-40		90	°C

- It's not allowed to apply a heavy load on ECU housing, or it may deform and damage ECU.
- Always handle ECU gently. Never drop it, especially on a hard surface.

8

(2) THROTTLE BODY:

Connected between air filter and engine. When throttle lever is applied, the valve butterfly in throttle body would spin at a certain angle. Tips can monitor the position of valve butterfly and send the signal to ECU.




Throttle body

CFMOTO


Pin function:

- 1.5V Power
- 2.Ground wire
- 3.Output voltage




Position sensor view

Here is the diagram with ECU



Idle speed screw is is not allowed to adjust.

● Engine idle speed is regulated by ECU. It is not allowed to adjusted by human.



Idle speed screw


8 Electrical and EFlsystem

(3) Intake pressure sensor

Measure the intake pipe pressure and send the engine load information to ECU.


Pin function

1. Ground wire
2. 5V power
4. Output voltage




8

Here is the wiring diagram of the sensor with ECU.




Here is the installing standard. Follow this standard to avoid the cooling water appeared. The cooling water can damage the pressing sensor part.



CFMOTO


The following figure refers to output voltage-pressure relation

Monitor pressure range: 10kPa~115kPa




(4) Intake temperature sensor

Sensor is the thermistor a negative temperature coefficient (NTC) The thermistor decrease with coolant temperature, but they are not linearity. Temperature sensor and sensor are assembled together.




The view of Intake temperature sensor.

Here is the wiring diagram of the sensor and ECU connection



The following chart explains resistance-temperature relation.




8

(5) Water temperature sensor

Sensor is the thermistor a negative temperature coefficient (NTC) The thermistor decrease with coolant temperature, but they are not linearity. The signal one is for ECU to check the heat situation, one is for dashboard to check the water temperature.


A and C is one group, for water temperature signal to ECU.



B and screw is one group, to give water temperature to dashboard.

Water temperature sensor view

Here is the wiring diagram of the sensor, ECU and dashboard.



CFMOTO

The right chart explains pin B and threaded portion coolant temperature relation. The signal is for meter.

Dashboard resistance (B-ground)	
Temperature (°C)	Standard (Ω)
45	265.0~323.0
80	74.6~90.6
115	25.7~31.7

The right chart explains pin A, C-coolant temperature relation. The signal is for ECU.

ECU resistance (A-C)	
Temperature (°C)	Standard (Ω)
-25	38583
0	9399
25	2795
80	334
115	115.7


(6) OXYGEN SENSOR

This sensor is used in closed-loop feedback-controlled fuel injection to improve the air-to-fuel ratio accuracy and control the emission.

It's located in the exhaust stream to measure the amount of oxygen in exhaust and send the signal to ECU, which can revise the fuel injector output, so as to reduce the amounts of unburnt fuel and make catalytic converter convert HC, CO and oxides of Nitrogen efficiently.

Pins and Function


- D. Connected with positive terminal, heating power (White)
- C. Connected with negative terminal, heating power (White)
- B. Connected with negative terminal, signal output (Grey)
- A. Connected with positive terminal, signal output (Black)



Oxygen sensor

8 Electrical and EFlsystem

Below figure is circuit of sensors and ECU




8

The following table explains the oxygen sensor working parameters.


Item	New		500h test	
	350°C	850°C	350°C	850°C
Exhaust Temp	350°C	850°C	350°C	850°C
$\lambda = 0.97$ (CO=1%) Sensor voltage (mV)	840 ± 70	710 ± 70	840 ± 80	710 ± 70
$\lambda = 1.10$ Sensor voltage (mV)	20 ± 50	55 ± 30	20 ± 50	40 ± 40
Sensor resistance (k Ω)	≤ 1.0	≤ 0.1	≤ 1.5	≤ 0.3
Sense time (ms) (600mV~300mV)	≤ 150	≤ 150	≤ 300	≤ 200
Sense time (ms) (300mV~600mV)	≤ 150	≤ 150	≤ 300	≤ 200

(7) CRANKSHAFT POSITION SENSOR

Detects the rate at which the crankshaft is spinning and provides the signal for ECU to determine ignition and fuel injection.




Right figure is the circuit of CPS and ECU



CPS Resistance

- Set multimeter to $1 \times 2k \Omega$ range
CPS resistance: $950 \Omega \pm 50 \Omega$ (20°C)
- If the CPS resistance reading is out of specification above, replace.



Test CPS Peak Voltage

● Connect multimeter and peak voltage adapter as right wiring diagram illustrates:

- + Probe: Green Lead
- Probe: Blue Lead


NOTE:

When using peak voltage adapter, refer to some instructions

- Set multimeter to **V** range
- Place the transmission in **N** and turn the ignition switch to **ON**
- Push starter switch and allow the engine to run for seconds, then test CPS peak voltage.
- Repeat above procedure and get the highest CPS peak voltage;

CPS peak voltage : $\geq 3V$ (200r/min)

- If the CPS peak voltage reading is out of above specification, replace.




8

(8) Milage sensor

This sensor is used to detect the rotating speed of the engine output shaft and provide the signal for ECU to determine the vehicle speed. It belongs to Hall effect sensor, that varies its output voltage in response to a magnetic field.

Pins and Function:


1. Ground
2. Output voltage signal (> 80% input power voltage)
3. Power **+DC12V**



Milage sensor view


CFMOTO

Right figure is circuit of sensor and ECU



Speed Sensor Test

- Ground pin 1 and connect pin 3 with +12V power
- Fix a gear 2.5mm away from a speed sensor as the right figure illustrates
- Turn multimeter to DC Voltage range
- Slowly turn the gear and measure the voltage between pin 2 and pin 3 to determine that if the reading varies from 0V~12V.
- If the reading doesn't vary, that indicates the sensor is defective and needs to be replaced.




(9) Gear position sensor

This sensor is used to provide the gear position signal for meter display. Meanwhile, it cooperates with cable as starting protection.

Pins and Function:

Yellow/Blue-L (Low Gear)
Orange/Blue-H (High Gear)
Yellow/Black-P (Park Gear)
White/Yellow-N (Neutral)
Sky Blue/White-R (Reverse Gear)

● When each pin at a certain gear position, there is continuity between this pin and engine. Otherwise, no continuity.



8

Gear position sensor view

Caution when driving in reverse:

● When driving in reverse, gear position sensor sends the reverse signal to ECU and meter. ECU would limit the vehicle speed in response to the reverse signal.

(10) Fuel pump

The Fuel pump assy includes fuel pump, plastic support, preliminary filter, fine filter and pressure regulator. It supplies fuel for engine under a certain pressure and flow.

Functions of the pins:

1. Blue (Ground)
2. Red (connected with fuel pump relay output terminal)


Parameters:

Pressure regulator opening pressure:

0. 33MPa \pm 0. 02MPa

Flow: >35L/h

- This fuel pump is located in fuel tank
- Do not operate the fuel pump in dry condition in order to prevent damage.
- Always handle the fuel pump gently Never drop the fuel pump, especially on a hard surface. Such a shock to pump can caused damage.




Fuel pump assy view

Fuel Pump Wiring (See drawing on the right)

- Battery supplies power for fuel pump assembly via fuel pump relay, which connects the fuel pump circuit only with engine started.

Fuel pressure test:

- Connect the fuel pressure gauge with fuel outlet and tighten the joint with a clamp to prevent fuel leaks.
- Route accords to the right circuit
- Turn both ignition switch engine stop switch on;
- At this moment, fuel pump will operate for 5 seconds. After the fuel pump stops running, fuel pressure should be in specification, otherwise, replace it.
- After fuel pump stops running, the holding pressure should be at 0.25MPa for at least 5 minutes, otherwise, replace it



Pressure of fuel pipe release:

In an EFI model, the pressure in fuel system is very high, so all the line is high pressure resistant. Even though the engine is not started, the pressure in fuel system remains high. Therefore, it is not recommended to remove fuel lines before pressure relief.

Follow the procedure below to perform pressure relief:

Remove fuel pump relay, start the engine and allow it to idle until the engine stops automatically.

(11) Fuel Injector

One end of fuel injector mounts into fuel injector seat, and the other end attaches to the injector cap, which connects with a fuel line. Fuel injector is controlled by ECU to inject fuel at stated time into the engine.

This injector nozzle is a 4-hole style. Don't turn injector after the joint between injector and injector cap is installed.

Pins and Function:


- Connector with the mark + connected with fuel pump relay output terminal. Connector without mark: connected with Fuel Injector

Fuel Injector Resistance: $12 \Omega \pm 1 \Omega$ (20°C)


Fuel Injector Circuit wiring diagram

Fuel injector install:

- Install fuel injector manually. Never knock fuel injector with a hammer.
- When removing and installing fuel injector, the O-rings on both ends must be replaced
- Perform pressure relief before fuel injector removal if necessary.
- Test the fuel injector sealing after installation to ensure no leaks.




Injector view



(12) Step motor.


Control the air flow. The step motor is controlled by ECU from engine loading and sensors data. Since different fuel injection in different engine load. It needs step motor to add enough air flow. So please follow the right way to connect the wire or can cause the idle speed unstable.



Pins and Function:

- 1、 Step motor 1 to ECU's 17.
- 2、 Step motor 2 to ECU's 27
- 3、 Step motor 3 to ECU's 18
- 4、 Step motor 4 to ECU's 28

Step motor and ECU connecting diagram




8 Electrical and EFlsystem

Step motor data

Item	Value			Unit
	Min	Standard	Max	
Rated Voltage		13.5		V
Resistance(+20°C)		16		Ω
Rated Current		0.85		A
Control Pulse Frequency			30	Hz
Standard Control Pulse Width		≈8		ms
Air Flow(When Pressure Difference=700mbr, Duty Ratio=100%)		5.0		m ³ /h

(13) Ignition coil

Ignition coil transforms the low voltage of primary coil to high voltage of secondary coil needed to spark the spark plug and ignite the mixture of air and fuel in cylinder.




Ignition coil

Pins and Function:

1. Ground;
2. Connect power +;
3. Connect ECU pin;

The wiring diagram of ignition coil and ECU connection.




8

CFMOTO

Secondary Ignition Voltage Test

- Connect the engine according to EFI wiring diagram;
- Connect the peak voltage tester according to the right diagram;
- Start engine
- Secondary ignition voltage should be $> 15000V$ 。



Ignition Coil Parameters

Item	Data			Unit	
	Min	Standard	Max		
Setted voltage		14		V	
Running voltage	6		16.5	V	
Resistance (20°C~25°C)	First level coil	0.74	0.76	0.78	Ω
	Second level coil	10.1	10.6	11.1	kΩ
First level		7		A	

8.3.5 EFI self-diagnosis

ECU constantly monitors sensors, actuators, circuits, MIL and battery voltage, etc, even itself. It also tests sensors output signal, actuator drive signal and inner signal (such as closed-loop control, coolant temp. signal, idle speed control and battery voltage control, etc for reliability). If any malfunction or suspectable signal found, ECU would record the fault information in RAM.

Fault information comes in form of fault codes, which are then displayed on PDA, in sequence of which fault comes first.

Faults can be divided into “steady fault” and “occasional fault” (such as a fault caused by harness short or loose connection.)

PDA or MIL can be used to locate the part in trouble immediately after fault happens.

EFI system trouble diagnose mainly use indicator light and PDA

(1) MIL (or FI Indicator):

MIL is a light-emitting diode and located on instrument panel. It indicates different fault codes through the flashes in different frequency.

The wiring diagram is on the right. The current to ECU J1-3 pin should less than 0.1A

MIL Flash principles:

a: In flash code model, trouble-free in Trouble memory


When ECU monitors MIL in flash code model, MIL flashes to indicate a fault code according to the fault P-code from Trouble memory.

From ECU ignition format MIL indicator keeps on. If trouble code comes, the indicator will off 3s. Then start blinking each 0.4s to show the code. One number blinking over. It will stop for one second then next number. MIL keeps on shows no trouble until the engine start it will off.

b: In flash code model, trouble faulted in Trouble memory.

When ECU monitors MIL in flash code model, MIL flashes to indicate a fault code according to the fault P-code from Trouble memory.

From ECU ignition format MIL indicator keeps on. If trouble code comes, the indicator will off 3s. Then start blinking each 0.4s to show the code. One number blinking over. It will stop for one second then next number. MIL keeps on shows no trouble until the engine start it will off. If indicator still on. Please check the trouble code list.



c: Read the troubles by flash code.

Turn the ignition on, and K line to ground after 2.5 seconds. If ECU Trouble memory has fault code, the output code of engine MIL means P-code. Take fault code P0203 for example: MIL lights flashes for 10 times-Interval- flashes for 10 times-Interval- flashes for 2 times-Interval- flashes for 10 times-Interval- flashes for 3 times.

(2) **PDA:** PDA has 3 pins-power, ground wire and data cable K. These pins are connected with related ECU pins.


The right photo refers to operation panel of PDA. When it comes to detailed keys function, refer to PDA manual.

Pins and Function:

1. Connect to ECU's J2-3 pin
2. Ground
3. +12V power

Keys and Function:

- LH Key: Page up
- UP Key: Scroll up
- RH Key: Page down
- Down Key: Scroll down
- OK Key: Entrance
- Exit Key: Exit




PDA Function:

(A) Version Information Display

PDA can display engine, ECU hardware and software information.

(B) Fault Display

PDA monitors IAP sensor, IAT sensor, water temperature sensor, TPS, Oxygen sensor, Oxygen sensor heating circuit, air-to-fuel ratio revision, fuel injector, fuel pump relay, CPS, speed signal, idle speed, idle air control valve, system voltage, ECU, FI indicator and displays the fault code.



8 Electrical and EFI system

(C) Engine Parameters Display

PDA can display battery voltage, RPM, desired idle speed, vehicle speed, coolant temperature, water temperature sensor signal voltage, inlet air temperature, IAT sensor signal voltage, inlet air pressure, inlet air flow, IACV target position, TPS signal voltage, throttle body position, throttle body relative position, canister duty, charging time, FI pulse width, park advance angle, Oxygen sensor voltage, engine relative load, canister load, IACV position, atmospheric pressure, altitude multiplier, engine operation time.

(D) EFI Status Display

Starter switch, main relay, fuel pump relay, idle speed, idle speed, full load status, deceleration activation, acceleration activation, FI close loop activation, lambda control activation, canister control valve activation, MIL status.

(E) Actuator Test Function

MIL, fuel pump, IACV, canister control valve, ignition and fuel injection.

8

(3) Trouble code list

P0107	MAP Circuit Low Voltage or Open
P0108	MAP Circuit High Voltage
P0112	IAT Circuit Low Voltage
P0113	IAT Circuit High Voltage or Open
P0117	Coolant/Oil Temperature Sensor Circuit Low Voltage
P0118	Coolant/Oil Temperature Sensor Circuit High Voltage or Open
P0122	TPS Circuit Low Voltage or Open
P0123	TPS Circuit High Voltage
P0131	O2S 1 Circuit Low Voltage
P0132	O2S 1 Circuit High Voltage
P0031	O2S 1 Heater Circuit Low Voltage
P0201	Injector 1 Circuit Malfunction
P0202	Injector 2 Circuit Malfunction
P0230	FPR Coil Circuit Low Voltage or Open
P0232	FPR Coil Circuit High Voltage
P0336	CKP Sensor Noisy Signal
P0337	CKP Sensor No Signal
P0351	Cylinder 1 Ignition Coil Malfunction
P0352	Cylinder 2 Ignition Coil Malfunction
P0505	Idle Speed Control Error
P0562	System Voltage Low
P0563	System Voltage High
P0650	MIL Circuit Malfunction
P1693	Tachometer Circuit Low Voltage
P1694	Tachometer Circuit High Voltage
P0137	O2S 2 Circuit Low Voltage
P0138	O2S 2 Circuit High Voltage
P0038	O2S Heater 2 Circuit High Voltage
P0037	O2S Heater 2 Circuit Low Voltage
P0500	VSS No Signal
P0850	Park Neutral Switch Error
P0445	CCP short to high
P0444	CCP short to low/open

EFI troubleshooting by trouble code

Instruction:

1. Only after stable trouble is confirmed, then do checking and repair. Otherwise it will bring mistakes.
2. Below mentioned multimeter is only for digital multimeter, pointer multimeter is not allowed for checking EFI circuit.
3. If trouble code means voltage is too low, it is short circuit to ground or open circuit. If trouble code means voltage is too high, it is short circuit to power. If trouble code means circuit has something wrong, then open circuit or many circuits is in trouble.

Diagnosis helps:

1. If trouble code cannot be removed, then it is a stable trouble.
If it is a temporary trouble, please check wiring connectors.
2. During checking, do not neglect influences of vehicle maintenance, cylinder pressure and valve timing.
3. Replace ECU and test.

If trouble code can be removed by replacement of ECU, then it is a trouble originated from ECU. If trouble code still exists, then install original ECU and check other parts step by step.

In the following, there are detailed descriptions about trouble codes and diagnosis procedures.

Trouble code P0032: Cylinder 1 Oxygen sensor heating coil high volt

<p>Note:</p> <p>Trouble may cause from this</p> <ol style="list-style-type: none"> 1) ECU to oxygen sensor C pin disconnected 2) Oxygen sensor C pin to main relay disconnected 3) Oxygen sensor C pin to D pin disconnected. 	<p>Maintenance note</p> <p>Inspect the item below</p> <ol style="list-style-type: none"> 1) Measure ECU connecting pin to C pin of oxygen sensor resistance. 2) Measure oxygen sensor D pin to main relay resistance. 3) Measure oxygen sensor C pin to D pin resistance (9.6kΩ).
---	--

Trouble code P0031: Cylinder 1 Oxygen sensor heating coil low volt

<p>Note:</p> <p>Trouble may cause from this</p> <ol style="list-style-type: none"> 1) ECU pin line short to the ground 2) ECU pin line short to D pin of oxygen sensor. 3) ECU short to other line. 	<p>Maintenance note:</p> <p>Inspect the item below</p> <ol style="list-style-type: none"> 1) Measure ECU pin to ground resistance 2) Measure ECU voltage 3) Measure ECU pin to D pin resistance (9.6kΩ).
---	--

Trouble code P0131: Cylinder 1 Oxygen sensor voltage low

Diagnose instructions: The system measure the A pin and B pin voltage on sensor to analyze the signal out put

Sensor may be damaged by cooled liquid in some situation. Especially cold start.

<p>Note:</p> <p>Trouble may cause from this</p> <ol style="list-style-type: none"> 1) ECU pin line short to the ground 2) ECU pin line short to D pin of oxygen sensor. 3) ECU short to other line. 4) Oxygen sensor damaged. 	<p>Maintenance note:</p> <p>Inspect the item below</p> <ol style="list-style-type: none"> 2) Measure ECU pin to ground resistance 2) Measure ECU voltage 3) Measure ECU pin to D pin resistance (9.6kΩ).
---	--

Trouble code P0132: Cylinder Oxygen sensor voltage high

<p>Note:</p> <p>Trouble may cause from this</p> <ol style="list-style-type: none"> 1) The ECU line to A pin and B pin disconnected 2) Oxygen sensor A pin and B pin disconnected 	<p>Maintenance note:</p> <p>Inspect the item below</p> <ol style="list-style-type: none"> 1) Replace the oxygen sensor 2) Replace the ECU 3) Line test
--	---

Trouble code P0107: Intake pressure sensor voltage low or disconnected

<p>Note: The trouble may cause from this 1) ECU test the signal line may short to the ground</p>	<p>Maintenance note: Inspect the item below 1) ECU pin resistance to the ground</p>
--	---

Trouble code P0108: Intake pressure sensor voltage high

<p>Note: The trouble may cause from this 1) ECU test the signal line short to power</p>	<p>Maintenance note: Inspect the item below 1) ECU pin voltage</p>
--	---

Trouble code P0112: Intake Temperature sensor voltage low

<p>Note: Trouble may cause from this. 1) ECU pin signal line short to the ground</p>	<p>Maintenance note: Inspect the item below 1) Measure ECU pin line resistance to the ground.</p>
---	--

Trouble code P0113: Intake temperature sensor voltage high

<p>Note: Trouble may cause from this 1) ECU pin signal line short to power.</p>	<p>Maintenance note: Inspect the item below 1) Measure ECU signal line voltege</p>
--	---

Trouble code P0117: Water temperature sensor voltage low

<p>Note: Trouble may cause from this 1) ECU pin signal line short to the ground.</p>	<p>Maintenance note: Inspect the item below 1) Measure ECU line resistance to the ground.</p>
---	--

Trouble code P0118: Water temperature voltage high or disconnected

<p>Note: Trouble may cause from this 1) ECU pin signal line short to the power</p>	<p>Maintenance note: Inspect the item below 1) Measure the ECU pin voltage</p>
---	---

Trouble code P0122: TPS voltage low or disconnected

<p>Note: Trouble may cause from this</p> <ol style="list-style-type: none"> 1) ECU pin line short to the ground 	<p>Maintenance Note: Inspect the item below</p> <ol style="list-style-type: none"> 1) Measure the ECU pin line resistance to the ground.
---	--

Trouble code P0123: TPS voltage too high.

<p>Note: Trouble may cause from this</p> <ol style="list-style-type: none"> 1) ECU Pin line short to other line. 	<p>Maintenance Note: Inspect the item below</p> <ol style="list-style-type: none"> 1) Measure the voltage from sensor to ECU pin.
--	--

Trouble code P0201: Cylinder 1 injector coil problem

<p>Note: Trouble may cause from this</p> <ol style="list-style-type: none"> 1) Injector coil disconnected 2) Injector is not well connected to ECU. 3) Injector is not connected to the relay. 4) The running line to ECU short to the ground. 5) The line to ECU is short to other line. 	<p>Maintenance Note: Inspect the item below</p> <ol style="list-style-type: none"> 1) Measure the injector resistance. 2) Inspect the connecting cable to check it well connected. 3) Measure the resistance to ECU 4) Measure the voltage to ECU.
---	--

Trouble code P0336: Crankshaft position sensor trouble signal

<p>Note: Trouble may cause from this</p> <ol style="list-style-type: none"> 1) Cable connector short cut or disconnected intermittently. 2) Crankshaft signal wheel position wrong. 3) Crankshaft position sensor position wrong. 	<p>Maintenance Note:</p> <ol style="list-style-type: none"> 1) Inspect the cable connector. 2) Inspect the magneto rotor
--	--

Trouble code P0337: No signal from crankshaft position sensor

Trouble reason: When engine start the ECU will test all the sensor's signal.

Analyze the signal reasonability to judge the signal lost.

<p>Note: Trouble may cause from this</p> <ol style="list-style-type: none"> 1) Crankshaft position sensor disconnected to ECU. 2) Crankshaft position sensor short to ECU. 3) Crankshaft position sensor coil disconnected 	<p>Maintenance Note:</p> <ol style="list-style-type: none"> 1) Measure the resistance between CPS and ECU. 2) Measure CPS resistance 3) Measure CPS top voltage
---	--

8 Electrical and EFlsystem

Trouble code P0230: Oil pump relay coil low voltage or disconnected.

Trouble code P0232: Oil pump relay coil high voltage

<p>Note: The trouble may cause from this</p> <ol style="list-style-type: none"> 1) Oil pump relay line to ECU may disconnected/ Short to the ground/Short to the power 2) Oil pump relay disconnect to the main relay. 3) Relay coil disconnected 	<p>Maintenance Note: Inspect the item below</p> <ol style="list-style-type: none"> 1) Measure the resistance or voltage between ECU and oil pump relay. 2) Measure the resistance between oil pump relay and main relay. 3) Measure the resistance between 2 pins on relay.
--	---

Trouble code P0505: Idle speed not in control

Trouble reason: The engine idle speed controlled by closed loop. If the ECU reached idle speed control for period and the engine speed still higher then target idle speed. The trouble code will comes out.

<p>Note: The trouble may cause from this</p> <ol style="list-style-type: none"> 1) Inspect the adjusting screw, cable and throttle body well worked. 2) Throttle body too dirty. 	<p>Maintenance Note: Inspect the item below</p> <ol style="list-style-type: none"> 1) Off the ignition switch for more than 3 seconds, then start again.
---	--

Trouble code P0562: Battery low voltage

Trouble code P0563: Battery high voltage

<p>Note: Trouble may cause from this</p> <ol style="list-style-type: none"> 1) Magneto damaged or battery energy flow. 2) Magneto coil disconnected. 3) Rectifier damaged 	<p>Maintenance note: Inspect the item below</p> <ol style="list-style-type: none"> 1) Inspect the magneto function. Measure the output voltage after start. 2) Inspect the rectifier output voltage
---	--

Trouble code P0650: MIL indicator trouble

<p>Note: The trouble may cause from this</p> <ol style="list-style-type: none"> 1) MIL indicator disconnect to ECU/ short to the ground/short to power. 2) MIL indicator disconnect to main relay 3) MIL indicator burned 	<p>Maintenance note: Inspect the item below</p> <ol style="list-style-type: none"> 1) Measure the resistance or voltage between ECU and MIL indicator.
---	--

Trouble code: P0500 Speed sensor no signal

Trouble reason: When the vehicle loose the gas with shift. The ECU will test the Engine speed and vehicle speed at the same time. If the engine keeps running at high speed and the vehicle speed too low. The system will judge the speed sensor signal problem.

<p>Note: Trouble may cause from this.</p> <ol style="list-style-type: none"> 1) ECU to speed sensor short to the ground or disconnected. 	<p>Maintenance Note: Inspect the item below</p> <ol style="list-style-type: none"> 1) Measure the resistance between ECU to speed sensor 2) Measure the resistance between ECU to the ground.
--	--

Trouble code: P0850 neutral sensor trouble

Trouble reason: Vehicle cannot start in neutral gear

<p>Note: The trouble may cause from this</p> <ol style="list-style-type: none"> 1) ECU to neutral sensor signal disconnected to the ground. 	<p>Maintenance Note: Inspect the item</p> <ol style="list-style-type: none"> 1) Measure the resistance between ECU and neutral sensor.
---	--

Trouble code: P0445 Starting auxiliary relay high voltage.

Trouble code: P0444 Starting auxiliary relay low voltage or disconnected

<p>Note: The trouble may cause from this</p> <ol style="list-style-type: none"> 1) Auxiliary relay to ECU disconnect to the ground/short to the ground/short to the power. 2) Auxiliary disconnected to power 3) Auxiliary relay oil disconnected 	<p>Maintenance Note: Inspect the item</p> <ol style="list-style-type: none"> 1) Measure the controlling resistance or voltage between ECU and auxiliary relay. 2) Measure the resistance between the relay and power. 3) Measure the resistance between pins
---	--

Trouble code P1693: Speed output voltage low

Trouble code P1694: Speed output voltage high

Trouble reason: When engine start the ECU will test all the sensor's signal.

Analyze the signal reasonability to judge the signal lost.

<p>Note: Trouble may cause from this</p> <ol style="list-style-type: none"> 1) Cable connector short cut or disconnected intermittently 2) Crankshaft signal wheel position wrong. 3) Crankshaft position sensor position wrong. 4) Crankshaft position sensor disconnected to ECU. 5) Crankshaft position sensor short to ECU 6) Crankshaft position sensor coil disconnected. 	<p>Maintenance Note:</p> <ol style="list-style-type: none"> 1) Inspect the cable connector. 2) Inspect the magneto rotor 3) Measure the resistance between CPS and ECU. 4) Measure resistance from CPS to ECU 5) Measure CPS resistance 6) Measure the top voltage of the CPS
---	---

Trouble code P0351: Ignition coil problem

<p>Note: The trouble may cause from this</p> <ol style="list-style-type: none"> 1) Ignition coil disconnected 2) Ignition coil well connected to ECU. 3) Ignition coil well connected to relay. 4) The running line to ECU short to the ground. 5) The wire to ECU short to other line. 	<p>Maintenance note: Inspect the item below</p> <ol style="list-style-type: none"> 1) Measure the resistance of ignition coil 2) Inspect the electric wire connection. 3) Measure the resistance between ECU pin and ground 4) Measure the voltage to ECU pin
---	---

9 Trouble shooting

1 Engine body.....	9-2
2 Diagnose the trouble by the trouble code.....(Refer to 8-32~8-39)	
3 Diagnose from the situation.....	9-12

1.Engine problem

Trouble	Coming from	Solution
Engine cannot start or hard to start	<p>Cylinder pressure low</p> <ol style="list-style-type: none"> 1.Cylinder wearing 2.Piston ring wearing 3.Cylinder gasket leaking 4.Valve conducting pipe wearing 5.Spark plug loose 6.Start motor running too slow 7.Valve timing problem 8.Valve clearance not in standard <p>Spark plug no fire</p> <ol style="list-style-type: none"> 1.Spark plug clearance needs adjust 2.Spark plug wet or dirt 3.Ignition coil trouble 4.Crankshaft position sensor problem 5.Magenato problem <p>Throttle body no fuel</p> <ol style="list-style-type: none"> 1.Gas breathing hole jammed 2.Fuel Injector jammed 3.Fuel pump not running 4.Fuel pressure low 5.Fuel strainer jammed <p>Not in neutral gear</p>	<p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Repair or replace</p> <p>Tight up</p> <p>Inspect the electric part</p> <p>Adjust</p> <p>Adjust</p> <p>Adjust or replace</p> <p>Washup or Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Wash or replace</p> <p>Wash or replace</p> <p>Inspect or replace</p> <p>Inspect or replace</p> <p>Wash or replace</p> <p>In neutral gear or break</p>
Idle speed unstable	<ol style="list-style-type: none"> 1.Valve clearance not in standard 2.Valve seat not suitable 3.Valve conducting pipe trouble 4.Rocker arm or rocker arm shaft wearing 5.Spark plug dirt 6.Spark clearance not in standard 7.Ignition coil trouble 8. Idle valve intake and exhaust jammed 9.Magenato problem 	<p>Adjust</p> <p>Replace or repair</p> <p>Replac</p> <p>Replace</p> <p>Replace</p> <p>Replace or adjust</p> <p>Replace</p> <p>Replace or adjust</p> <p>Replace</p>

9 Trouble shooting

Trouble	Coming from	Solution
Not stable in high speed running	<ol style="list-style-type: none"> 1.Valve spring getting weak 2.Camshaft wearing 3.Spark plug dirty 4.Spark plug clearance too small 5.Wrong valve timing 6.Ignition coil trouble 7.Fuel pump pressure not enough 8.Air-filter too dirty 	<p>Replace</p> <p>Replace</p> <p>Wash and replace</p> <p>Adjust or replace</p> <p>Adjust</p> <p>Replace</p> <p>Adjust or replace</p> <p>Wash or replace</p>
Engine exhaust blue or black smoke	<ol style="list-style-type: none"> 1.Oil over fill. 2.Piston ring wearing 3.Valve conducting pipe worn 4.Cylinder body scatched 5.Valve rod wearing 6.Valve rod seal worn 	<p>Inspect the oil and leak out</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p>
Engine power not enough.	<ol style="list-style-type: none"> 1.Valve clearance not suitable 2.Valve spring getting weak 3.Wrong valve timing 4.Cylinder worn 5.Piston ring worn 6.Valve seat unsuitable 7.Spark plug dirty 8.Spark plug wrong clearance 9.Injector jammed 10.Fuel pressure not enough 11.Air-filter dirty 12.Rocker arm or camshaft wearing 13.Intake pipe leaking 14.Oil too much 	<p>Adjust</p> <p>Replace</p> <p>Adjust</p> <p>Replace</p> <p>Replace</p> <p>Replace or repair</p> <p>Wash or replace</p> <p>Wash or replace</p> <p>Wash or replace</p> <p>Repair or replace</p> <p>Wash or replace</p> <p>Replace</p> <p>Tight up or replace</p> <p>Check oil level and change</p>
Engine over heat	<ol style="list-style-type: none"> 1.Piston top carbon covered 2.Oil too much or too little 3.Oil pump trouble 4.Oil line jammed 5.Intake pipe leaking 6.Oil not right 7.Cooling system trouble(See 7-4) 	<p>Clean</p> <p>Inspect refill or leakout</p> <p>Replace</p> <p>Clean up</p> <p>Tight or replace</p> <p>Replace the oil</p>

9

CFMOTO

Trouble	Reason	Solution
Engine strange noise	Valve noise 1.Valve clearance too large 2.Valve spring worn or damaged 3.Rocker arm or camshaft worn	Adjust Replace Replace
	Piston noise 1.Piston worn 2.Cylinder worn 3.Carbon covered in combustor 4.Piston pin or pin hole worn 5.Piston ring or groove worn	Replace Replace Clean Replace Replace
	Timing chain noise 1.Chain pulled 2.Chain gear wearing 3.Timing chain tensioner wrong function	Replace the chain and gear Replace the chain and gear Repair or replace
	CVT noise 1.Belt loose or worn 2.Drive pulley cluthshoe worn	Replace Replace
	Crankshaft noise 1.Crankpin bearing worn or burned 2.Clearance too much	Replace Replace
	CVT noise 1.Belt loose or worn 2.Drive pulley cluthshoe worn	Replace Replace
	Driving system noise 1.Gear worn or damage 2.Input or output shaft worn 3.Bearing damaged	Replace Replace Replace
Clutch slide	1.Clutchshoe worn or damaged 2.Clutch spring getting weak 3.Clutch plate wearing 4.Belt worn or loose	Replace Replace Replace Replace

9 Trouble shooting

2 Diagnose the trouble by the trouble code

(Refer to 8-32~8-39)

3 Diagnose from the situation

Before trouble diagnosis by engine problems, initial checking should be done as follows.

1. Confirm if trouble light is ok;
2. Confirm there's no trouble code record by PDA checking.
3. Confirm there's really trouble existing complained by end-users.

Then check the following points.

- (1) Check fuel hoses if any fuel leakage;
- (2) Check vacuum pipes if any broken, twist or improper connection;
- (3) Check intake manifold if any blocked, air leakage or damaged;
- (4) Check high-tension cable if any damaged, aging; or ignition order is correct.
- (5) Check wiring close to ground if it's clean and firm;
- (6) Check connector of all sensors and actuator if any loose or improper connection.

Important note: In case there're some problems as above-mentioned, then removal work should be done firstly, then go to next diagnosis.

Diagnosis helps:

1. Confirm engine without any trouble record.;
2. Confirm there's really trouble existing;
3. During checking, do not neglect vehicle periodic maintenance, cylinder pressure, valve timing, fuel supply and so on;
4. Replace ECU to test.

In case trouble disappears, then it's a problem of ECU. If trouble still exists, then assemble original ECU and check other points.

Frequent troubles list:

- I When starting engine, engine cannot rotate or rotate slowly.
- I When starting engine, starter motor can rotate but cannot start engine.
- I Difficult to start warm or hot engine
- I Difficult to start cold engine
- I RPM is ok, but difficult to start engine.
- I Starting is ok, but idle speed is unstable at any time.
- I Starting is ok, but idle speed is unstable during engine warm-up period.
- I Starting is ok, but idle speed is unstable after engine warm-up.
- I Starting is ok, idle speed is unstable or engine stop when switch on some lights or other electric components.
- I Starting is ok, but too high idle speed.
- I RPM cannot go up or engine stop when acceleration.
- I Slow acceleration.
- I Insufficient power and bad performance when acceleration.

9 Trouble shooting

1) Starting Failure/Hard Starting

Possible defective parts: 1. Battery; 2. Starter motor; 3. Wirings harness or ignition switch; 4. Engine mechanism part.

General diagnosis procedures

Item	Procedures	Results	Next
1	Use multi-meter to check battery voltage if voltage is between 8V~12V or not when engine starts .	YES	Next Step
		NO	Replace battery
2	Turn on ignition switch, stop switch side stand switch and check if voltage of ECU pin 14 is around 12V .	YES	Next Step
		NO	Repair switches or change harness
3	Keep ignition switch "on", use multi-meter to check if voltage of starting motor anode is over 8V.	YES	Next Step
		NO	Repair switches or change harness
4	Disassemble starting motor and check its working status, especially whether there was broken circuit or jammed by bad lubrication.	YES	Repair or replace starting motor
		NO	Next Step
5	If error only occur in Winter, check if starting motor resistance is too big caused by improper oil used	YES	Change to proper lubricant
		NO	Next Step
6	Check if mechanical resistance is too big inside engine	YES	Check resistance inside engine
		NO	Repeat above procedures

9

(2) When starting, engine can rotate but cannot start

Possible defective parts: 1、No fuel; 2、Fuel pump; 3、Pick up; 4、 Ignition coil; 5、 Mechanical parts of engine

General diagnosis procedures: :

Item	Procedures	Results	Next
1	Connect fuel pressure gauge, turn on ignition switch or start engine, check if fuel pressure is around 300kPa	YES	Next Step
		NO	Repair fuel supply system
2	Connect PDA, check if there's signal of RPM data after starting engine	YES	Next Step
		NO	Check and repair RPM sensor circuit
3	Disconnect high-tension cable, connect spark plug and set its electrode 5mm to engine body, then start engine to check if blue and white spark appears	YES	Next Step
		NO	Check and repair ignition system

CFMOTO

4	Test cylinder pressure and check if pressure is enough	YES	Eliminate engine Mechanical failures
		NO	Next step
5	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30、pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

(3) Difficult to start hot engine

General failure part : 1、Water in fuel tank; 2、 fuel pump; 3、 water temp. sensor; 4、 Ignition coil.

General diagnosis procedures:

Item	Procedures	Results	Next
1	Connect fuel pump gauge, start engine, check if pressure is around 300kPa	YES	Next step
		NO	Repair fuel supply system
2	Disconnect high-tension cable, connect spark plug and set its electrode 5mm to engine body, then start engine to check if blue and white spark appears	YES	Next step
		NO	Repair ignition system
3	Disconnect water temp.sensor connector and start engine to check if engine can start.(or use one 300ohm resistance to replace water temp.sens or)	YES	Repair wiring or replace sensor
		NO	Next step
		NO	Next step
4	Check whether the failure happens right after filling fuel oil	YES	Change fuel
		NO	Next step
5	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30、pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

(4) Difficult to start cold engine.

General failure part: 1、 water in fuel tank; 2、 Fuel pump; 3、 Engine temp.sensor; 4、 Injector; 5、 Ignition coil; 6、 Throttle body and by-pass; 7、 Mechanical parts of engine

General diagnosis procedures:

9 Trouble shooting

Item	Procedures	Results	Next
1	Connect fuel pump gauge ,start engine, check if pressure is around 300kPa	YES	Next step
		NO	Repair fuel supply system
2	Disconnect high-tension cable, connect spark plug and set its electrode 5mm to engine body, then start engine to check if blue and white spark appears	YES	Next step
		NO	Repair ignition System
3	Disconnect water temp.sensor connector and start engine to check if engine can start.(or use one 2500ohm resistance to replace water temp.sensor)	YES	Repair circuit or replace sensor
		NO	Next step
4	Slightly draw throttle cable and check if engine could start easily	YES	Clean throttle body and by-pass
		NO	Next step
5	Disassemble injector and use special tool to check if there is leakage or block	YES	Replace injector
		NO	Next step
6	Check whether the failure happens right after filling fuel	YES	Change fuel
		NO	Next step
7	Check if cylinder pressure is insufficient	YES	Eliminate engine mechanic failures
		NO	Next step
8	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30 、 pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Check PDA
		NO	Check circuit

9

(5) Difficult to start in any conditions.

General failure part: 1、Water in fuel tank; 2、Fuel pump; 3、Water temp. sensor; 4、Injector; 5、Ignition coil; 6、Throttle body and by-pass; 7、Air intake pipe; 8、Ignition timing; 9、Spark plug; 10、Mechanical part of engine.

General diagnosis procedures:

Item	Procedures	Results	Next
1	Check if air filter is blocked or air intake pipe leaks	YES	Repair air intake system
		NO	Next step

CFMOTO

2	Connect fuel pump gauge, start engine, check if pressure is around 330kPa	YES	Next step
		NO	Repair fuel Supply system
3	Disconnect high-tension cable, connect spark plug and set its electrode 5mm to engine body, then start engine to check if blue and white spark appears	YES	Next step
		NO	Repair ignition System
4	Check if spark plug is suitable for requirement(including its type and clearance)	YES	Next step
		NO	Adjust or replace
5	Disconnect water temp. sensor connector and start engine to check if engine can start	YES	Repair circuit or replace sensor
		NO	Next step
6	Slightly draw throttle cable and check if engine could start easily	YES	Clean throttle body and bypass
		NO	Next step
7	Disassemble injector and use special tool to check if there is leakage or blocked.	YES	Replace injector
		NO	Next step
8	Check whether the failure happens right after filling fuel	YES	Change fuel
		NO	Next step
9	Check if cylinder pressure is insufficient	YES	Eliminate mechanical failures
		NO	Next step
10	Check if ignition timing complies with standard regulation	YES	Next step
		NO	Adjust ignition timing
11	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30、pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

(6) Normal starting, but unstable idle speed

General failure part: 1、Water in fuel tank; 2、Injector; 3、Spark plug; 4、Throttle body and by-pass; 5、Air intake pipe; 6、Air control valve; 7、Ignition timing; 8、Spark plug; 9、Mechanical part of engine

General diagnosis procedures:

Item	Procedures	Results	Next
1	Check if air filter is blocked or air intake pipe leaks	YES	Repair air intake system
		NO	Next step

9 Trouble shooting

2	Check if air control valve is blocked	YES	Clean or replace
		NO	Next step
3	Check if spark plug is suitable for requirement(including its type and clearance)	YES	Next step
		NO	Adjust or replace
4	Check if there is carbon deposit inside throttle body and air control valve	YES	Clean
		NO	Next step
5	Disassemble injector and use special tool to check if there is leakage or blocked or wrong fuel flow	YES	Replace
		NO	Next step
6	Check whether the failure happens right after filling fuel	YES	Change fuel
		NO	Next step
7	Check if cylinder pressure is insufficient	YES	Eliminate mechanical failures
		NO	Next step
8	Check if ignition timing complies with standard regulation	YES	Next step
		NO	Repair ignition timing
9	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30 , pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

9

(7) Normal starting, but unstable idle speed during engine warming

General failure part: 1、Water in fuel tank; 2、Injector; 3、Spark plug; 4、Throttle body and by-pass; 5、Air intake pipe; 6、Air control valve; 7、Mechanical part of engine

General diagnosis procedures:

Item	Procedures	Results	Next
1	Check if air filter is blocked or air intake pipe leaks	YES	Repair air intake system
		NO	Next step
2	Check if spark plug is suitable for requirement(including its type and clearance)	YES	Next step
		NO	Adjust or replace
3	Check if there is carbon deposit inside throttle body and air control valve	YES	Clean
		NO	Next step
4	Disconnect water temp. sensor connector and start engine to check idle speed is stable or not	YES	Repair circuit or replace sensor
		NO	Next step
5	Disassemble injector and use special tool to check if there is leakage or blocked or wrong fuel flow	YES	Replace
		NO	Next step

CFMOTO

6	Check whether the failure happens right after filling fuel	YES	Change fuel
		NO	Next step
7	Check if cylinder pressure is insufficient	YES	Eliminate mechanical failures
		NO	Next step
8	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30 、 pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

(8) Normal starting, but unstable idle speed after engine warming

General failure part: 1、 Water in fuel tank; 2、 Injector; 3、 Spark plug; 4、 Throttle body and by-pass; 5、 Air intake pipe; 6、 Air control valve; 7、 Mechanical part of engine

General diagnosis procedures:

Item	Procedures	Results	Next
1	Check if air filter is blocked or air intake pipe leaks	YES	Repair air intake system
		NO	Next step
2	Check if spark plug is suitable for requirement(including its type and clearance)	YES	Next step
		NO	Adjust or replace
3	Check if there is carbon deposit inside throttle body and air control valve	YES	Clean
		NO	Next step
4	Disconnect water temp. sensor connector and start engine to check idle speed is stable or not	YES	Repair circuit or replace sensor
		NO	Next step
5	Disassemble injector and use special tool to check if there is leakage or blocked or wrong fuel flow	YES	Replace
		NO	Next step
6	Check whether the failure happens right after filling fuel	YES	Change fuel
		NO	Next step
7	Check if cylinder pressure is insufficient	YES	Eliminate mechanical failures
		NO	Next step
8	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30 、 pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

(9) Normal starting, unstable idle speed or engine stop when it is electronic loaded (e.g. headlight is on)

9 Trouble shooting

General failure part: 1、 Air control valve; 2、 Injector.

General diagnosis procedures:

Item	Procedures	Results	Next
1	Disassemble air control valve and check if there is carbon deposit inside throttle body, idle adjustment and by-pass	YES	Clean related parts
		NO	Next step
2	Check if output power increases when lighting, by using PDA to test if ignition advance angle, fuel spray and air intake volume is normal	YES	To step 4
		NO	Next step
		NO	Repair air intake System
3	Disassemble injector and use special tool to check if there is leakage or blocked or wrong fuel flow	YES	Replace injector
		NO	Next step
4	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30、pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

(10) Engine starts normally, but idle speed is too high

General failure part: 1、 Throttle body and by-pass; 2、 Injector seat; 3、 Air control valve; 4、 Water temp.sensor; 5、 Ignition timing.

General diagnosis procedures:

Item	Procedures	Results	Next
1	Check if throttle cable is jammed or too tight	YES	Adjust
		NO	Next step
2	Check if there's leakage between air intake pip and injector seat	YES	Repair air intake system
		NO	Next step
3	Remove air control valve and check if there s carbon deposit inside throttle body, air control valve and by-pass	YES	Clean related Parts
		NO	Next step
4	Remove water temp. sensor connector, start engine to check if idle speed is too high	YES	Repair wiring or replace sensor
		NO	Next step
5	Check if ignition timing complies with standard regulation	YES	Next step
		NO	Repair ignition Timing

9

CFMOTO

6	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30 、 pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

(11) RPM cannot increase or engine stop when accelerating

General failure part: 1、 Water in fuel tank; 2、 TPS; 3、 Spark plug; 4、 Throttle body and by-pass; 5、 Air intake pipe; 6、 Air control valve; 7、 Injector; 8、 Ignition timing;9、 Exhaust pipe

General diagnosis procedures:

Item	Procedures	Results	Next
1	Check if air filter is blocked	YES	Repair air intake system
		NO	Next step
2	Connect fuel pressure gauge, start engine to check if pressure is around 300kPa at idle	YES	Next step
		NO	Repair fuel supply system
3	Check if spark plug is suitable for requirement(including its type and clearance)	YES	Next step
		NO	Adjust or replace
4	Remove air control valve and check if there is carbon deposit inside throttle body, air control valve and by-pass	YES	Clean related parts
		NO	Next step
5	Check if TPS and its circuit is normal	YES	Next step
		NO	Repair circuit or replace TPS
6	Disassemble injector and use special tool to check if there is leakage or blocked	YES	Replace
		NO	Next step
7	Check whether the failure happens right after filling fuel	YES	Change fuel
		NO	Next step
8	Check if ignition timing and timing order comply with standard regulation	YES	Next step
		NO	Adjust ignition timing
9	Check if exhaust gas exhale smoothly	YES	Next step
		NO	Repair or replace exhaust pipe
10	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30 、 pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

9 Trouble shooting

(12) Low acceleration

General failure part: 1、Water in fuel tank; 2、TPS; 3、Spark plug; 4、Throttle body and by-pass; 5、Air intake pipe; 6、Air control valve; 7、Injector; 8、Ignition timing; 9、Exhaust pipe

General diagnosis procedures:

Item	Procedures	Results	Next
1	Check if air filter is blocked	YES	Repair air intake system
		NO	Next step
2	Connect fuel pressure gauge, start engine to check if pressure is around 300kPa at idle	YES	Next step
		NO	Repair fuel supply system
3	Check if spark plug is suitable for requirement(including its type and clearance)	YES	Next step
		NO	Adjust or replace
4	Remove air control valve and check if there is carbon deposit inside throttle body, air control valve and by-pass	YES	Clean related parts
		NO	Next step
5	Check if TPS and its circuit is normal	YES	Next step
		NO	Repair circuit or replace TPS
6	Disassemble injector and use special tool to check if there is leakage or blocked	YES	Replace
		NO	Next step
7	Check whether the failure happens right after filling fuel	YES	Change fuel
		NO	Next step
8	Check if ignition timing and timing order comply with standard regulation	YES	Next step
		NO	Adjust ignition timing
9	Check if exhaust gas exhale smoothly	YES	Next step
		NO	Repair or replace Exhaust pipe
10	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30、pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

(13) Difficult to accelerate and bad performance

General failure part: 1、Water in fuel tank; 2、TPS; 3、Spark plug; 4、Ignition coil; 5、Throttle body and by-pass; 6、Air intake pipe; 7、Idle speed stepper motor; 8、Injector; 9、Ignition timing; 10、Exhaust pipe

General diagnosis procedures:

Item	Procedures	Results	Next
1	Check if clutch sliding, low tire pressure, bad brake or wrong tire size	YES	Repair
		NO	Next step
2	Check if air filter is blocked	YES	Repair air intake system
		NO	Next step
3	Connect fuel pressure gauge, start engine to check if pressure is around 300kPa at idle	YES	Next step
		NO	Repair fuel supply system
4	Disconnect high-tension cable, connect spark plug and set its electrode 5mm to engine body, then start engine to check if spark is strong enough	YES	Next step
		NO	Repair ignition system
5	Check if spark plug is suitable for requirement(including its type and clearance)	YES	Next step
		NO	Adjust or replace
6	Remove air control valve and check if there is carbon deposit inside throttle body, air control valve and by-pass	YES	Clean related Part
		NO	Next step
7	Check if TPS and its circuit is normal	YES	Next step
		NO	Repair circuit or Replace sensor
8	Disassemble injector and use special tool to check if there is leakage or blocked	YES	Replace
		NO	Next step
9	Check whether the failure happens right after filling fuel	YES	Change fuel
		NO	Next step
10	Check if ignition timing complies with standard regulation	YES	Next step
		NO	Repair ignition Timing
11	Check if exhaust gas exhale smoothly	YES	Next step
		NO	Repair or replace
12	Use PDA to test, turn on ignition switch, check if power supply of ECU pin 30 、 pin 32 and pin 33 is normal; check if pin 5 and pin 10 works normally	YES	Use PDA to check
		NO	Repair related circuit

